
# **MITSUBISHI**

Mitsubishi Programmable Controller



# MELSEC-L Temperature Control Module User's Manual



- -L60TCTT4
- -L60TCTT4BW
- -L60TCRT4
- -L60TCRT4BW



(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the user's manual for the CPU module used.

In this manual, the safety precautions are classified into two levels: "\_\_\_\_CAUTION" and "\_\_\_\_\_WARNING".

**!**WARNING

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

**!**CAUTION

Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "\_\_\_\_\_CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

# [Design Precautions]

### **!** WARNING

Do not write any data to the "system area" and "write-protect area" (R) of the buffer memory in the intelligent function module. Also, do not use any "use prohibited" signals as an output signal from the programmable controller CPU to the intelligent function module. Doing so may cause malfunction of the programmable controller system.

### [Design Precautions]

## **CAUTION**

 Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100mm or more between them. Failure to do so may result in malfunction due to noise.

### [Installation Precautions]

### **WARNING**

Shut off the external power supply (all phases) used in the system before mounting or removing a
module. Failure to do so may result in electric shock or cause the module to fail or malfunction.

### [Installation Precautions]

# **!** CAUTION

- Use the programmable controller in an environment that meets the general specifications in the Safety Guidelines provided with the CPU module or head module. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To interconnect modules, engage the respective connectors and securely lock the module joint levers. Incorrect interconnection may cause malfunction, failure, or drop of the module.
- Tighten the screw within the specified torque range. Undertightening can cause drop of the screw, short circuit or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Do not directly touch any conductive parts and electronic components of the module. Doing so can cause malfunction or failure of the module.

# [Wiring Precautions]

# **WARNING**

 After installation and wiring, attach the included terminal cover to the module before turning it on for operation. Failure to do so may result in electric shock.

# [Wiring Precautions]

# **CAUTION**

- Ground the FG terminal to the protective ground conductor dedicated to the programmable controller.
   Failure to do so may result in electric shock or malfunction.
- Tighten the terminal block screw within the specified torque range. Undertightening can cause short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring. Do not remove the film during wiring. Remove it for heat dissipation before system operation.
- Mitsubishi programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring methods, refer to the MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection).

# [Startup and Maintenance Precautions]

# / WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal block screw. Failure to do so may result in electric shock.

# [Startup and Maintenance Precautions]

# **!** CAUTION

- Do not disassemble or modify the module. Doing so may cause failure, malfunction, injury, or a fire.
- Shut off the external power supply (all phases) used in the system before mounting or removing a module. Failure to do so may cause the module to fail or malfunction.
- Tighten the terminal block screw within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- After the first use of the product (module, display unit, and terminal block), the number of connections/disconnections is limited to 50 times (in accordance with IEC 61131-2). Exceeding the limit may cause malfunction.
- Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.

### [Disposal Precautions]

# **!** CAUTION

When disposing of this product, treat it as industrial waste.

# CONDITIONS OF USE FOR THE PRODUCT

- (1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;
  - i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
  - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT. ("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any
  other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as
  Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation,
  Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or
  Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a
  significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTs are required. For details, please contact the Mitsubishi representative in your region.

# INTRODUCTION

Thank you for purchasing the Mitsubishi MELSEC-L series programmable controllers.

■Relevant modules: L60TCTT4, L60TCTT4BW, L60TCRT4, L60TCRT4BW

This manual describes the operating procedures, system configuration, parameter settings, functions, programming, and troubleshooting of the L series temperature control module L60TCTT4/L60TCTT4BW/L60TCRT4/L60TCRT4BW (hereafter abbreviated as L60TC4).

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC-L series programmable controller to handle the product correctly. When applying the program examples introduced in this manual to the actual system, ensure the applicability and confirm that it will not cause system control problems.

emark	•
Operating procedures are explained using GX Works? When using GX Developer, refer to Fig. Page 419, Appendix 5	

# COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

### (1) Method of ensuring compliance

To ensure that Mitsubishi programmable controllers maintain EMC and Low Voltage Directives when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to the manual included with the CPU module or head module. The CE mark on the side of the programmable controller indicates compliance with EMC and Low Voltage Directives.

### (2) Additional measures

To ensure that this product maintains EMC and Low Voltage Directives, please refer to the manual included with the CPU module or head module.

# **RELEVANT MANUALS**

# (1) CPU module user's manual

Manual name <manual (model<="" number="" th=""><th>code)&gt;</th><th>Description</th></manual>	code)>	Description
MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)	<sh-080890eng, 13jz36=""></sh-080890eng,>	Specifications of the CPU modules, power supply modules, display unit, SD memory cards, and batteries, information on how to establish a system, maintenance and inspection, and troubleshooting
MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)	<sh-080889eng, 13jz35=""></sh-080889eng,>	Functions and devices of the CPU module, and programming

# (2) Head module user's manual

Manual name <manual (model="" code)="" number=""></manual>	Description	
MELSEC-L CC-Link IE Field Network Head Module User's Manual	Specifications, procedures before operation, system configuration, installation,	
<sh-080919eng, 13jz48=""></sh-080919eng,>	wiring, settings, and troubleshooting of the head module	

### (3) Operating manual

Manual name <manual (model="" code)="" number=""></manual>	Description
GX Works2 Version 1 Operating Manual (Common) <sh-080779eng, 13ju63=""></sh-080779eng,>	System configuration, parameter settings, and online operations (common to Simple project and Structured project) of GX Works2
GX Developer Version 8 Operating Manual  SH-080373E, 13JU41>	Operating methods of GX Developer, such as programming, printing, monitoring, and debugging

# CONTENTS

SAFETY PRECAUTIONS       1         CONDITIONS OF USE FOR THE PRODUCT       4         INTRODUCTION       5         COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES       6         RELEVANT MANUALS       7         MANUAL PAGE ORGANIZATION       12         TERMS       14         PACKING LIST       15		
CHAPTER	1 WHAT CAN BE DONE WITH A TEMPERATURE CONTRO	DI MODULE 16
1.1	Use	
1.2	Features	
1.3	The PID Control System	_
1.4	About the PID Operation.	
1.4	1.4.1 Operation method and formula	
	1.4.2 The L60TC4 actions.	
	1.4.3 Proportional action (P-action).	
	1.4.4 Integral action (I-action)	
	1.4.5 Derivative action (D-action)	
	1.4.6 PID action.	
CHAPTER :	2 PART NAMES	29
CHAPTER	3 SPECIFICATIONS	31
3.1	General Specifications	31
3.2	Performance Specifications	
	3.2.1 Number of parameters to be set	
	3.2.2 Type of usable temperature sensors, temperature measurement range, re	
	and effect from wiring resistance of 1 ohm	
	3.2.3 Sampling cycle and control output cycle	38
3.3	Function List	
3.4	I/O Signal List	42
3.5	Buffer Memory List	44
CHAPTER	4 PROCEDURE BEFORE OPERATION	79
CHAPTER	5 SYSTEM CONFIGURATION	81
5.1	Total Configuration	81
5.2	Applicable Systems	
5.3	Precautions for System Configuration	
CHAPTER	6 INSTALLATION AND WIRING	84
	Installation Environment and Installation Position	
6.1		-
6.2 6.3	Terminal Block	
0.3	vviinig precautions	

6.4	Exter	nal wiring	93
	6.4.1	L60TCTT4	93
	6.4.2	L60TCTT4BW	96
	6.4.3	L60TCRT4	99
	6.4.4	L60TCRT4BW	102
6.5	Heate	er disconnection detection wiring and setting example for three-phase heater .	105
6.6	Unus	ed Channel Setting	106
CHAPTER	7 VARI	OUS SETTINGS	107
7.1	Addit	ion of Modules	107
7.2	Switc	h Setting	108
7.3	Parar	neter Setting	110
7.4	Auto	Refresh	114
7.5	Auto	Tuning	114
7.6	Sens	or Correction	114
CHAPTER	8 FUN	CTIONS	115
8.1	Temp	erature Input Mode	116
	8.1.1	Conversion enable/disable function	
	8.1.2	Temperature conversion method	
	8.1.3	Alert output function	
8.2	Temp	erature Control Mode	125
	8.2.1	Control Mode Selection Function	
	8.2.2	Control output setting at CPU stop error	128
	8.2.3	Control method.	129
	8.2.4	Manual Reset Function	137
	8.2.5	Manual Control	139
	8.2.6	Control output cycle unit selection function	140
	8.2.7	Auto tuning function	141
	8.2.8	Simple Two-degree-of-freedom	153
	8.2.9	Derivative Action Selection Function	154
	8.2.10	Setting Change Rate Limiter Setting Function	155
	8.2.11	Alert Function	157
	8.2.12	RFB Limiter Function	171
	8.2.13	Input/output (with another analog module) function	172
	8.2.14	ON delay output function	174
	8.2.15	Self-tuning function	175
	8.2.16	Peak current suppression function	185
	8.2.17	Simultaneous temperature rise function	190
	8.2.18	Forward/reverse action selection function	203
	8.2.19	Loop disconnection detection function	204
	8.2.20	Proportional band setting function	206
	8.2.21	Cooling method setting function.	207
	8.2.22	Overlap/dead band function	209
	8.2.23	Temperature conversion function (using unused channels)	212
	8.2.24	Heater disconnection detection function	215


8.3 Common Functions			8.2.25	Output off-time current error detection function	220
8.3.2 Sensor compensation function		8.3	Comr	mon Functions	.221
8.3.3 Auto configuration at input range change function			8.3.1	Temperature process value (PV) scaling function	221
8.3.4 Buffer memory data backup function			8.3.2	Sensor compensation function	223
8.3.5 Error history function			8.3.3	Auto configuration at input range change function	234
8.3.6 Module error history collection function			8.3.4	Buffer memory data backup function	235
### 241  ### 243  ### 244  ### 244  ### 244  ### 245  ### 244  ##			8.3.5	Error history function	237
### PAPTER 9 DISPLAY UNIT  9.1 Display Unit			8.3.6	Module error history collection function	239
9.1       Display Unit.       .241         9.2       Menu Transition       .241         9.3       Setting Value Change Screen List       .243         9.4       Checking and Clearing Errors.       .248         CHAPTER 10 PROGRAMMING       .250         10.1       Programming Procedure.       .250         10.2       When Using the Module in a Standard System Configuration       .252         10.2.1       When using the L60TC4 as a temperature input module.       .252         10.2.2       Standard control (such as auto tuning, self-tuning, and error code read)       .263         10.2.3       Standard control (peak current suppression function, simultaneous temperature rise function)       .274         10.2.4       When performing the heating-cooling control       .288         10.3       When the Module is Connected to the Head Module       .298         CHAPTER 11 TROUBLESHOOTING       308         11.1       Before Troubleshooting       308         11.2       Troubleshooting Procedure       .308         11.3       When the RUN LED flashes or turns off       .310         11.3.1       When the RUN LED flashes or turns off       .310         11.3.2       When the RUN LED flashes or turns off       .310         11.3.3       <			8.3.7		
9.1       Display Unit.       .241         9.2       Menu Transition       .241         9.3       Setting Value Change Screen List       .243         9.4       Checking and Clearing Errors.       .248         CHAPTER 10 PROGRAMMING       .250         10.1       Programming Procedure.       .250         10.2       When Using the Module in a Standard System Configuration       .252         10.2.1       When using the L60TC4 as a temperature input module.       .252         10.2.2       Standard control (such as auto tuning, self-tuning, and error code read)       .263         10.2.3       Standard control (peak current suppression function, simultaneous temperature rise function)       .274         10.2.4       When performing the heating-cooling control       .288         10.3       When the Module is Connected to the Head Module       .298         CHAPTER 11 TROUBLESHOOTING       308         11.1       Before Troubleshooting       308         11.2       Troubleshooting Procedure       .308         11.3       When the RUN LED flashes or turns off       .310         11.3.1       When the RUN LED flashes or turns off       .310         11.3.2       When the RUN LED flashes or turns off       .310         11.3.3       <					
9.2 Menu Transition       241         9.3 Setting Value Change Screen List       243         9.4 Checking and Clearing Errors       248         CHAPTER 10 PROGRAMMING       250         10.1 Programming Procedure       250         10.2 When Using the Module in a Standard System Configuration       252         10.2.1 When using the L60TC4 as a temperature input module       252         10.2.2 Standard control (such as auto tuning, self-tuning, and error code read)       263         10.2.3 Standard control (peak current suppression function, simultaneous temperature rise function)       274         10.2.4 When performing the heating-cooling control       288         10.3 When the Module is Connected to the Head Module       298         CHAPTER 11 TROUBLESHOOTING       308         11.1 Before Troubleshooting       308         11.2 Troubleshooting Procedure       308         11.3 Checks Using LEDs       310         11.3.1 When the RRN LED turns on or flashes       310         11.3.2 When the ERR, LED turns on or flashes       310         11.3.3 When the ALM LED turns on or flashes       311         11.4 When Module READY flag (Xn0) does not turn on       312         11.4.1 When Error occurrence flag (Xn2) is on       312         11.4.2 When Error occurrence flag (Xn2) is on       312	CHAP	TER 9	DISF	PLAY UNIT	241
9.3 Setting Value Change Screen List		9.1	Displa	ay Unit	.241
9.3 Setting Value Change Screen List		9.2	Menu	ı Transition	.241
### Checking and Clearing Errors.  ### CHAPTER 10 PROGRAMMING    10.1 Programming Procedure.		9.3			
### CHAPTER 10 PROGRAMMING  10.1 Programming Procedure.  10.2 When Using the Module in a Standard System Configuration  252  10.2.1 When using the L60TC4 as a temperature input module.  252  10.2.2 Standard control (such as auto tuning, self-tuning, and error code read)  263  10.2.3 Standard control (peak current suppression function, simultaneous temperature rise function).  274  10.2.4 When performing the heating-cooling control  288  10.3 When the Module is Connected to the Head Module  298  **CHAPTER 11 TROUBLESHOOTING  308  11.1 Before Troubleshooting  308  11.2 Troubleshooting Procedure  308  11.3 Checks Using LEDs  310  11.3.1 When the RUN LED flashes or turns off  310  11.3.2 When the ERR. LED turns on or flashes  310  11.3.3 When the ALM LED turns on or flashes  311  11.4 Checks Using Input Signals  312  11.4.1 When Module READY flag (Xn0) does not turn on  312  11.4.2 When Error occurrence flag (Xn2) is on  312  11.4.3 When Hardware error flag (Xn3) is on  312  11.4.4 When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn off)  313  11.4.6 When the self-tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn off)  313  11.4.7 When Back-up of the set value fall flag (XnA) is on  313					
10.1 Programming Procedure		3.4	Office	king and Oleaning Entris.	.240
10.2 When Using the Module in a Standard System Configuration	 CHAP	TER 1	0 PR	OGRAMMING	250
10.2 When Using the Module in a Standard System Configuration		10.1	Drogr	ramming Procedure	250
10.2.1 When using the L60TC4 as a temperature input module					
10.2.2 Standard control (such as auto tuning, self-tuning, and error code read)  10.2.3 Standard control (peak current suppression function, simultaneous temperature rise function)		10.2			
10.2.3 Standard control (peak current suppression function, simultaneous temperature rise function)					
rise function)					263
10.2.4 When performing the heating-cooling control			10.2.3		
10.3       When the Module is Connected to the Head Module       298         CHAPTER 11 TROUBLESHOOTING       308         11.1       Before Troubleshooting Procedure       308         11.2       Troubleshooting Procedure       308         11.3       Checks Using LEDs       310         11.3.1       When the RUN LED flashes or turns off       310         11.3.2       When the ERR. LED turns on or flashes       310         11.3.3       When the ALM LED turns on or flashes       311         11.4       Checks Using Input Signals       312         11.4.1       When Module READY flag (Xn0) does not turn on       312         11.4.2       When Error occurrence flag (Xn2) is on       312         11.4.3       When Hardware error flag (Xn3) is on       312         11.4.4       When the auto tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       312         11.4.5       When the auto tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)       313         11.4.6       When the self-tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       313         11.4.7       When Back-up of the set value fail flag (XnA) is on       313					
CHAPTER 11 TROUBLESHOOTING       308         11.1 Before Troubleshooting       308         11.2 Troubleshooting Procedure       308         11.3 Checks Using LEDs       310         11.3.1 When the RUN LED flashes or turns off       310         11.3.2 When the ERR. LED turns on or flashes       310         11.3.3 When the ALM LED turns on or flashes       311         11.4 Checks Using Input Signals       312         11.4.1 When Module READY flag (Xn0) does not turn on       312         11.4.2 When Error occurrence flag (Xn2) is on       312         11.4.3 When Hardware error flag (Xn3) is on       312         11.4.4 When the auto tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       312         11.4.5 When the auto tuning does not complete       (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)       313         11.4.6 When the self-tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       313         11.4.7 When Back-up of the set value fail flag (XnA) is on       313			10.2.4	When performing the heating-cooling control	288
11.1 Before Troubleshooting       308         11.2 Troubleshooting Procedure       308         11.3 Checks Using LEDs       310         11.3.1 When the RUN LED flashes or turns off       310         11.3.2 When the ERR. LED turns on or flashes       310         11.3.3 When the ALM LED turns on or flashes       311         11.4 Checks Using Input Signals       312         11.4.1 When Module READY flag (Xn0) does not turn on       312         11.4.2 When Error occurrence flag (Xn2) is on       312         11.4.3 When Hardware error flag (Xn3) is on       312         11.4.4 When the auto tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       312         11.4.5 When the auto tuning does not complete       (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)       313         11.4.6 When the self-tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       313         11.4.7 When Back-up of the set value fail flag (XnA) is on       313		10.3	Wher	n the Module is Connected to the Head Module	.298
11.2 Troubleshooting Procedure       308         11.3 Checks Using LEDs       310         11.3.1 When the RUN LED flashes or turns off       310         11.3.2 When the ERR. LED turns on or flashes       310         11.3.3 When the ALM LED turns on or flashes       311         11.4 Checks Using Input Signals       312         11.4.1 When Module READY flag (Xn0) does not turn on       312         11.4.2 When Error occurrence flag (Xn2) is on       312         11.4.3 When Hardware error flag (Xn3) is on       312         11.4.4 When the auto tuning does not start					
11.2 Troubleshooting Procedure       308         11.3 Checks Using LEDs       310         11.3.1 When the RUN LED flashes or turns off       310         11.3.2 When the ERR. LED turns on or flashes       310         11.3.3 When the ALM LED turns on or flashes       311         11.4 Checks Using Input Signals       312         11.4.1 When Module READY flag (Xn0) does not turn on       312         11.4.2 When Error occurrence flag (Xn2) is on       312         11.4.3 When Hardware error flag (Xn3) is on       312         11.4.4 When the auto tuning does not start	CHAP	TER 1	1 TR(	DUBLESHOOTING	308
11.3 Checks Using LEDs       310         11.3.1 When the RUN LED flashes or turns off       310         11.3.2 When the ERR. LED turns on or flashes       310         11.3.3 When the ALM LED turns on or flashes       311         11.4 Checks Using Input Signals       312         11.4.1 When Module READY flag (Xn0) does not turn on       312         11.4.2 When Error occurrence flag (Xn2) is on       312         11.4.3 When Hardware error flag (Xn3) is on       312         11.4.4 When the auto tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       312         11.4.5 When the auto tuning does not complete       (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)       313         11.4.6 When the self-tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       313         11.4.7 When Back-up of the set value fail flag (XnA) is on       313	CHAP				
11.3.1       When the RUN LED flashes or turns off       .310         11.3.2       When the ERR. LED turns on or flashes       .310         11.3.3       When the ALM LED turns on or flashes       .311         11.4       Checks Using Input Signals       .312         11.4.1       When Module READY flag (Xn0) does not turn on       .312         11.4.2       When Error occurrence flag (Xn2) is on       .312         11.4.3       When Hardware error flag (Xn3) is on       .312         11.4.4       When the auto tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       .312         11.4.5       When the auto tuning does not complete       (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)       .313         11.4.6       When the self-tuning does not start       (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)       .313         11.4.7       When Back-up of the set value fail flag (XnA) is on       .313	CHAP	11.1	Befor	e Troubleshooting	.308
11.3.2 When the ERR. LED turns on or flashes	CHAF	11.1 11.2	Befor Trouk	re Troubleshooting	.308
11.3.3 When the ALM LED turns on or flashes.  11.4 Checks Using Input Signals  11.4.1 When Module READY flag (Xn0) does not turn on  11.4.2 When Error occurrence flag (Xn2) is on.  11.4.3 When Hardware error flag (Xn3) is on.  11.4.4 When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  11.4.5 When the auto tuning does not complete  (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)  11.4.6 When the self-tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  313  11.4.7 When Back-up of the set value fail flag (XnA) is on.  314	CHAP	11.1 11.2	Befor Troub Chec	re Troubleshooting Deshooting Procedure Using LEDs	.308 .308 .310
11.4 Checks Using Input Signals	CHAP	11.1 11.2	Befor Troub Chec 11.3.1	re Troubleshooting  Dleshooting Procedure  ks Using LEDs  When the RUN LED flashes or turns off	.308 .308 .310 .310
11.4.1 When Module READY flag (Xn0) does not turn on	CHAP	11.1 11.2	Befor Troub Chec 11.3.1 11.3.2	re Troubleshooting  Dieshooting Procedure  Eks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes	.308 .308 .310 .310 .310
11.4.2 When Error occurrence flag (Xn2) is on	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3	re Troubleshooting Deshooting Procedure Usks Using LEDs When the RUN LED flashes or turns off When the ERR. LED turns on or flashes When the ALM LED turns on or flashes	.308 .308 .310 .310 .310 .311
11.4.3 When Hardware error flag (Xn3) is on	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3	re Troubleshooting Dieshooting Procedure Usks Using LEDs When the RUN LED flashes or turns off When the ERR. LED turns on or flashes When the ALM LED turns on or flashes Using Input Signals	308 308 310 310 310 311 311
11.4.4 When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec	re Troubleshooting  pleshooting Procedure  pleshooting LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  pleshooting Input Signals  When Module READY flag (Xn0) does not turn on	308 308 310 310 310 311 312 312
(CH□ Auto tuning status (Xn4 to Xn7) does not turn on)	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1	re Troubleshooting  Dieshooting Procedure  Eks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  Eks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on	308 308 310 310 310 311 312 312 312
11.4.5 When the auto tuning does not complete  (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2	re Troubleshooting  Dieshooting Procedure  Eks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  Eks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on	308 308 310 310 310 311 312 312 312
(CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3	re Troubleshooting  pleshooting Procedure  pleshooting Procedure  pleshooting LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  Pleshooting Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on  When Hardware error flag (Xn3) is on	308 308 310 310 310 311 312 312 312
11.4.6 When the self-tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3	re Troubleshooting  Dieshooting Procedure  Eks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  Eks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on  When Hardware error flag (Xn3) is on  When the auto tuning does not start	308 308 310 310 311 312 312 312 312
(CH□ Auto tuning status (Xn4 to Xn7) does not turn on)	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3 11.4.4	re Troubleshooting  pleshooting Procedure  ks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  ks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on  When Hardware error flag (Xn3) is on  When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)	308 308 310 310 311 312 312 312 312
11.4.7 When Back-up of the set value fail flag (XnA) is on	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3 11.4.4	re Troubleshooting  Dieshooting Procedure  Eks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  Eks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on.  When Hardware error flag (Xn3) is on  When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  When the auto tuning does not complete	308 308 310 310 311 312 312 312 312 312
11.4.7 When Back-up of the set value fail flag (XnA) is on	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3 11.4.4	re Troubleshooting  cleshooting Procedure  cks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  cks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on.  When Hardware error flag (Xn3) is on  When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  When the auto tuning does not complete  (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)	308 308 310 310 311 312 312 312 312 312
	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3 11.4.4	re Troubleshooting  cleshooting Procedure  cks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  cks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on.  When Hardware error flag (Xn3) is on  When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  When the auto tuning does not complete  (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)  When the self-tuning does not start	308 308 310 310 311 312 312 312 312 312 313
TILLIO TITION OF IMPROVED COUNTY FOR THE PROPERTY OF THE PROPE	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3 11.4.4 11.4.5	re Troubleshooting  cleshooting Procedure  cks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  cks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on.  When Hardware error flag (Xn3) is on  When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  When the self-tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)  When the self-tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)	308 308 310 310 311 312 312 312 312 312 313
TITO WHOLI OLI PUOL COCALICIO II I	CHAF	11.1 11.2 11.3	Befor Troub Chec 11.3.1 11.3.2 11.3.3 Chec 11.4.1 11.4.2 11.4.3 11.4.4	re Troubleshooting  Dieshooting Procedure  Eks Using LEDs  When the RUN LED flashes or turns off  When the ERR. LED turns on or flashes  When the ALM LED turns on or flashes  Eks Using Input Signals  When Module READY flag (Xn0) does not turn on  When Error occurrence flag (Xn2) is on.  When Hardware error flag (Xn3) is on  When the auto tuning does not start  (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)  When the auto tuning does not complete	308 308 310 310 311 312 312 312 312 312

	11.5 Troubleshooting by Symptom	
	11.5.1 When the temperature process value (PV) is abnormal	314
	11.6 Error Code List	
	11.7 Alarm Code List	
	11.8 Check the L60TC4 Status	
APPEN	NDICES	323
	Appendix 1 Details of I/O Signals	
	Appendix 1.1 Input signal	323
	Appendix 1.2 Output signal	330
	Appendix 2 Details of the Buffer Memory	
	Appendix 3 How to Check the Serial Number and Function Version	416
	Appendix 4 Differences with MELSEC-Q series Modules	417
	Appendix 4.1 Differences with temperature control modules	417
	Appendix 5 When Using GX Developer	419
	Appendix 5.1 I/O assignment and intelligent function module switch setting	419
	Appendix 5.2 Initial setting and auto refresh setting	422
	Appendix 6 External Dimensions	
INDEX		426
	SIONS	


# MANUAL PAGE ORGANIZATION

In this manual, pages are organized and the symbols are used as shown below.

The following illustration is for explanation purpose only, and should not be referred to as an actual documentation.




\*1 The mouse operation example is provided below.



Pages describing buffer memory areas and functions are organized as shown below.

The following illustration is for explanation purpose only, and should not be referred to as an actual documentation.



Icon	Meaning
Common to all modes	This icon means that the buffer memory area or function can be used in both temperature control mode and temperature input mode.
Temperature control mode	This icon means that the buffer memory area or function for temperature control can be used in the standard control.  The buffer memory area and function can be used in the following control modes and channels:  • CH1 to CH4 in the standard control  • CH3 and CH4 in the mix control (normal mode)  • CH3 and CH4 in the mix control (expanded mode)
Heating-cooling	This icon means that the buffer memory or function for temperature control can be used in the heating-cooling control.  The buffer memory area and function can be used in the following control modes and channels:  • CH1 and CH2 in the heating-cooling control (normal mode)  • CH1 to CH4 in the heating-cooling control (expanded mode)  • CH1 in the mix control (normal mode)  • CH1 and CH2 in the mix control (expanded mode)
Temperature input mode	This icon means that the buffer memory area or function can be used in the temperature input mode.

# **TERMS**


Unless otherwise specified, this manual uses the following terms.

Term	Description
L60TCTT4	The abbreviation for the L60TCTT4 temperature control module
L60TCTT4BW	The abbreviation for the L60TCTT4BW temperature control module with the disconnection detection function
L60TCRT4	The abbreviation for the L60TCRT4 temperature control module
L60TCRT4BW	The abbreviation for the L60TCRT4BW temperature control module with the disconnection detection function
L60TC4	A generic term for the L60TCTT4, L60TCTT4BW, L60TCRT4, and L60TCRT4BW
PID constants	A generic term for the proportional band (P), integral time (I), and derivative time (D)
Temperature sensor	A generic term for thermocouples and platinum resistance thermometers
Control method	A generic term for two-position control, P control, PI control, PD control, and PID control
Temperature input mode	The mode to use the L60TC4 as a temperature input module
Temperature control mode	The mode to use the L60TC4 as a temperature control module
Control mode	A generic term for the standard control, heating-cooling control (normal mode), heating-cooling control (expanded mode), mix control (normal mode), and mix control (expanded mode) when the L60TC4 is used in the temperature control mode
Fixed value action	The operating status of when the set value (SV) is fixed
Full scale	A full input range. For example, when the selected input range is -200.0°C to 400.0°C, the full scale is 600.0.
Ramp action	The operating status of when the set value (SV) is constantly changed
Number of loops	The number of feedback control systems (closed-loop control systems) that can be configured using one module. Under the standard control, one loop consists of one input and one output. Under the heating-cooling control, one loop consists of one input and two outputs.
CPU module	Another term for the MELSEC-L series CPU module
Head module	The abbreviation for the LJ72GF15-T2 CC-Link IE Field Network head module
Display unit	A liquid crystal display to be attached to the CPU module
External input	The abbreviation for input from connectors for external devices
External output	The abbreviation for output to connectors for external devices
Programming tool	A generic term for GX Works2 and GX Developer
GX Works2	The product name of the software package for the MELSEC programmable
GX Developer	controllers
Buffer memory	The memory of an intelligent function module used to store data (such as setting values and monitored values) for communication with a CPU module

# **PACKING LIST**

The following items are included in the package of this product. Before use, check that all the items are included.

### L60TCTT4, L60TCRT4






L60TCTT4, L60TCRT4

Before Using the Product

### L60TCTT4BW, L60TCRT4BW







Before Using the Product

# CHAPTER 1 WHAT CAN BE DONE WITH A TEMPERATURE CONTROL MODULE

# 1.1 Use


The L60TC4 performs PID operation to reach the target temperature based on input from an external temperature sensor. The module controls temperature by outputting the operation result to a heater or others in transistor output.

# Point P

The L60TCTT4BW and L60TCRT4BW are L60TCTT4 and L60TCRT4-based modules which possess an additional function to detect heater disconnection using input from external current sensors.


### Ex. Standard control (heating)

The input from a temperature sensor is processed with PID operation, and the heater temperature is controlled.




Ex. Heating-cooling control (heating and cooling)

Heating and cooling are processed when the target temperature is lower than the ambient temperature or when the temperature of the target subject is easy to change.



Ex. Temperature input (temperature input only)

The L60TC4 can be used as a temperature input module also.



# 1.2 Features


This section describes the L60TC4 features. For functions not described here, refer to the list of functions. (Fig. Page 39, Section 3.3)

### (1) Optimum temperature adjustment control (PID control)

- The L60TC4 performs temperature adjustment control automatically when the user simply sets PID constants necessary for PID operation: proportional band (P), integral time (I), derivative time (D), and temperature set value (SV). No special instruction is necessary to perform PID control.
- Using the auto tuning function or self-tuning function enables the PID constants to be set automatically by the L60TC4. Complicated PID operational expressions to determine PID constants are not necessary.


### (2) Combination of control mode

A control mode can be selected from the standard control (heating or cooling), heating-cooling control (heating and cooling), or mix control (combination of the standard control and heating-cooling control).



### (3) Four loops on one module


The maximum of four loops of temperature adjustment control can be performed simultaneously. In addition, loop control can be performed using analog modules in the system; input from an A/D converter module or output to a D/A converter module can be processed.



# I.2 Features


### (4) Simultaneous temperature rise of multiple loops

Temperatures of multiple loops can be adjusted to simultaneously reach the set value of each; temperatures are controlled evenly without any partial heat exaggeration.



This function saves energy and cost.

Ex. Comparison of temperature rises on CH1 when using and not using the simultaneous temperature rise function



### (5) Suppression of peak current

Current flows into a heater can be suppressed by controlling output so that each channel's output does not turn on at the same time as other channels.

This function saves energy and cost.

### (6) RFB limiter function

The RFB (Reset feed back) limiter suppresses overshoot which is liable to occur at a startup or when a temperature process value (PV) is increased.

### (7) Correction of temperature process value (PV)

The difference between the temperature process value (PV) and actual temperature can be corrected easily using the following functions.

- 1-point sensor compensation (standard) function: Corrects the difference by setting the rate of correction value to the full scale of the input range.
- 2-point sensor compensation function: Corrects the difference based on the inclination of the line on the two points set in advance.
- · Primary delay digital filter setting: Smoothens extreme noise, and absorbs drastic change.

### (8) Non-volatile memory for backing up set values

The set values in the buffer memory, such as the setting related to PID control, can be stored into a non-volatile memory for data backup. The values do not need to be reset after turning the power on from off or releasing the CPU module from its reset status.

Using the test function of the programming tool to write data directly to the buffer memory, the minimum sequence program required is "LD\*\*" + "OUT Yn1".

### (9) Detection of disconnection

Heater disconnection can be detected easily by the loop disconnection detection function.

The L60TCTT4BW and L60TCRT4BW can detect the disconnection of a heater accurately.

#### (10)Selectable sampling cycle

The module can be applied to wide range of systems since the sampling cycle can be selected from 250ms/4 channels or 500ms/4 channels.

### (11)Use as a temperature input module

The L60TC4 can be used not only as a temperature control module, but also as a temperature input module. The mode can be switched easily by a setting.

In addition, The temperature input can be processed through the primary delay digital filter, or output as an alert. (Fig. Page 116, Section 8.1)

#### (12) Easy setting by GX Works2


Sequence program can be reduced by configuring the default setting or auto refresh setting on the screen. Also, the setting status or operating status of the module can be checked easily.

# 1.3 The PID Control System

This section explains the PID control of the L60TC4.


### (1) PID control system

The following figure shows a system of when performing the PID control.



### (2) PID control procedure


The PID control is performed in the following procedure.



### (3) PID control (simple two-degree-of-freedom)

The L60TC4 operates in "simple two-degree-of-freedom". In this form of PID control, parameters are simplified compared to the two-degree-of-freedom PID control.

In the simple two-degree-of-freedom, the module controls the target subject using not only PID constants but also the control response parameter. The parameter can be set to "fast", "normal", or "slow". This setting enables the form of "response to the change of the set value (SV)" to change maintaining "response to the disturbance" in a good condition. (Fig. Page 153, Section 8.2.8)




The following explains the difference between the one-degree-of-freedom PID control, two-degree-of-freedom PID control, and simple two-degree-of-freedom PID control.

#### (a) One-degree-of-freedom PID control and two-degree-of-freedom PID control

- General PID control is called one-degree-of freedom PID control. In the one-degree-of freedom PID
  control, when PID constants to improve "response to the change of the set value (SV)" are set, "response
  to the disturbance" degrades. Conversely, when PID constants to improve "response to the disturbance"
  are set, "response to the change of the set value (SV)" degrades.
- In the two-degree-of-freedom PID control, a manipulated value (MV) is determined considering the set value (SV) or variations. In this form of PID control, "response to the change of the set value (SV)" and "response to the disturbance" can be compatible with each other.

# (b) Two-degree-of-freedom PID control and simple two-degree-of-freedom PID control The following figure is a block diagram of the two-degree-of-freedom PID control.



By setting  $\alpha$ ,  $\beta$ , and  $\gamma$  above properly, optimum control can be achieved.

Note that required parameter settings increase and PID constants can hardly be auto-set by the auto tuning function for complete two-degree-of-freedom PID control. Therefore, the L60TC4 operates in the simple two-degree-of-freedom PID control for which parameters are simplified.

#### 1.4 **About the PID Operation**


The L60TC4 can perform PID control in process-value incomplete derivation.

#### 1.4.1 Operation method and formula

The PID control in process-value incomplete derivation is an operation method which puts a primary delay filter on input from a derivative action and eliminate high-frequency noise component in order to perform a PID operation on the deviation (E).

### (1) Algorithm of PID control in process-value incomplete derivation

The algorithm of PID control in process-value incomplete derivation is shown below.



Ti: Integral time

s: Laplace transform conversion

Tp: Derivative time

### (2) Formula

The formula used for the L60TC4 is shown below.

$$MV_{n} = MV_{n-1} + \frac{T_{D}}{\tau + \eta \cdot T_{D}} \left\{ (PV_{n-1} - PV_{n}) - \frac{\tau}{T_{D}} \cdot MV_{n-1} \right\}$$

τ : Sampling period

MV: Incomplete derivative output

PV: Temperature process value (PV)

To: Derivative time : Derivative

Remark

The PID control in process-value derivation is an operation method which uses the process value (PV) for the derivation section in order to perform a PID operation. Not using deviation for the derivation section, drastic output change due to a derivative action is reduced when deviation varies along with the setting value change.


# 1.4.2 The L60TC4 actions


The L60TC4 performs PID operations in forward actions and reverse actions.

### (1) Forward action

In a forward action, the manipulated value (MV) is increased when the temperature process value (PV) increases from the set value (SV).

A forward action is used for cooling control.







### (2) Reverse action

In a reverse action, the manipulated value is increased when the temperature process value (PV) decreases from the set value (SV).

A reverse action is used for heating control.





# **1.4.3** Proportional action (P-action)

A proportional action is an action to obtain the manipulated value (MV) proportional to the deviation (difference between the set value (SV) and the process value (PV)).

### (1) Proportional gain

In a proportional action, the relationship between changes in the deviation (E) and the manipulated value can be expressed in the following formula:


MV = KP•E

where Kp is a proportional constant and is called proportional gain. The manipulated value (MV) varies in the range from -5.0% to 105.0%.

The following table describes the difference of actions depending on the value of Kp, proportional gain.

Condition	Proportional action
Kp is a small value	The control action slows down.
Kp is a large value	The control action speeds up, though the temperature process value (PV) tends to fluctuate around the set value.


A proportional action is as shown below for step responses where the deviation (E) is a fixed value.



### (2) Offset

The certain amount of difference generates between the temperature process value (PV) and the set value (SV) is called an offset (remaining deviation).

In an proportional action, an offset (remaining deviation) generates.



# 1.4.4 Integral action (I-action)

An integral action is an action which continuously changes the manipulated value (MV) to eliminate the deviation (E) when there is any.


The offset caused by a proportional action can be eliminated.

In an integral action, the time from a deviation occurrence until when the manipulated value (MV) of the integral action becomes equals to that of the proportional action is called integral time, and is indicated as Ti.

The following table describes the difference of actions depending on the value of T<sub>I</sub>, integral time.

Condition	Integral action
Tı is a small value	The integral effect gets large, and time to eliminate the offset gets short.  Though, the temperature process value (PV) tends to fluctuate around the set value.
Tı is a large value	The integral effect gets small, and time to eliminate the offset gets long.

The following figure shows an integral action of step responses where the deviation (E) is a fixed value.



An integral action is used as a PI action in combination with a proportional action, or PID action in combination with a proportional and derivative actions.

An integral action cannot be used by itself.

# 1.4.5 Derivative action (D-action)


A derivative action adds the manipulated value (MV) proportional to the rate of change to eliminate the deviation (E) when it occurs.

A derivative action can prevent the control target from changing significantly due to disturbance.

In an integral action, the time from a deviation occurrence until when the manipulated value (MV) of the derivative action becomes equals to that of the proportional action is called derivative time, and is indicated as T<sub>D</sub>. The following table describes the difference of actions depending on the value of T<sub>D</sub>, derivative time.

Condition	Derivative action	
To is a small value	The derivative effect gets small.	
T <sub>D</sub> is a large value	The derivative effect gets large.  Though, the temperature process value (PV) tends to fluctuate around the set value in short cycles.	

The following figure shows a derivative action of step responses where the deviation (E) is a fixed value.




A derivative action is used as a PD action in combination with a proportional action, or PID action in combination with a proportional and integral actions.

A derivative action cannot be used by itself.

# 1.4.6 PID action


A PID action performs control using the manipulated value (MV) calculated by merging the proportional action, integral action, and derivative action.

The following figure shows a PID action of step responses where the deviation (E) is a fixed value.



# CHAPTER 2 PART NAMES

The following table shows part names of the L60TC4.



Number	r Name		Description		
1)	Module joint levers		Levers for connecting modules		
	RUN LED		Indicates the operating status of the L60TC4.		
		ON	Operating normally		
			The power is not supplied.		
		OFF	The watchdog timer error has occurred.		
		OFF	CPU stop error has occurred when all channels are set to "CLEAR" on Switch Setting.		
			A value out of the setting range was set on Switch Setting 2 to 5.		
	ERR. LED		Indicates the error status of the L60TC4.		
		ON	Hardware fault (Including no connection of a cold junction temperature compensation resistor)		
		Flicker	Error occurring (Page 334, Appendix 2 (1))		
	OFF		Operating normally		
2)	ALM LED		Indicates the alert status of the L60TC4.		
	ON		Alert is occurring.		
		Flicker	Temperature process value (PV) came out of temperature measurement range.		
			Loop disconnection was detected.		
			Temperature sensor is not connected.		
		OFF	Alert is not occurring.		
	HBA LED (the L60TCTT4BW and				
			Indicates the heater disconnection detection status of the L60TCTT4BW and L60TCRT4BW.		
	L60TCRT4BW only)				
		ON	Heater disconnection was detected.		
	OFF		Heater disconnection is not detected.		

Number	Name	Description		
3)	Terminal block for I/O	Used for temperature sensor input and transistor output.		
3)	Terminal block for I/O	(Frage 85, Section 6.2)		
4)	Terminal block for CT	Ised for current sensor (CT) input.		
5)	Cold junction temperature compensation resistor (the L60TCTT4 and L60TCTT4BW only)	Used when cold junction temperature compensation is executed for the L60TCTT4 and L60TCTT4BW.		
6)	DIN rail hook	A hook used to mount the module to a DIN rail.		
7)	Serial number plate	Displays the serial number printed on the rating plate. For the L60TCTT4BW, L60TCRT4BW, the serial number is displayed on the terminal block for CT.		

# 3.1 General Specifications

# **CHAPTER 3** SPECIFICATIONS

This chapter describes general specifications, performance specifications, the function list, the I/O signal list, and the buffer memory list.

# 3.1 General Specifications

For the general specifications of the L60TC4, refer to the following manual.

"Safety Guidelines", the manual supplied with a CPU module or head module

# **3.2** Performance Specifications

The following table lists the performance specifications of the L60TC4.

lto un		Specifications				
	Item			L60TCRT4	L60TCTT4BW	L60TCRT4BW
Control output			Transistor output			
Number of temperature input points			4 channe	ls/module		
Type of usable temperature sensors, the temperature measurement range, the resolution, and the effect from wiring resistance of $1\Omega$		Page 36, Section 3.2.2				
Indication	Indication	Ambient temperature: 25±5°C	Full scale × (±0.3%)			
	accuracy	Ambient temperature: 0 to 55°C	Full scale × (±0.7%)			
Accuracy*1	Cold junction temperature compensation	Temperature process value (PV): -100°C or more	Within ±1.0°C		Within ±1.0°C	
	accuracy: (ambient	Temperature process value (PV): -150 to -100°C	Within ±2.0°C	_	Within ±2.0°C	_
	temperature: 0 to 55°C)	Temperature process value (PV): -200 to -150°C	Within ±3.0°C		Within ±3.0°C	
Sampling cy	Sampling cycle		250ms/4 channels			
Control outs			500ms/4 channels			
Input imped			0.5 to 100.0s			
Input filter	ance		1MΩ 0 to 100s (0: Input filter OFF)			
	ection value setti	na	-50.00 to 50.00%			
	t sensor input dis		Upscale processing			
	e control method		PID ON/OFF pulse or two-position control			
		PID constants setting	Can be set by auto tuning.			
		Proportional band (P)	0.0 to 1000.0% (0: Two-position control)			
PID constar	its range	Integral time (I)	0 to 3600s (set 0 for P control and PD control.)			
		Derivative time (D)	0 to 3600s (set 0 for P control and PI control.)			
Set value (S	V) setting range		Within the temperature range set in the thermocouple/platinum resistance thermometer to be used			
Dead band	setting range		0.1 to 10.0%			
		Output signal		ON/OF	F pulse	
		Rated load voltage		10 to 3	30VDC	
		Max. load current		0.1A/point, 0	.4A/common	
L		Max. inrush current		0.4A	10ms	
		Leakage current at OFF	0.1mA or less			
		Max. voltage drop at ON	1.0VDC (TYP) at 0.1A 2.5VDC (MAX) at 0.1A			1A
		Response time	OFF→ON: 2ms or less, ON→OFF: 2ms or less			ess
Number of a	Number of accesses to non-volatile memory		Max. 10 <sup>12</sup> times			
Insulation method		Between input terminal and programmable controller power supply: Transformer insulation				
		Between input channels: Transformer insulation				

ltem		Specifications				
		L60TCTT4	L60TCRT4	L60TCTT4BW	L60TCRT4BW	
Dielectric withstand voltage		Between input terminal and programmable controller power supply: 500VAC for				
			1 minute			
		Be	tween input channel	s: 500VAC for 1 mini	ute	
		Between input ter	minal and programm	able controller powe	r supply: 500VDC	
Insulation resistance		20M $Ω$ or more				
		Betv	Between input channels: 500VDC 20M $\Omega$ or more			
Heater disconnection detection specifications	Current sensor	_		Page 82, Section 5.2 (4)		
	Input accuracy			Full scale × (±1.0%)		
	Number of alert delay			3 to 255		
Number of occupied I/O points		16 points (I/O assignment: 16 intelligent points)				
Number of occupied module		1		2		
Connected terminal		18-point terminal block Two		Two 18-point t	erminal blocks	
Applicable wire size		0.3mm <sup>2</sup> to 0.75mm <sup>2</sup>				
Applicable solderless terminal		R1.25-3 (Solderless terminal with sleeve is unavailable.)				
Internal current consumption		0.30A	0.31A	0.33A	0.35A	
Weight		0.18kg		0.33kg		
Outline dimensions		28.5(W)mm × 90(H)mm × 117(D)mm		57.0(W)mm × 90(H)mm × 117(D)mm		

Calculate the accuracy in the following method (only when it is not affected by noise).

Accuracy (°C) = full scale × indication accuracy + cold junction temperature compensation accuracy

Ex. Accuracy at the input range of 38 (-200.0 to 400.0°C), the operating ambient temperature of 35°C, and the temperature process value (PV) of 300°C

(Full scale) × (indication accuracy) + cold junction temperature compensation accuracy =  $(400.0^{\circ}\text{C} - (-200.0^{\circ}\text{C})) \times (\pm 0.007) + (\pm 1.0^{\circ}\text{C})$  =  $\pm 5.2^{\circ}\text{C}$ 

For the noise immunity, dielectric withstand voltage, insulation resistance and others of the programmable controller system which uses the L60TC4, refer to the following manual.

- MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

# 3.2.1 Number of parameters to be set

The total number of the parameters of the initial setting and of the auto refresh setting of the L60TC4 must be within the number of parameters which can be set in the CPU module including the number of other intelligent function module parameters.

For the maximum number of parameters which can be set in a CPU module (maximum number of set parameter), refer to the following manual.

- MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

### (1) Number of parameters of the L60TC4


The following table lists the number of parameters that can be set for one L60TC4.

Target module Initial setting		Auto refresh setting	
L60TCTT4		103 (Max.)	
L60TCRT4	43	103 (Max.)	
L60TCTT4BW	43	115 (Max.)	
L60TCRT4BW			

### (2) Checking method

The current number and maximum number of the parameters set in the intelligent function module can be checked by the following operation.

Project window ⇔ [Intelligent Function Module] ⇔ Right-click
⇔ [Intelligent Function Module Parameter List...]



No.	Description		
1)	Total number of the parameters of the initial setting that is checked on the window		
2)	Maximum number of parameters of the initial setting		

No.	Description
3)	Total number of the parameters of the auto refresh setting that is checked on the window
4)	Maximum number of parameters of the auto refresh setting

# **3.2.2** Type of usable temperature sensors, temperature measurement range, resolution, and effect from wiring resistance of 1 ohm

This section describes the types of temperature sensors that can be used with the L60TC4, the temperature measurement range, the resolution, and the effect from wiring resistance of  $1\Omega$ . Set the used temperature sensor in the following buffer memory area.

• CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128) ( Page 345, Appendix 2 (12))

#### (1) L60TCTT4, L60TCTT4BW

The following table lists the types of thermocouples that can be used with the L60TCTT4 and L60TCTT4BW, the temperature measurement range, the resolution, and the effect from wiring resistance of  $1\Omega$ .

		°C			°F	
Thermocouple type	Temperature measurement range	Resolution	Effect from wiring resistance of $1\Omega$ (°C/ $\Omega$ )*1	Temperature measurement range	Resolution	Effect from wiring resistance of $1\Omega$ (°F $I\Omega$ )*1
R	0 to 1700	1	0.030	0 to 3000	1	0.054
	0 to 500 0 to 800 0 to 1300	1		0 to 1000 0 to 2400	1	
К	-200.0 to 1300.0 -200.0 to 400.0 0.0 to 400.0 0.0 to 500.0 0.0 to 800.0	0.1	0.005	0.0 to 1000.0	0.1	0.008
	0 to 500 0 to 800 0 to 1200	1		0 to 1000 0 to 1600 0 to 2100	1	
J	-200.0 to 1000.0 0.0 to 400.0 0.0 to 500.0 0.0 to 800.0	0.1	0.003	0.0 to 1000.0	0.1	0.006
Т	-200 to 400 -200 to 200 0 to 200 0 to 400	1	0.004	0 to 700 -300 to 400	1	0.008
	-200.0 to 400.0 0.0 to 400.0	0.1		0.0 to 700.0	0.1	
S	0 to 1700	1	0.030	0 to 3000	1	0.054
В	0 to 1800 <sup>*2</sup>	1	0.038	0 to 3000 <sup>*2</sup>	1	0.068
E	0 to 400 0 to 1000	1	0.003	0 to 1800	1	0.005
<u> </u>	-200.0 to 1000.0 0.0 to 700.0	0.1	0.003	_	_	_
N	0 to 1300	1	0.006	0 to 2300	1	0.011
	0.0 to 1000.0	0.1	0.000	_	_	_
U	0 to 400 -200 to 200	1	0.004	0 to 700 -300 to 400	1	0.009
	0.0 to 600.0	0.1		_	_	

		°C		°F		
Thermocouple type	Temperature measurement range	Resolution	Effect from wiring resistance of $1\Omega$ (°C/ $\Omega$ )*1	Temperature measurement range	Resolution	Effect from wiring resistance of $1\Omega$ (°F $I\Omega$ )*1
1	0 to 400 0 to 900	1	0.003	0 to 800 0 to 1600	1	0.006
L	0.0 to 400.0 0.0 to 900.0	0.1	0.000	_	_	_
PLII	0 to 1200	1	0.005	0 to 2300	1	0.010
W5Re/W26Re	0 to 2300	1	0.017	0 to 3000	1	0.021

<sup>\*1</sup> Means temperature error per  $\Omega$  of wiring resistance of the thermocouple. The temperature error can be corrected by the sensor compensation function. (Fig. Page 223, Section 8.3.2)

#### (2) L60TCRT4, L60TCRT4BW

The following table lists the types of platinum resistance thermometer that can be used with the L60TCRT4 and L60TCRT4BW and temperature measurement range.

Platinum resistance	°(	С	°F		
thermometer type	Temperature measurement range	Resolution	Temperature measurement range	Resolution	
	-200.0 to 850.0		-300 to 1100	1	
Pt100	-200.0 to 600.0 -200.0 to 200.0	0.1	-300.0 to 300.0	0.1	
	-200.0 to 640.0		-300 to 900	1	
JPt100	-200.0 to 500.0 -200.0 to 200.0	0.1	-300.0 to 300.0	0.1	

<sup>\*2</sup> While temperature can be measured within less than 400°C/800°F, the accuracy cannot be guaranteed.

## 3.2.3 Sampling cycle and control output cycle


This section describes the sampling cycle and control output cycle of the L60TC4.

#### (1) Sampling cycle

The L60TC4 performs PID operations in the order of CH1, CH2, CH3, CH4, CH1, CH2 .....


The time from when PID operation is started on the current channel (CHn) until PID operation is restarted on the current channel (CHn) is called a sampling cycle. Select 250ms or 500ms as a sampling cycle. (FP Page 108, Section 7.2 (1))

The number of used channels and the settings of unused channels do not affect the sampling cycle.



#### (2) Control output cycle

The control output cycle is the ON/OFF cycle of transistor output.



The manipulated value (MV) represents the ON time of the control output cycle in percentage. (FP Page 339, Appendix 2 (5))

Set the control output cycle in the following buffer memory area in the range of 1 to 100s.

• CH $\square$  Control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143) ([ $\bigcirc$  Page 364, Appendix 2 (23)) In the heating-cooling control, the following buffer memory areas are used for the manipulated value (MV) and control output cycle.

Data type	Buffer memory area		Buffer mem	Reference		
Data type	name	CH1	CH2	CH3	CH4	Keierence
Manipulated	Manipulated value for heating (MVh)	Un\G13	Un\G14	Un\G15	Un\G16	Page 339, Appendix 2 (5)
value (MV)	Manipulated value for cooling (MVc)	Un\G704	Un\G705	Un\G706	Un\G707	Page 339, Appendix 2 (3)
Control output	Heating control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	Page 364, Appendix 2 (23)
cycle	Cooling control output cycle setting	Un\G722	Un\G738	Un\G754	Un\G770	Tage 504, Appendix 2 (25)

# 3.3 Function List

# 3.3 Function List

This section lists the L60TC4 functions.

#### (1) When the L60TC4 is used as a temperature input module

Item	Description	Reference
Conversion enable/disable function	Whether to enable or disable the temperature conversion can be set for each channel.	Page 117, Section 8.1.1
Temperature conversion method	The measured temperature by each sampling cycle is stored in the buffer memory.  The temperature process values (PV) can be smoothed and sudden changes can be controlled by using the primary delay filter.	Page 117, Section 8.1.2
Alert output function	An alert is output if the temperature process value (PV) meets the condition set in advance. The alert has process alarm and rate alarm.	Page 120, Section 8.1.3

#### (2) When the L60TC4 is used as a temperature control module

O: Enable, ×: Disable

		Enable o		
Item	Description	Standard control	Heating- cooling control	Reference
Control mode selection function	The control mode can be selected from the following modes.  • Standard control  • Heating-cooling control (normal mode)  • Heating-cooling control (expanded mode)  • Mix control (normal mode)  • Mix control (expanded mode)	0	0	Page 126, Section 8.2.1
Output setting at CPU stop error function	Whether to clear or hold the transistor output status when a CPU stop error occurs or when a CPU module is turned from RUN to STOP can be selected.	0	0	Page 128, Section 8.2.2
Control method	The following control methods can be used with the settings of proportional band (P), integral time (I), and derivative time (D).  • Two-position control  • P control  • PI control  • PD control  • PID control	0	0	Page 129, Section 8.2.3
Manual reset function	The stable status position in the P control or PD control can be moved manually.	0	0	Page 137, Section 8.2.4
Manual control	The manipulated value (MV) can be set manually by users without automatic calculation by the PID control.	0	0	Page 139, Section 8.2.5
Control output cycle unit selection function	The unit for control output cycle can be selected from 1s or 0.1s and switched between them. Setting the control output cycle to 0.1s allows a more detailed control to be performed.	0	0	Page 140, Section 8.2.6
Auto tuning function	The L60TC4 sets the optimal PID constants automatically.	0	0	Page 141, Section 8.2.7
Simple two-degree-of- freedom	In addition to the PID control, the response speed can be selected from three levels. The simple two-degree-of-freedom PID control can be realized.	0	0	Page 153, Section 8.2.8

		Enable o	Enable or disable		
ltem	Description	Standard control	Heating- cooling control	Reference	
Derivative action selection function	Dynamic performance can be improved by selecting the suitable derivative action for the fixed value action and the ramp action.	0	0	Page 154, Section 8.2.9	
Setting change rate limiter setting function	Change rate setting of the set value (SV) per set time unit when this value is changed. The batch setting or individual setting can be selected for the temperature rise and drop.	0	0	Page 155, Section 8.2.10	
Alert function	The modules goes to the alert status when the temperature process value (PV) or deviation (E) meets the condition set in advance.	0	0	Page 157, Section 8.2.11	
RFB limiter function	When the deviation (E) continues for a long time, the PID operation result (manipulated value (MV)) by the integral action can be prevented from exceeding the effective range of the manipulated value (MV).		0	Page 171, Section 8.2.12	
Input/output (with another analog module) function	Data can be input and output using another analog module (A/D conversion module or D/A converter module) on the system.	0	0	Page 172, Section 8.2.13	
ON delay output function	Setting with considering delay time (response/scan time delay) of actual transistor output is possible.	0	0	Page 174, Section 8.2.14	
Self-tuning function	The L60TC4 monitors the control status constantly. If the control system oscillates due to a status soon after the control starts, a change of the set value (SV), and property fluctuation of a controlled object, PID constants are changed automatically.	0	×	Page 175, Section 8.2.15	
Peak current suppression function	Changing automatically the upper limit output limiter value of each channel and dividing the timing of transistor output can suppress the peak current.	0	×	Page 185, Section 8.2.16	
Simultaneous temperature rise function	This function allows several loops to reach the set value (SV) at the same time.	0	×	Page 190, Section 8.2.17	
Forward action/reverse action selection function	Whether to perform PID operations in the forward action or reverse action can be selected.	0	×	Page 203, Section 8.2.18	
Loop disconnection detection function	Errors in the control system (control loop) can be detected.	0	×	Page 204, Section 8.2.19	
Proportional band setting function	The proportional band (P) can be individually set for heating or cooling.	×	0	Page 206, Section 8.2.20	
Cooling method setting function	When the auto tuning is executed, an auto tuning formula is automatically selected according to the selected cooling method and the operation starts.	×	0	Page 207, Section 8.2.21	
Overlap/dead band function	By changing the temperature where the cooling transistor output is started, whether control stability is prioritized or energy saving is prioritized can be selected.	×	0	Page 209, Section 8.2.22	
Temperature conversion function (using unused channels)	In heating-cooling control (normal mode) and mix control (normal mode), only temperature measurement is allowed by using unused temperature input terminals.	×	0	Page 212, Section 8.2.23	
Heater disconnection detection function	The current which flows in the heater main circuit can be measured and disconnections can be detected.	0	0	Page 215, Section 8.2.24	
Output off-time current error detection function	An error of when the transistor output is off can be detected.	0	0	Page 220, Section 8.2.25	

## (3) Common functions

Item	Description	Reference
Temperature process value (PV) scaling function	The temperature process value (PV) can be converted to the set width and this value can be imported into the buffer memory.	Page 221, Section 8.3.1
Sensor compensation function	If a difference between a temperature process value (PV) and an actual temperature occurs due to the measurement status, the error can be corrected. Select a correction method from the following two types.  • 1-point sensor compensation (standard) function: The percentage of the full scale of the set input range can be corrected as an error corrected value.  • 2-point sensor compensation function: An error is corrected by setting any two points (corrected offset value and corrected gain value).	Page 223, Section 8.3.2
Auto-setting at the input range change	When the input range is changed, the related buffer memory data is changed automatically so that errors outside the setting range does not occur.	Page 234, Section 8.3.3
Buffer memory data backup function	The buffer memory data can be stored and backed up in the non-volatile memory.	Page 235, Section 8.3.4
Error history function	Up to 16 errors and alarms that occur on the L60TC4 are stored in the buffer memory as history.	Page 237, Section 8.3.5
Module error history collection function	Error contents can be notified to the CPU module when errors and alarms occur on the L60TC4. Error information is held in the memory inside of the CPU module as module error history.	Page 239, Section 8.3.6
Error clear function	When an error occurs, the error can be cleared on the system monitor.	Page 240, Section 8.3.7

# 3.4 I/O Signal List

This section describes the assignment and applications of the L60TC4 input signals.

#### (1) Input signal list

	Input signal (signal direction: CPU module ← L60TC4)						
Device No.	Temperature input mode	Standard control	Heating-cooling control	Mix control			
Xn0	Module READY flag	Module READY flag	Module READY flag	Module READY flag			
Xn1	Setting/operation mode status	Setting/operation mode status	Setting/operation mode status	Setting/operation mode status			
Xn2	Error occurrence flag	Error occurrence flag	Error occurrence flag	Error occurrence flag			
Xn3	Hardware error flag	Hardware error flag	Hardware error flag	Hardware error flag			
Xn4	N/A	CH1 Auto tuning status	CH1 Auto tuning status	CH1 Auto tuning status			
Xn5	N/A	CH2 Auto tuning status	CH2 Auto tuning status	CH2 Auto tuning status*2			
Xn6	N/A	CH3 Auto tuning status	CH3 Auto tuning status*1	CH3 Auto tuning status			
Xn7	N/A	CH4 Auto tuning status	CH4 Auto tuning status*1	CH4 Auto tuning status			
Xn8	Back-up of the set value completion flag	Back-up of the set value completion flag	Back-up of the set value completion flag	Back-up of the set value completion flag			
Xn9	Default value write completion flag	Default value write completion flag	Default value write completion flag	Default value write completion flag			
XnA	Back-up of the set value fail flag	Back-up of the set value fail flag	Back-up of the set value fail flag	Back-up of the set value fail flag			
XnB	Setting change completion flag	Setting change completion flag	Setting change completion flag	Setting change completion flag			
XnC	CH1 Alert occurrence flag	CH1 Alert occurrence flag	CH1 Alert occurrence flag	CH1 Alert occurrence flag			
XnD	CH2 Alert occurrence flag	CH2 Alert occurrence flag	CH2 Alert occurrence flag	CH2 Alert occurrence flag			
XnE	CH3 Alert occurrence flag	CH3 Alert occurrence flag	CH3 Alert occurrence flag	CH3 Alert occurrence flag			
XnF	CH4 Alert occurrence flag	CH4 Alert occurrence flag	CH4 Alert occurrence flag	CH4 Alert occurrence flag			

<sup>\*1</sup> Available only under the heating-cooling control (expanded mode). For details on the expanded mode, refer to Page 127, Section 8.2.1 (3).

<sup>\*2</sup> Available only under the mix control (expanded mode). For details on the expanded mode, refer to Page 127, Section 8.2.1 (3).

#### (2) Output signal list

	Output signal (signal direction: CPU module $ ightarrow$ L60TC4)						
Device No.	Temperature input mode	Standard control	Heating-cooling control	Mix control			
Yn0	N/A	N/A	N/A	N/A			
Yn1	Setting/operation mode status	Setting/operation mode instruction	Setting/operation mode instruction	Setting/operation mode instruction			
Yn2	Error reset instruction	Error reset instruction	Error reset instruction	Error reset instruction			
Yn3	N/A	N/A	N/A	N/A			
Yn4	N/A	CH1 Auto tuning instruction	CH1 Auto tuning instruction	CH1 Auto tuning instruction			
Yn5	N/A	CH2 Auto tuning instruction	CH2 Auto tuning instruction	CH2 Auto tuning instruction*2			
Yn6	N/A	CH3 Auto tuning instruction	CH3 Auto tuning instruction*1	CH3 Auto tuning instruction			
Yn7	N/A	CH4 Auto tuning instruction	CH4 Auto tuning instruction*1	CH4 Auto tuning instruction			
Yn8	Set value backup instruction	Set value backup instruction	Set value backup instruction	Set value backup instruction			
Yn9	Default setting registration instruction	Default setting registration instruction	Default setting registration instruction	Default setting registration instruction			
YnA	N/A	N/A	N/A	N/A			
YnB	Setting change instruction	Setting change instruction	Setting change instruction	Setting change instruction			
YnC	N/A	CH1 PID control forced stop instruction	CH1 PID control forced stop instruction	CH1 PID control forced stop instruction			
YnD	N/A	CH2 PID control forced stop instruction	CH2 PID control forced stop instruction	CH2 PID control forced stop instruction*2			
YnE	N/A	CH3 PID control forced stop instruction	CH3 PID control forced stop instruction*1	CH3 PID control forced stop instruction			
YnF	N/A	CH4 PID control forced stop instruction	CH4 PID control forced stop instruction*1	CH4 PID control forced stop instruction			

<sup>\*1</sup> Available only under the heating-cooling control (expanded mode). For details on the expanded mode, refer to Page 127, Section 8.2.1 (3).

<sup>\*2</sup> Available only under the mix control (expanded mode). For details on the expanded mode, refer to Page 127, Section 8.2.1 (3).



The functions of the L60TC4 cannot be guaranteed if any of the unavailable areas is turned on/off in a program.

# 3.5 Buffer Memory List



For details on the buffer memory, refer to Page 334, Appendix 2.



Do not write data in the system area or the write-protect area in a program in the buffer memory. Doing so may cause malfunction.

#### (1) Buffer memory address by mode

This section describes the buffer memory assignments by mode.

For details on the modes, refer to Page 116, Section 8.1, Page 126, Section 8.2.1.



Depending on the control mode, some channels cannot be used for control under the temperature control mode.

The channels which cannot be used for control are the following.

- · For heating-cooling control (normal mode): CH3, CH4
- For mix control (normal mode): CH2

The channels which cannot be used for control can be used only for temperature input. For details, refer to Page 212, Section 8.2.23.

#### (a) In the temperature input mode

O: Enable, ×: Disable

Address Setting contents Non-volatile					O. Ellable, A. Disable		
(decimal (hexadecimal))	Target channel	Temperature input mode	Default value <sup>*1</sup>	Read/Write *2	Automatic setting*3	memory write availability*4	Reference
0(0 <sub>H</sub> )	All CHs	Error code	0	R	×	×	Page 334, Appendix 2 (1)
1(1 <sub>H</sub> )	CH1	Decimal point position					
2(2 <sub>H</sub> )	CH2	Decimal point position	0(TT)				Page 334, Appendix 2
3(3 <sub>H</sub> )	CH3	Decimal point position	1(RT) *5	R	×	×	(2)
4(4 <sub>H</sub> )	CH4	Decimal point position					
5(5 <sub>H</sub> )	CH1	Alert definition					
6(6 <sub>H</sub> )	CH2	Alert definition	0	D.			Page 336, Appendix 2
7(7 <sub>H</sub> )	CH3	Alert definition	0	R	×	×	(3)
8(8 <sub>H</sub> )	CH4	Alert definition					
9(9 <sub>H</sub> )	CH1	Temperature process value (PV)					
10(A <sub>H</sub> )	CH2	Temperature process value (PV)	0	R	×	×	Page 338, Appendix 2
11(B <sub>H</sub> )	CH3	Temperature process value (PV)	Ü		^	^	(4)
12(C <sub>H</sub> )	CH4	Temperature process value (PV)					
13(D <sub>H</sub> )							
to	_	System area	_	_	_		_
28(1C <sub>H</sub> )							
29(1D <sub>H</sub> )	All CHs	Cold junction temperature process value*6	0	R	×	×	Page 342, Appendix 2 (9)
30(1E <sub>H</sub> )	All CHs	System area		_	_	_	_
31(1F <sub>H</sub> )	All CHs	System area		_	_	_	_
32(20 <sub>H</sub> )	CH1	Input range*7	2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
33(21 <sub>H</sub> ) to 44(2C <sub>H</sub> )	_	System area	_	_	_	_	_
45(2D <sub>H</sub> )	CH1	Sensor correction value setting	0	R/W	×	0	Page 363, Appendix 2 (21)
46(2E <sub>H</sub> )	_	System area	_	_	_	_	_
47(2F <sub>H</sub> )	_	System area	_	_	_	_	_
48(30 <sub>H</sub> )	CH1	Primary delay digital filter setting	0	R/W	×	0	Page 365, Appendix 2 (24)
49(31 <sub>H</sub> )							
to 63(3F <sub>H</sub> )	_	System area	_	_	_	_	_
64(40 <sub>H</sub> )	CH2	Input range*7	2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
65(41 <sub>H</sub> ) to 76(4C <sub>H</sub> )	_	System area	_	_	_	_	_

Address	Target	Setting contents	Default	Read/Write	Automatic	Non-volatile	
(decimal (hexadecimal))	channel	Temperature input mode	value*1	*2	setting*3	memory write availability*4	Reference
77(4D <sub>H</sub> )	CH2	Sensor correction value setting	0	R/W	×	0	Page 363, Appendix 2 (21)
78(4E <sub>H</sub> )	CH2	System area	_	_	_	_	_
79(4F <sub>H</sub> )	CH2	System area	_	_	_	_	_
80(50 <sub>H</sub> )	CH2	Primary delay digital filter setting	0	R/W	×	0	Page 365, Appendix 2 (24)
81(51 <sub>H</sub> ) to 95(5F <sub>H</sub> )	_	System area			_	_	_
96(60 <sub>H</sub> )	СНЗ	Input range*7	2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
97(61 <sub>H</sub> ) to 108(6C <sub>H</sub> )	_	System area	_	_	_	_	_
109(6D <sub>H</sub> )	CH3	Sensor correction value setting	0	R/W	×	0	Page 363, Appendix 2 (21)
110(6E <sub>H</sub> )	CH3	System area	_	_	_	_	_
111(6F <sub>H</sub> )	CH3	System area	_	_	_	_	_
112(70 <sub>H</sub> )	CH3	Primary delay digital filter setting	0	R/W	×	0	Page 365, Appendix 2 (24)
113(71 <sub>H</sub> ) to 127(7F <sub>H</sub> )	_	System area	_	_	_	_	_
128(80 <sub>H</sub> )	CH4	Input range <sup>*7</sup>	2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
129(81 <sub>H</sub> ) to 140(8C <sub>H</sub> )	_	System area	_	_	_	_	_
141(8D <sub>H</sub> )	CH4	Sensor correction value setting	0	R/W	×	0	Page 363, Appendix 2 (21)
142(8E <sub>H</sub> )	CH4	System area	_	_	_	_	_
143(8F <sub>H</sub> )	CH4	System area	_	_	_	_	
144(90 <sub>H</sub> )	CH4	Primary delay digital filter setting	0	R/W	×	0	Page 365, Appendix 2 (24)
145(91 <sub>H</sub> ) to 181(B5 <sub>H</sub> )	_	System area	_	_	_	_	_
182(B6 <sub>H</sub> )	All	Cold junction temperature compensation selection*6	0	R/W	×	0	Page 384, Appendix 2 (49)
183(B7 <sub>H</sub> )	All	Control switching monitor	0	R	×	×	Page 385, Appendix 2 (50)
184(B8 <sub>H</sub> ) to 195(C3 <sub>H</sub> )	_	System area	_	_	_	_	_
196(C4 <sub>H</sub> )	CH1	Process alarm alert output enable/disable setting*7	1	R/W	×	0	Page 387, Appendix 2 (53)

Address	Townst	Setting contents	Default	<b>5</b> 1047 17	Automatic	Non-volatile	
(decimal (hexadecimal))	Target channel	Temperature input mode	value <sup>*1</sup>	Read/Write *2	setting*3	memory write availability*4	Reference
197(C5 <sub>H</sub> )	CH1	Process alarm lower lower limit value*7	0(TT) -2000(RT) *5	R/W	0	0	
198(C6 <sub>H</sub> )	CH1	Process alarm lower upper limit value*7	0(TT) -2000(RT) *5	R/W	0	0	Page 388, Appendix 2
199(C7 <sub>H</sub> )	CH1	Process alarm upper lower limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	(54)
200(C8 <sub>H</sub> )	CH1	Process alarm upper upper limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	
201(C9 <sub>H</sub> )	CH1	Rate alarm alert output enable/disable setting*7	1	R/W	×	0	Page 389, Appendix 2 (55)
202(CA <sub>H</sub> )	CH1	Rate alarm alert detection cycle*7	1	R/W	×	0	Page 389, Appendix 2 (56)
203(CB <sub>H</sub> )	CH1	Rate alarm upper limit value*7	0	R/W	×	0	Page 390, Appendix 2
204(CC <sub>H</sub> )	CH1	Rate alarm lower limit value*7	0	R/W	×	0	(57)
205(CD <sub>H</sub> ) to 211(D3 <sub>H</sub> )	_	System area	_	_		1	_
212(D4 <sub>H</sub> )	CH2	Process alarm alert output enable/disable setting* <sup>7</sup>	1	R/W	×	0	Page 387, Appendix 2 (53)
213(D5 <sub>H</sub> )	CH2	Process alarm lower lower limit value*7	0(TT) -2000(RT) *5	R/W	0	0	
214(D6 <sub>H</sub> )	CH2	Process alarm lower upper limit value <sup>*7</sup>	0(TT) -2000(RT) *5	R/W	0	0	Page 388, Appendix 2
215(D7 <sub>H</sub> )	CH2	Process alarm upper lower limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	(54)
216(D8 <sub>H</sub> )	CH2	Process alarm upper upper limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	
217(D9 <sub>H</sub> )	CH2	Rate alarm alert output enable/disable setting*7	1	R/W	×	0	Page 389, Appendix 2 (55)
218(DA <sub>H</sub> )	CH2	Rate alarm alert detection cycle*7	1	R/W	×	0	Page 389, Appendix 2 (56)
219(DB <sub>H</sub> )	CH2	Rate alarm upper limit value*7	0	R/W	×	0	Page 390, Appendix 2
220(DC <sub>H</sub> )	CH2	Rate alarm lower limit value*7	0	R/W	×	0	(57)
221(DD <sub>H</sub> ) to 227(E3 <sub>H</sub> )	_	System area	_	_	_	-	_
228(E4 <sub>H</sub> )	CH3	Process alarm alert output enable/disable setting*7	1	R/W	×	0	Page 387, Appendix 2 (53)

Address	Toward	Setting contents	Default	Read/Write	Automatic	Non-volatile	
(decimal (hexadecimal))	Target channel	Temperature input mode	value*1	*2	setting*3	memory write availability*4	Reference
229(E5 <sub>H</sub> )	СНЗ	Process alarm lower lower limit value <sup>*7</sup>	0(TT) -2000(RT) *5	R/W	0	0	
230(E6 <sub>H</sub> )	СНЗ	Process alarm lower upper limit value <sup>*7</sup>	0(TT) -2000(RT) *5	R/W	0	0	Page 388, Appendix 2
231(E7 <sub>H</sub> )	СНЗ	Process alarm upper lower limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	(54)
232(E8 <sub>H</sub> )	СНЗ	Process alarm upper upper limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	
233(E9 <sub>H</sub> )	CH3	Rate alarm alert output enable/disable setting*7	1	R/W	×	0	Page 389, Appendix 2 (55)
234(EA <sub>H</sub> )	CH3	Rate alarm alert detection cycle*7	ate alarm alert detection		×	0	Page 389, Appendix 2 (56)
235(EB <sub>H</sub> )	CH3	Rate alarm upper limit value*7	0	R/W	×	0	Page 390, Appendix 2
236(EC <sub>H</sub> )	CH3	Rate alarm lower limit value*7	0	R/W	×	0	(57)
237(ED <sub>H</sub> ) to 243(F3 <sub>H</sub> )	_	System area	_	_	_	_	_
244(F4 <sub>H</sub> )	CH4	Process alarm alert output enable/disable setting*7	1	R/W	×	0	Page 387, Appendix 2 (53)
245(F5 <sub>H</sub> )	CH4	Process alarm lower lower limit value*7	0(TT) -2000(RT) *5	R/W	0	0	
246(F6 <sub>H</sub> )	CH4	Process alarm lower upper limit value <sup>*7</sup>	0(TT) -2000(RT) *5	R/W	0	0	Page 388, Appendix 2
247(F7 <sub>H</sub> )	CH4	Process alarm upper lower limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	(54)
248(F8 <sub>H</sub> )	CH4	Process alarm upper upper limit value <sup>*7</sup>	1300(TT) 6000(RT) *5	R/W	0	0	
249(F9 <sub>H</sub> )	CH4	Rate alarm alert output enable/disable setting*7	1	R/W	×	0	Page 389, Appendix 2 (55)
250(FA <sub>H</sub> )	CH4	Rate alarm alert detection cycle*7	1	R/W	×	0	Page 389, Appendix 2 (56)
251(FB <sub>H</sub> )	CH4	Rate alarm upper limit value*7	0	R/W	×	0	Page 390, Appendix 2
252(FC <sub>H</sub> )	CH4	Rate alarm lower limit value*7	0	R/W	×	0	(57)
253(FD <sub>H</sub> ) to 543(21F <sub>H</sub> )	_	System area	_	_	_	_	_
544(220 <sub>H</sub> )	CH1	2-point sensor compensation offset value (measured value)*7	0	R/W	0	0	Page 394, Appendix 2 (63)
545(221 <sub>H</sub> )	CH1	2-point sensor compensation offset value(compensation value)*7	0	R/W	0	0	Page 394, Appendix 2 (64)
546(222 <sub>H</sub> )	CH1	2-point sensor compensation gain value (measured value)*7	0	R/W	0	0	Page 395, Appendix 2 (65)

Address	Target	Setting contents	Default	Read/Write	Automatic	Non-volatile	
(decimal (hexadecimal))	channel	Temperature input mode	value*1	*2	setting*3	memory write availability*4	Reference
547(223 <sub>H</sub> )	CH1	2-point sensor compensation gain value (compensation value) <sup>*7</sup>	0	R/W	0	0	Page 395, Appendix 2 (66)
548(224 <sub>H</sub> )	CH1	2-point sensor compensation offset latch request*7	0	R/W	×	×	Page 396, Appendix 2 (67)
549(225 <sub>H</sub> )	CH1	2-point sensor compensation offset latch completion	0	R	×	×	Page 396, Appendix 2 (68)
550(226 <sub>H</sub> )	CH1	2-point sensor compensation gain latch request*7	0	R/W	×	×	Page 397, Appendix 2 (69)
551(227 <sub>H</sub> )	CH1	2-point sensor compensation gain latch completion	0	R	×	×	Page 397, Appendix 2 (70)
552(228 <sub>H</sub> ) to 575(23F <sub>H</sub> )	_	System area	_	_	_	_	_
576(240 <sub>H</sub> )	CH2	2-point sensor compensation (measured value)*7	0	R/W	0	0	Page 394, Appendix 2 (63)
577(241 <sub>H</sub> )	CH2	2-point sensor compensation offset value (compensation value)*7	0	R/W	0	0	Page 394, Appendix 2 (64)
578(242 <sub>H</sub> )	CH2	2-point sensor compensation gain value (measured value)*7	0	R/W	0	0	Page 395, Appendix 2 (65)
579(243 <sub>H</sub> )	CH2	2-point sensor compensation (compensation value)*7	0	R/W	0	0	Page 395, Appendix 2 (66)
580(244 <sub>H</sub> )	CH2	2-point sensor compensation offset latch request*7	0	R/W	×	×	Page 396, Appendix 2 (67)
581(245 <sub>H</sub> )	CH2	2-point sensor compensation offset latch completion	0	R	×	×	Page 396, Appendix 2 (68)
582(246 <sub>H</sub> )	CH2	2-point sensor compensation gain latch request*7	0	R/W	×	×	Page 397, Appendix 2 (69)
583(247 <sub>H</sub> )	CH2	2-point sensor compensation gain latch completion	0	R	×	×	Page 397, Appendix 2 (70)
584(248 <sub>H</sub> ) to 607(25F <sub>H</sub> )	_	System area	_	_	_	_	_
608(260 <sub>H</sub> )	СН3	2-point sensor compensation offset value (measured value)*7	0	R/W	0	0	Page 394, Appendix 2 (63)
609(261 <sub>H</sub> )	СНЗ	2-point sensor compensation offset value (compensation value)*7	0	R/W	0	0	Page 394, Appendix 2 (64)
610(262 <sub>H</sub> )	CH3	2-point sensor compensation gain value (measured value)*7	0	R/W	0	0	Page 395, Appendix 2 (65)
611(263 <sub>H</sub> )	CH3	2-point sensor compensation gain value (compensation value)*7	0	R/W	0	0	Page 395, Appendix 2 (66)
612(264 <sub>H</sub> )	CH3	2-point sensor compensation offset latch request*7	0	R/W	×	×	Page 396, Appendix 2 (67)
613(265 <sub>H</sub> )	CH3	2-point sensor compensation offset latch completion	0	R	×	×	Page 396, Appendix 2 (68)
614(266 <sub>H</sub> )	CH3	2-point sensor compensation gain latch request*7	0	R/W	×	×	Page 397, Appendix 2 (69)
615(267 <sub>H</sub> )	CH3	2-point sensor compensation gain latch completion	0	R	×	×	Page 397, Appendix 2 (70)

Address	Target	Setting contents	Default	Read/Write	Automatic	Non-volatile		
(decimal (hexadecimal))	channel	Temperature input mode	value*1	*2	setting*3	memory write availability*4	Reference	
616(268 <sub>H</sub> )						-		
to 639(27F <sub>H</sub> )	_	System area	_	_	_		_	
640(280 <sub>H</sub> )	CH4	2-point sensor compensation offset value (measured value)*7	0	R/W	0	0	Page 394, Appendix 2 (63)	
641(281 <sub>H</sub> )	CH4	2-point sensor compensation offset value (compensation value)*7	0	R/W	0	0	Page 394, Appendix 2 (64)	
642(282 <sub>H</sub> )	CH4	2-point sensor compensation gain value (measured value)*7	0	R/W	0	0	Page 395, Appendix 2 (65)	
643(283 <sub>H</sub> )	CH4	2-point sensor compensation gain value (compensation value)*7	0	R/W	0	0	Page 395, Appendix 2 (66)	
644(284 <sub>H</sub> )	CH4	2-point sensor compensation offset latch request*7	0	R/W	×	×	Page 396, Appendix 2 (67)	
645(285 <sub>H</sub> )	CH4	2-point sensor compensation offset latch completion	0	R	×	×	Page 396, Appendix 2 (68)	
646(286 <sub>H</sub> )	CH4	2-point sensor compensation gain latch request*7	0	R/W	×	×	Page 397, Appendix 2 (69)	
647(287 <sub>H</sub> )	CH4	2-point sensor compensation gain latch completion	0	R	×	×	Page 397, Appendix 2 (70)	
648(288 <sub>H</sub> ) to 692(2B4 <sub>H</sub> )	_	System area	_	_	_	_	_	
693(2B5 <sub>H</sub> )	All CHs	Conversion enable/disable setting*7	000Fн	R/W	×	0	Page 402, Appendix 2 (75)	
694(2B6 <sub>H</sub> ) to 724(2D4 <sub>H</sub> )	_	System area	_	_	_	_	_	
725(2D5 <sub>H</sub> )	CH1	Process value (PV) scaling function enable/disable setting <sup>*7</sup>	0	R/W	×	0	Page 405, Appendix 2 (80)	
726(2D6 <sub>H</sub> )	CH1	Process value (PV) scaling lower limit value*7	0	R/W	×	0	Page 406, Appendix 2	
727(2D7 <sub>H</sub> )	CH1	Process value (PV) scaling upper limit value*7	0	R/W	×	0	(81)	
728(2D8 <sub>H</sub> )	CH1	Process value (PV) scaling value	0	R	×	×	Page 406, Appendix 2 (82)	
729(2D9 <sub>H</sub> ) to 740(2E4 <sub>H</sub> )	_	System area	_	_	_	_	_	
741(2E5 <sub>H</sub> )	CH2	Process value (PV) scaling function enable/disable setting *7	0	R/W	×	0	Page 405, Appendix 2 (80)	
742(2E6 <sub>H</sub> )	CH2	Process value (PV) scaling lower limit value*7	0	R/W	×	0	Page 406, Appendix 2	
743(2E7 <sub>H</sub> )	CH2	Process value (PV) scaling upper limit value*7	0	R/W	×	0	(81)	
744(2E8 <sub>H</sub> )	CH2	Process value (PV) scaling value	0	R	×	×	Page 406, Appendix 2 (82)	

Address (decimal	Target	Setting contents	Default	Read/Write	Automatic	Non-volatile		
(decimal (hexadecimal))	channel	Temperature input mode	value*1	*2	setting*3	memory write availability*4	Reference	
745(2E9 <sub>H</sub> )								
to	_	System area	_	_	_	_	_	
756(2F4 <sub>H</sub> )								
757(2F5 <sub>H</sub> )	СНЗ	Process value (PV) scaling function enable/disable setting *7	0	R/W	×	0	Page 405, Appendix 2 (80)	
758(2F6 <sub>H</sub> )	CH3	Process value (PV) scaling lower limit value *7	0	R/W	×	0	Page 406, Appendix 2	
759(2F7 <sub>H</sub> )	СН3	Process value (PV) scaling upper limit value*7	0	R/W	×	0	(81)	
760(2F8 <sub>H</sub> )	CH3	Process value (PV) scaling value	0	R	×	×	Page 406, Appendix 2 (82)	
761(2F9 <sub>H</sub> )								
to	_	System area	_	_	_	_	_	
772(304 <sub>H</sub> )								
773(305 <sub>H</sub> )	CH4	Process value (PV) scaling function enable/disable setting *7	0	R/W	×	0	Page 405, Appendix 2 (80)	
774(306 <sub>H</sub> )	CH4	Process value (PV) scaling lower limit value*7	0	R/W	×	0	Page 406, Appendix 2	
775(307 <sub>H</sub> )	CH4	Process value (PV) scaling upper limit value*7	0	R/W	×	0	(81)	
776(308 <sub>H</sub> )	CH4	Process value (PV) scaling value	0	R	×	×	Page 406, Appendix 2 (82)	
777(309 <sub>H</sub> )								
to	_	System area	_	_	_	_	_	
784(310 <sub>H</sub> )								
785(311 <sub>H</sub> )	All CHs	Sensor compensation function selection*7	0	R/W	×	0	Page 413, Appendix 2 (91)	
786(312 <sub>H</sub> )	All CHs	Temperature conversion completion flag	0	R	×	×	Page 413, Appendix 2 (92)	
787(313 <sub>H</sub> )	All CHs	Function extension bit monitor	0	R	×	×	Page 414, Appendix 2 (93)	
788(314 <sub>H</sub> )	All CHs	Sampling cycle monitor	0	R	×	×	Page 414, Appendix 2 (94)	
789(315 <sub>H</sub> )								
to	_	System area	_	_	_	_	_	
1278(4FE <sub>H</sub> )								
1279(4FF <sub>H</sub> )								
to 4095(FFF <sub>H</sub> )		Buffer mem	ory areas for	error history (	ਤੋਂ Page 76, Se	ection 3.5 (2))		
4096(1000 <sub>H</sub> )								
to	_	System area	_	_	_	_	_	

- \*1 This default value is set after the module is turned off and on or after the CPU module is reset and the reset is cancelled.
- \*2 This column indicates whether data can be read from or written to the buffer memory area through sequence programs. R: Reading enabled
  - W: Writing enabled
- \*3 This column indicates whether the setting in the buffer memory area is automatically changed when the input range is changed. Enable/disable of automatic change can be set on Switch Setting. For details, refer to Page 234, Section 8.3.3.
- \*4 Whether writing to the non-volatile memory by turning off and on Set value backup instruction (Yn8) is enabled in this column. For details, refer to Page 235, Section 8.3.4.
- \*5 (TT) indicates the L60TCTT4 and L60TCTT4BW. (RT) indicates the L60TCRT4 and L60TCRT4BW.
- \*6 Available only when the L60TCTT4 or L60TCTT4BW is used. With other models, this area is handled as a system area.
- \*7 Available only in the setting mode. To enable the setting contents, turn off, on, and off Setting change instruction (YnB) when Setting/operation mode instruction (Yn1) is off (during setting mode). Note that a write data error (error code: \( \subset \subset \subset \subset \) occurs if the setting is changed during the operation mode.

#### (b) In the temperature control mode

O: Enable, ×: Disable

	Target	9	Setting content	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
0(0 <sub>H</sub> )	All CHs	Error code			0	R	×	×	Page 334, Appendix 2 (1)
1(1 <sub>H</sub> )	CH1	Decimal point pos	sition						
2(2 <sub>H</sub> )	CH2	Decimal point pos	sition		0(TT)	_		×	Page 334,
3(3 <sub>H</sub> )	CH3	Decimal point pos	sition		1(RT) *5	R	×	×	Appendix 2 (2)
4(4 <sub>H</sub> )	CH4	Decimal point pos	sition		1				
5(5 <sub>H</sub> )	CH1	Alert definition							
6(6 <sub>H</sub> )	CH2	Alert definition			1	1			Page 336,
7(7 <sub>H</sub> )	CH3	Alert definition			0 R	R	×	×	Appendix 2 (3)
8(8 <sub>H</sub> )	CH4	Alert definition							(0)
9(9 <sub>H</sub> )	CH1	Temperature prod	cess value (PV)						
10(A <sub>H</sub> )	CH2	Temperature prod	cess value (PV)		1 _	_	×	×	Page 338, Appendix 2 (4)
11(B <sub>H</sub> )	CH3	Temperature prod	cess value (PV)		0	R		×	
12(C <sub>H</sub> )	CH4	Temperature prod	cess value (PV)		1				,
13(D <sub>H</sub> )	CH1	Manipulated value (MV)	Manipulated value for heating (MVh)	Manipulated value for heating (MVh)				×	
14(E <sub>H</sub> )	CH2	Manipulated value (MV)	Manipulated value for heating (MVh)	Manipulated value for heating (MVh)*7					Page 339,
15(F <sub>H</sub> )	CH3	Manipulated value (MV)	Manipulated value for heating (MVh)*6	Manipulated value (MV)	0	R	×		Appendix 2 (5)
16(10 <sub>H</sub> )	CH4	Manipulated value (MV)	Manipulated value for heating (MVh)*6	Manipulated value (MV)					
17(11 <sub>H</sub> )	CH1	Temperature rise judgment flag	Temperature rise judgment flag	Temperature rise judgment flag					
18(12 <sub>H</sub> )	CH2	Temperature rise judgment flag	Temperature rise judgment flag	Temperature rise judgment flag*7					Page 340
19(13 <sub>H</sub> )	СНЗ	Temperature rise judgment flag	Temperature rise judgment flag *6	Temperature rise judgment flag	0	R	×	×	Page 340, Appendix 2 (6)
20(14 <sub>H</sub> )	CH4	Temperature rise judgment flag	Temperature rise judgment flag	Temperature rise judgment flag					

	Target	S	etting content	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
21(15 <sub>H</sub> )	CH1	Transistor output flag	Heating transistor output flag	Heating transistor output flag					
22(16 <sub>H</sub> )	CH2	Transistor output flag	Heating transistor output flag	Heating transistor output flag*7					Page 341,
23(17 <sub>H</sub> )	СНЗ	Transistor output flag	Heating transistor output flag*6	Transistor output flag	0	R	×	×	Appendix 2 (7)
24(18 <sub>H</sub> )	CH4	Transistor output flag	Heating transistor output flag*6	Transistor output flag					
25(19 <sub>H</sub> )	CH1	Set value (SV) me	onitor						
26(1A <sub>H</sub> )	CH2	Set value (SV) monitor	Set value (SV) monitor	Set value (SV) monitor*7		_			Page 342,
27(1B <sub>H</sub> )	CH3	Set value (SV) monitor	Set value (SV) monitor*6	Set value (SV) monitor		R	×	×	Appendix 2 (8)
28(1C <sub>H</sub> )	CH4	Set value (SV) monitor	Set value (SV) monitor*6	Set value (SV) monitor					
29(1D <sub>H</sub> )	All CHs	Cold junction tem	perature process	value <sup>*8</sup>	0	R	×	×	Page 342, Appendix 2 (9)
30(1E <sub>H</sub> )	All CHs	MAN mode shift of	completion flag		0	R	×	×	Page 342, Appendix 2 (10)
31(1F <sub>H</sub> )	All CHs	Memory of PID co	onstants read/Writ	e completion flag	0	R	×	×	Page 343, Appendix 2 (11)
32(20 <sub>H</sub> )	CH1	Input range*9			2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
33(21 <sub>H</sub> )	CH1	Stop mode setting	9		1	R/W	×	0	Page 353, Appendix 2 (13)
34(22 <sub>H</sub> )	CH1	Set value (SV) se	etting		0	R/W	0	0	Page 354, Appendix 2 (14)
35(23 <sub>H</sub> )	CH1	Proportional band (P) setting	Heating proportional band (Ph) setting	Heating proportional band (Ph) setting	30	R/W	×	0	Page 355, Appendix 2 (15)
36(24 <sub>H</sub> )	CH1	Integral time (I) se	etting				×	0	Page 357, Appendix 2 (16)
37(25 <sub>H</sub> )	CH1	Derivative time (D	)) setting	60	R/W	×	0	Page 357, Appendix 2 (17)	
38(26 <sub>H</sub> )	CH1	Alert set value 1		0	R/W	0	0		
39(27 <sub>H</sub> )	CH1	Alert set value 2			0	R/W	0	0	Page 358, Appendix 2
40(28 <sub>H</sub> )	CH1	Alert set value 3			0	R/W	0	0	(18)
41(29 <sub>H</sub> )	CH1	Alert set value 4			0	R/W	0	0	

	Target	S	etting content	s				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
42(2A <sub>H</sub> )	CH1	Upper limit output limiter	Heating upper limit output limiter	Heating upper limit output limiter	1000	R/W	×	0	Page 360, Appendix 2
43(2B <sub>H</sub> )	CH1	Lower limit output limiter	System area	System area	0	R/W	×	0	(19)
44(2C <sub>H</sub> )	CH1	Output variation li	out variation limiter setting			R/W	×	0	Page 362, Appendix 2 (20)
45(2D <sub>H</sub> )	CH1	Sensor correction	Sensor correction value setting				×	0	Page 363, Appendix 2 (21)
46(2E <sub>H</sub> )	CH1	Adjustment sensit	Adjustment sensitivity (dead band) setting			R/W	×	0	Page 363, Appendix 2 (22)
47(2F <sub>H</sub> )	CH1	Control output cycle setting	Heating control output cycle setting	Heating control output cycle setting	30/300	R/W	×	0	Page 364, Appendix 2 (23)
48(30 <sub>H</sub> )	CH1	Primary delay dig	ital filter setting		0	R/W	×	0	Page 365, Appendix 2 (24)
49(31 <sub>H</sub> )	CH1	Control response	0	R/W	×	0	Page 366, Appendix 2 (25)		
50(32 <sub>H</sub> )	CH1	AUTO/MAN mode	AUTO/MAN mode shift				×	0	Page 367, Appendix 2 (26)
51(33 <sub>H</sub> )	CH1	MAN output settir	ng		0	R/W	×	0	Page 368, Appendix 2 (27)
52(34 <sub>H</sub> )	CH1	Setting change ra	=	change rate	0	R/W	×	0	Page 369, Appendix 2 (28)
53(35 <sub>H</sub> )	CH1	AT bias			0	R/W	0	0	Page 370, Appendix 2 (29)
54(36 <sub>H</sub> )	CH1	Forward/reverse action setting	System area	System area	1	R/W	×	0	Page 371, Appendix 2 (30)
55(37 <sub>H</sub> )	CH1	Upper limit setting	g limiter		1300 (TT) 6000 (RT) *5	R/W	0	0	Page 372, Appendix 2
56(38 <sub>H</sub> )	CH1	Lower limit setting	0(TT) -2000 (RT) *5	R/W	0	0	(31)		
57(39 <sub>H</sub> )	CH1	System area	area			_	_		
58(3A <sub>H</sub> )	CH1	Heater disconnec	disconnection alert setting*11			R/W	×	0	Page 373, Appendix 2 (32)
59(3B <sub>H</sub> )	CH1	Loop disconnection detection judgment time	System area	System area	480	R/W	×	0	Page 374, Appendix 2 (33)

	Target	S	etting contents	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
60(3C <sub>H</sub> )	CH1	Loop disconnection detection dead band	System area	System area	0	R/W	0	0	Page 375, Appendix 2 (34)
61(3D <sub>H</sub> )	CH1	Unused channel s	setting		0	R/W	×	0	Page 376, Appendix 2 (35)
62(3E <sub>H</sub> )	CH1	Memory of PID co	mory of PID constants read instruction			R/W	×	×	Page 377, Appendix 2 (36)
63(3F <sub>H</sub> )	CH1	Automatic backup	tomatic backup setting after auto tuning of PID nstants			R/W	×	×	Page 378, Appendix 2 (37)
64(40 <sub>H</sub> )	CH2	Input range*9			2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
65(41 <sub>H</sub> )	CH2	Stop mode setting	Stop mode setting	Stop mode setting*7	1	R/W	×	0	Page 353, Appendix 2 (13)
66(42 <sub>H</sub> )	CH2	Set value (SV) setting	Set value (SV) setting	Set value (SV) setting*7	0	R/W	0	0	Page 354, Appendix 2 (14)
67(43 <sub>H</sub> )	CH2	Proportional band (P) setting	Heating proportional band (Ph) setting	Heating proportional band (Ph) setting*7	30	R/W	×	0	Page 355, Appendix 2 (15)
68(44 <sub>H</sub> )	CH2	Integral time (I) setting	Integral time (I) setting	Integral time (I) setting*7	240	R/W	×	0	Page 357, Appendix 2 (16)
69(45 <sub>H</sub> )	CH2	Derivative time (D) setting	Derivative time (D) setting	Derivative time (D) setting*7	60	R/W	×	0	Page 357, Appendix 2 (17)
70(46 <sub>H</sub> )	CH2	Alert set value 1	Alert set value	Alert set value 1*7	0	R/W	0	0	
71(47 <sub>H</sub> )	CH2	Alert set value 2	Alert set value 2	Alert set value $2^{*7}$	0	R/W	0	0	Page 358,
72(48 <sub>H</sub> )	CH2	Alert set value 3	Alert set value 3	Alert set value 3*7	0	R/W	0	0	Appendix 2 (18)
73(49 <sub>H</sub> )	CH2	Alert set value 4	Alert set value 4	Alert set value 4*7	0	R/W	0	0	
74(4A <sub>H</sub> )	CH2	Upper limit output limiter	Heating upper limit output limiter	Heating upper limit output limiter*7	1000	R/W	×	0	Page 360, Appendix 2
75(4B <sub>H</sub> )	CH2	Lower limit output limiter	System area	System area	0	R/W	×	0	(19)
76(4C <sub>H</sub> )	CH2	Output variation limiter setting	Output variation limiter setting	Output variation limiter setting*7	0	R/W	×	0	Page 362, Appendix 2 (20)
77(4D <sub>H</sub> )	CH2	Sensor correction	value setting		0	R/W	×	0	Page 363, Appendix 2 (21)
78(4E <sub>H</sub> )	CH2	Adjustment sensitivity (dead band) setting	Adjustment sensitivity (dead band) setting	Adjustment sensitivity (dead band) setting*7	5	R/W	×	0	Page 363, Appendix 2 (22)

	Target	S	etting contents	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
79(4F <sub>H</sub> )	CH2	Control output cycle setting	Heating control output cycle setting	Heating control output cycle setting*7	30/300	R/W	×	0	Page 364, Appendix 2 (23)
80(50 <sub>H</sub> )	CH2	Primary delay dig	ital filter setting		0	R/W	×	0	Page 365, Appendix 2 (24)
81(51 <sub>H</sub> )	CH2	Control response parameters	Control response parameters	Control response parameters*7	0	R/W	×	0	Page 366, Appendix 2 (25)
82(52 <sub>H</sub> )	CH2	AUTO/MAN mode shift	AUTO/MAN mode shift	AUTO/MAN mode shift *7	0	R/W	×	0	Page 367, Appendix 2 (26)
83(53 <sub>H</sub> )	CH2	MAN output setting	MAN output setting	MAN output setting	0	R/W	×	0	Page 368, Appendix 2 (27)
84(54 <sub>H</sub> )	CH2	Setting change ra limiter (temperatu *10	•	change rate	0	R/W	×	0	Page 369, Appendix 2 (28)
85(55 <sub>H</sub> )	CH2	AT bias	AT bias	AT bias*7	0	R/W	0	0	Page 370, Appendix 2 (29)
86(56 <sub>H</sub> )	CH2	Forward/reverse action setting	System area	System area	1	R/W	×	0	Page 371, Appendix 2 (30)
87(57 <sub>H</sub> )	CH2	Upper limit setting limiter	Upper limit setting limiter	Upper limit setting limiter*7	1300 (TT) 6000 (RT) *5	R/W	0	0	Page 372,
88(58 <sub>H</sub> )	CH2	Lower limit setting limiter	Lower limit setting limiter	Lower limit setting limiter*7	0 (TT) -2000 (RT) *5	R/W	0	0	Appendix 2 (31)
89(59 <sub>H</sub> )	CH2	System area			_	_	_	_	_
90(5A <sub>H</sub> )	CH2	Heater disconnection alert setting*11	Heater disconnection alert setting*11	Heater disconnection alert setting*7*11	0	R/W	×	0	Page 373, Appendix 2 (32)
91(5B <sub>H</sub> )	CH2	Loop disconnection detection judgment time	System area	System area	480	R/W	×	0	Page 374, Appendix 2 (33)
92(5C <sub>H</sub> )	CH2	Loop disconnection detection dead band	System area	System area	0	R/W	0	0	Page 375, Appendix 2 (34)
93(5D <sub>H</sub> )	CH2	Unused channel setting	Unused channel setting	Unused channel setting*7	0	R/W	×	0	Page 376, Appendix 2 (35)
94(5E <sub>H</sub> )	CH2	Memory of PID constants read instruction	Memory of PID constants read instruction	Memory of PID constants read instruction*7	0	R/W	×	×	Page 377, Appendix 2 (36)

	Target	S	etting contents	3				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
95(5F <sub>H</sub> )	CH2	Automatic backup setting after auto tuning of PID constants	Automatic backup setting after auto tuning of PID constants	Automatic backup setting after auto tuning of PID constants*7	0	R/W	×	×	Page 378, Appendix 2 (37)
96(60 <sub>H</sub> )	СНЗ	Input range*9			2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)
97(61 <sub>H</sub> )	CH3	Stop mode setting	Stop mode setting	Stop mode setting	1	R/W	×	0	Page 353, Appendix 2 (13)
98(62 <sub>H</sub> )	CH3	Set value (SV) setting	Set value (SV) setting*6	Set value (SV) setting	0	R/W	0	0	Page 354, Appendix 2 (14)
99(63 <sub>H</sub> )	СНЗ	Proportional band (P) setting	Heating proportional band (Ph) setting*6	Proportional band (P) setting	30	R/W	×	0	Page 355, Appendix 2 (15)
100(64 <sub>H</sub> )	СНЗ	Integral time (I) setting	Integral time (I) setting*6	Integral time (I) setting	240	R/W	×	0	Page 357, Appendix 2 (16)
101(65 <sub>H</sub> )	СНЗ	Derivative time (D) setting	Derivative time (D) setting*6	Derivative time (D) setting	60	R/W	×	0	Page 357, Appendix 2 (17)
102(66 <sub>H</sub> )	CH3	Alert set value 1	Alert set value 1*6	Alert set value	0	R/W	0	0	
103(67 <sub>H</sub> )	CH3	Alert set value 2	Alert set value 2*6	Alert set value 2	0	R/W	0	0	Page 358,
104(68 <sub>H</sub> )	CH3	Alert set value 3	Alert set value 3*6	Alert set value 3	0	R/W	0	0	Appendix 2 (18)
105(69 <sub>H</sub> )	СНЗ	Alert set value 4	Alert set value 4*6	Alert set value	0	R/W	0	0	
106(6A <sub>H</sub> )	СНЗ	Upper limit output limiter	Heating upper limit output limiter*6	Upper limit output limiter	1000	R/W	×	0	Page 360, Appendix 2
107(6B <sub>H</sub> )	CH3	Lower limit output limiter	System area	Lower limit output limiter	0	R/W	×	0	(19)
108(6C <sub>H</sub> )	СНЗ	Output variation limiter setting	Output variation limiter setting*6	Output variation limiter setting	0	R/W	×	0	Page 362, Appendix 2 (20)
109(6D <sub>H</sub> )	СНЗ	Sensor correction	value setting		0	R/W	×	0	Page 363, Appendix 2 (21)
110(6E <sub>H</sub> )	СНЗ	Adjustment sensitivity (dead band) setting	Adjustment sensitivity (dead band) setting*6	Adjustment sensitivity (dead band) setting	5	R/W	×	0	Page 363, Appendix 2 (22)
111(6F <sub>H</sub> )	СНЗ	Control output cycle setting	Heating control output cycle setting*6	Control output cycle setting	30/300	R/W	×	0	Page 364, Appendix 2 (23)
112(70 <sub>H</sub> )	СНЗ	Primary delay dig	ital filter setting		0	R/W	×	0	Page 365, Appendix 2 (24)

	Target	S	etting contents	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
113(71 <sub>H</sub> )	СНЗ	Control response parameters	Control response parameters*6	Control response parameters	0	R/W	×	0	Page 366, Appendix 2 (25)
114(72 <sub>H</sub> )	СНЗ	AUTO/MAN mode shift	AUTO/MAN mode shift*6	AUTO/MAN mode shift	0	R/W	×	0	Page 367, Appendix 2 (26)
115(73 <sub>H</sub> )	СНЗ	MAN output setting	MAN output setting*6	MAN output setting	0	R/W	×	0	Page 368, Appendix 2 (27)
116(74 <sub>H</sub> )	CH3	Setting change ra	_	change rate	0	R/W	×	0	Page 369, Appendix 2 (28)
117(75 <sub>H</sub> )	СНЗ	AT bias	AT bias <sup>*6</sup>	AT bias	0	R/W	0	0	Page 370, Appendix 2 (29)
118(76 <sub>H</sub> )	СНЗ	Forward/reverse action setting	System area	Forward/revers e action setting	1	R/W	×	0	Page 371, Appendix 2 (30)
119(77 <sub>H</sub> )	СНЗ	Upper limit setting limiter	Upper limit setting limiter*6	Upper limit setting limiter	1300 (TT) 6000 (RT) *5	R/W	0	0	Page 372,
120(78 <sub>H</sub> )	СНЗ	Lower limit setting limiter	Lower limit setting limiter*6	Lower limit setting limiter	0 (TT) -2000 (RT) *5	R/W	0	0	Appendix 2 (31)
121(79 <sub>H</sub> )	CH3	System area			_	_	_	_	_
122(7A <sub>H</sub> )	CH3	Heater disconnection alert setting*11	Heater disconnection alert setting*6*11	Heater disconnection alert setting*11	0	R/W	×	0	Page 373, Appendix 2 (32)
123(7B <sub>H</sub> )	СНЗ	Loop disconnection detection judgment time	System area	Loop disconnection detection judgment time	480	R/W	×	0	Page 374, Appendix 2 (33)
124(7C <sub>H</sub> )	СНЗ	Loop disconnection detection dead band	System area	Loop disconnection detection dead band	0	R/W	0	0	Page 375, Appendix 2 (34)
125(7D <sub>H</sub> )	СНЗ	Unused channel setting	Unused channel setting*6	Unused channel setting	0	R/W	×	0	Page 376, Appendix 2 (35)
126(7E <sub>H</sub> )	СНЗ	Memory of PID constants read instruction	Memory of PID constants read instruction*6	Memory of PID constants read instruction	0	R/W	×	×	Page 377, Appendix 2 (36)
127(7F <sub>H</sub> )	СНЗ	Automatic backup setting after auto tuning of PID constants	Automatic backup setting after auto tuning of PID constants*6	Automatic backup setting after auto tuning of PID constants	0	R/W	×	×	Page 378, Appendix 2 (37)
128(80 <sub>H</sub> )	CH4	Input range*9			2(TT) 7(RT) *5	R/W	×	0	Page 345, Appendix 2 (12)

	Target	S	etting contents	5				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
129(81 <sub>H</sub> )	CH4	Stop mode setting	Stop mode setting*6	Stop mode setting	1	R/W	×	0	Page 353, Appendix 2 (13)
130(82 <sub>H</sub> )	CH4	Set value (SV) setting	Set value (SV) setting*6	Set value (SV) setting	0	R/W	0	0	Page 354, Appendix 2 (14)
131(83 <sub>H</sub> )	CH4	Proportional band (P) setting	Heating proportional band (Ph) setting*6	Proportional band (P) setting	30	R/W	×	0	Page 355, Appendix 2 (15)
132(84 <sub>H</sub> )	CH4	Integral time (I) setting	Integral time (I) setting*6	Integral time (I) setting	240	R/W	×	0	Page 357, Appendix 2 (16)
133(85 <sub>H</sub> )	CH4	Derivative time (D) setting	Derivative time (D) setting*6	Derivative time (D) setting	60	R/W	×	0	Page 357, Appendix 2 (17)
134(86 <sub>H</sub> )	CH4	Alert set value 1	Alert set value 1*6	Alert set value	0	R/W	0	0	
135(87 <sub>H</sub> )	CH4	Alert set value 2	Alert set value 2*6	Alert set value 2	0	R/W	0	0	Page 358,
136(88 <sub>H</sub> )	CH4	Alert set value 3	Alert set value 3*6	Alert set value	0	R/W	0	0	Appendix 2 (18)
137(89 <sub>H</sub> )	CH4	Alert set value 4	Alert set value 4*6	Alert set value	0	R/W	0	0	
138(8A <sub>H</sub> )	CH4	Upper limit output limiter	Heating upper limit output limiter*6	Upper limit output limiter	1000	R/W	×	0	Page 360, Appendix 2
139(8B <sub>H</sub> )	CH4	Lower limit output limiter	System area	Lower limit output limiter	0	R/W	×	0	(19)
140(8C <sub>H</sub> )	CH4	Output variation limiter setting	Output variation limiter setting*6	Output variation limiter setting	0	R/W	×	0	Page 362, Appendix 2 (20)
141(8D <sub>H</sub> )	CH4	Sensor correction	value setting		0	R/W	×	0	Page 363, Appendix 2 (21)
142(8E <sub>H</sub> )	CH4	Adjustment sensitivity (dead band) setting	Adjustment sensitivity (dead band) setting*6	Adjustment sensitivity (dead band) setting	5	R/W	×	0	Page 363, Appendix 2 (22)
143(8F <sub>H</sub> )	CH4	Control output cycle setting	Heating control output cycle setting*6	Control output cycle setting	30/300	R/W	×	0	Page 364, Appendix 2 (23)
144(90 <sub>H</sub> )	CH4	Primary delay dig	ital filter setting		0	R/W	×	0	Page 365, Appendix 2 (24)
145(91 <sub>H</sub> )	CH4	Control response parameters	Control response parameters*6	Control response parameters	0	R/W	×	0	Page 366, Appendix 2 (25)
146(92 <sub>H</sub> )	CH4	AUTO/MAN mode shift	AUTO/MAN mode shift *6	AUTO/MAN mode shift	0	R/W	×	0	Page 367, Appendix 2 (26)
147(93 <sub>H</sub> )	CH4	MAN output setting	MAN output setting*6	MAN output setting	0	R/W	×	0	Page 368, Appendix 2 (27)

	Target	S	etting contents	3				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
148(94 <sub>H</sub> )	CH4	Setting change ra limiter (temperatu *10	_	change rate	0	R/W	×	0	Page 369, Appendix 2 (28)
149(95 <sub>H</sub> )	CH4	AT bias	AT bias	AT bias	0	R/W	0	0	Page 370, Appendix 2 (29)
150(96 <sub>H</sub> )	CH4	Forward/reverse action setting	System area	Forward/revers e action setting	1	R/W	×	0	Page 371, Appendix 2 (30)
151(97 <sub>H</sub> )	CH4	Upper limit setting limiter	Upper limit setting limiter*6	Upper limit setting limiter	1300 (TT) 6000 (RT) *5	R/W	0	0	Page 372,
152(98 <sub>H</sub> )	CH4	Lower limit setting limiter	Lower limit setting limiter*6	Lower limit setting limiter	0 (TT) -2000 (RT) *5	R/W	0	0	Appendix 2 (31)
153(99 <sub>H</sub> )	CH4	System area	l	l .	_	_	_	_	_
154(9A <sub>H</sub> )	CH4	Heater disconnection alert setting*11	Heater disconnection alert setting*6*11	Heater disconnection alert setting*11	0	R/W	×	0	Page 373, Appendix 2 (32)
155(9B <sub>H</sub> )	CH4	Loop disconnection detection judgment time	System area	Loop disconnection detection judgment time	480	R/W	×	0	Page 374, Appendix 2 (33)
156(9C <sub>H</sub> )	CH4	Loop disconnection detection dead band	System area	Loop disconnection detection dead band	0	R/W	0	0	Page 375, Appendix 2 (34)
157(9D <sub>H</sub> )	CH4	Unused channel setting	Unused channel setting*6	Unused channel setting	0	R/W	×	0	Page 376, Appendix 2 (35)
158(9E <sub>H</sub> )	CH4	Memory of PID constants read instruction	Memory of PID constants read instruction*6	Memory of PID constants read instruction	0	R/W	×	×	Page 377, Appendix 2 (36)
159(9F <sub>H</sub> )	CH4	Automatic backup setting after auto tuning of PID constants	Automatic backup setting after auto tuning of PID constants*6	Automatic backup setting after auto tuning of PID constants	0	R/W	×	×	Page 378, Appendix 2 (37)
160(A0 <sub>H</sub> ) to 163(A3 <sub>H</sub> )	_	System area			_	_	_	_	_
164(A4 <sub>H</sub> )	All CHs	Alert dead band s	etting		5	R/W	×	0	Page 379, Appendix 2 (38)
165(A5 <sub>H</sub> )	All CHs	Number of alert d	Number of alert delay		0	R/W	×	0	Page 379, Appendix 2 (39)
166(A6 <sub>H</sub> )	All CHs	Heater disconnect detection delay co	•	e current error	3	R/W	×	0	Page 380, Appendix 2 (40)

	Target	S	Setting contents	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
167(A7 <sub>H</sub> )	All CHs	Temperature rise	completion range	setting	1	R/W	×	0	Page 380, Appendix 2 (41)
168(A8 <sub>H</sub> )	All CHs	Temperature rise	completion soak ti	ime setting	0	R/W	×	0	Page 381, Appendix 2 (42)
169(A9 <sub>H</sub> )	All CHs	PID continuation	flag		0	R/W	×	0	Page 381, Appendix 2 (43)
170(AA <sub>H</sub> )	All CHs	Heater disconnec	tion correction fun	ction selection*11	0	R/W	×	0	Page 381, Appendix 2 (44)
171(AB <sub>H</sub> ) to 174(AE <sub>H</sub> )	_	System area			_	_	_	_	_
175(AF <sub>H</sub> )	All CHs	Transistor output	ransistor output monitor ON delay time setting				×	0	Page 382, Appendix 2 (45)
176(B0 <sub>H</sub> )	All CHs	CT monitor metho	CT monitor method switching*11				×	0	Page 382, Appendix 2 (46)
177(B1 <sub>H</sub> )	CH1	Manipulated value (MV) for output with another analog module	Manipulated value of heating (MVh) for output with another analog module	Manipulated value of heating (MVh) for output with another analog module	0	R	×	×	
178(B2 <sub>H</sub> )	CH2	Manipulated value (MV) for output with another analog module	Manipulated value of heating (MVh) for output with another analog module	Manipulated value of heating (MVh) for output with another analog module*7	0	R	×	×	Page 383,
179(B3 <sub>H</sub> )	СНЗ	Manipulated value (MV) for output with another analog module	Manipulated value of heating (MVh) for output with another analog module*6	Manipulated value (MV) for output with another analog module	0	R	×	×	Appendix 2 (47)
180(B4 <sub>H</sub> )	CH4	Manipulated value (MV) for output with another analog module	module o  Manipulated value of heating (MVh) for output with another analog  Manipulated value (MV) for output with another analog		0	R	×	×	
181(B5 <sub>H</sub> )	All CHs		Resolution of the manipulated value for output with inother analog module		0	R/W	×	0	Page 384, Appendix 2 (48)
182(B6 <sub>H</sub> )	All CHs	Cold junction temperature compensation selection*8			0	R/W	×	0	Page 384, Appendix 2 (49)
183(B7 <sub>H</sub> )	All CHs	Control switching	ontrol switching monitor			R	×	×	Page 385, Appendix 2 (50)

	Target	8	Setting contents	3				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
184(B8 <sub>H</sub> )	CH1	Auto tuning mode	eselection		0	R/W	×	0	
185(B9 <sub>H</sub> )	CH2	Auto tuning mode selection	Auto tuning mode selection	Auto tuning mode selection	0	R/W	×	0	
186(BA <sub>H</sub> )	СНЗ	Auto tuning mode selection	Auto tuning mode selection*6	Auto tuning mode selection	0	R/W	×	0	Page 385, Appendix 2 (51)
187(BB <sub>H</sub> )	CH4	Auto tuning mode selection	Auto tuning mode selection*6	Auto tuning mode selection	0	R/W	×	0	
188(BC <sub>H</sub> ) to 191(BF <sub>H</sub> )	_	System area			_	_	_	_	_
192(C0 <sub>H</sub> )	CH1	Alert 1 mode setti	ina* <sup>9</sup>		0	R/W	×	0	
193(C1 <sub>H</sub> )	CH1	Alert 2 mode sett			0	R/W	×	0	Page 386,
194(C2 <sub>H</sub> )	CH1		lert 2 mode setting *  lert 3 mode setting*9				×	0	Appendix 2 (52)
195(C3 <sub>H</sub> )	CH1		Alert 3 mode setting <sup>9</sup> Alert 4 mode setting <sup>9</sup>				×	0	(32)
196(C4 <sub>H</sub> )	OIII	Alert 4 mode sett	ilig		0	R/W		0	
to 207(CF <sub>H</sub> )	_	System area			_	_	_	_	_
208(D0 <sub>H</sub> )	CH2	Alert 1 mode setting*9	Alert 1 mode setting*9	Alert 1 mode setting*7*9	0	R/W	×	0	
209(D1 <sub>H</sub> )	CH2	Alert 2 mode setting*9	Alert 2 mode setting*9	Alert 2 mode setting*7*9	0	R/W	×	0	Page 386, Appendix 2
210(D2 <sub>H</sub> )	CH2	Alert 3 mode setting*9	Alert 3 mode setting*9	Alert 3 mode setting*7*9	0	R/W	×	0	(52)
211(D3 <sub>H</sub> )	CH2	Alert 4 mode setting*9	Alert 4 mode setting*9	Alert 4 mode setting*7*9	0	R/W	×	0	
212(D4 <sub>H</sub> ) to 223(DF <sub>H</sub> )	_	System area			_	_	_	_	_
224(E0 <sub>H</sub> )	CH3	Alert 1 mode setting*9	Alert 1 mode setting*6*9	Alert 1 mode setting*9	0	R/W	×	0	
225(E1 <sub>H</sub> )	CH3	Alert 2 mode setting*9	Alert 2 mode setting*6*9	Alert 2 mode setting*9	0	R/W	×	0	Page 386,
226(E2 <sub>H</sub> )	CH3	Alert 3 mode setting*9	Alert 3 mode setting*6*9	Alert 3 mode setting*9	0	R/W	×	0	Appendix 2 (52)
227(E3 <sub>H</sub> )	CH3	Alert 4 mode setting*9	Alert 4 mode setting*6*9	Alert 4 mode setting*9	0	R/W	×	0	
228(E4 <sub>H</sub> ) to 239(EF <sub>H</sub> )	_	System area			_	_	_	_	_

	Target Setting contents							Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
240(F0 <sub>H</sub> )	CH4	Alert 1 mode setting*9	Alert 1 mode setting*6*9	Alert 1 mode setting*9	0	R/W	×	0	
241(F1 <sub>H</sub> )	CH4	Alert 2 mode setting*9	Alert 2 mode setting*6*9	Alert 2 mode setting*9	0	R/W	×	0	Page 386, Appendix 2
242(F2 <sub>H</sub> )	CH4	Alert 3 mode setting*9	Alert 3 mode setting*6*9	Alert 3 mode setting*9	0	R/W	×	0	(52)
243(F3 <sub>H</sub> )	CH4	Alert 4 mode setting*9	Alert 4 mode setting*6*9	Alert 4 mode setting*9	0	R/W	×	0	
244(F4 <sub>H</sub> ) to 255(FF <sub>H</sub> )	_	System area			_	_	_	_	_
256(100 <sub>H</sub> )	CT1	Heater current m	easurement value	*11					
257(101 <sub>H</sub> )	CT2	Heater current m	easurement value	*11					
258(102 <sub>H</sub> )	CT3	Heater current m	easurement value	e <sup>*11</sup>					
259(103 <sub>H</sub> )	CT4	Heater current m	easurement value	e <sup>*11</sup>	0	R	×	×	Page 390, Appendix 2
260(104 <sub>H</sub> )	CT5	Heater current m	easurement value		IX.		^	(58)	
261(105 <sub>H</sub> )	CT6	Heater current m	easurement value						
262(106 <sub>H</sub> )	CT7	Heater current m	easurement value						
263(107 <sub>H</sub> )	CT8	Heater current m	easurement value						
264(108 <sub>H</sub> )	CT1	CT input channe	l assignment settir	ng <sup>*11</sup>					
265(109 <sub>H</sub> )	CT2	CT input channe	l assignment settir	ng <sup>*11</sup>					
266(10A <sub>H</sub> )	CT3	CT input channe	l assignment settir	ng <sup>*11</sup>					
267(10B <sub>H</sub> )	CT4	CT input channe	l assignment settir	ng <sup>*11</sup>	0	R/W	×	0	Page 391, Appendix 2
268(10C <sub>H</sub> )	CT5	· ·	l assignment settir						(59)
269(10D <sub>H</sub> )	CT6	CT input channe	l assignment settir	ng <sup>*11</sup>	-				
270(10E <sub>H</sub> )	CT7	CT input channe	l assignment settir	ng <sup>*11</sup>	-				
271(10F <sub>H</sub> )	CT8		l assignment settir	ng <sup>*11</sup>					
272(110 <sub>H</sub> )	CT1	CT selection*9*11			-				
273(111 <sub>H</sub> )	CT2	CT selection*9*11							
274(112 <sub>H</sub> )	CT3	CT selection*9*11			-				Page 392,
275(113 <sub>H</sub> )	CT4	CT selection*9*11			0	R/W	×	0	Appendix 2
276(114 <sub>H</sub> )	CT5	CT selection*9*11			-				(60)
277(115 <sub>H</sub> )	CT6	CT selection*9*11							
278(116 <sub>H</sub> )	CT7	CT selection*9*11			-				
279(117 <sub>H</sub> ) 280(118 <sub>H</sub> )	CT8	CT selection*9*11							
	CT1		r current value*11						
281(119 <sub>H</sub> )	CT2		r current value*11						
282(11A <sub>H</sub> ) 283(11B <sub>H</sub> )	CT3 CT4		r current value*11						Page 393,
284(11C <sub>H</sub> )			eference heater current value*11 eference heater current value*11			R/W	×	0	Appendix 2
	CT6							(61)	
285(11D <sub>H</sub> )	CT6		r current value*11						
286(11E <sub>H</sub> )	CT7	Reference heate	r current value*11		]				1

	Target	S	etting content	s				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
288(120 <sub>H</sub> )	CT1	CT ratio setting*11	l						
289(121 <sub>H</sub> )	CT2	CT ratio setting*11	1						
290(122 <sub>H</sub> )	СТЗ	CT ratio setting*11	l						
291(123 <sub>H</sub> )	CT4	CT ratio setting*11	l		800	R/W	×		Page 393, Appendix 2
292(124 <sub>H</sub> )	CT5	CT ratio setting*11	1		800	FC/ VV	^	0	(62)
293(125 <sub>H</sub> )	CT6	CT ratio setting*11	l						
294(126 <sub>H</sub> )	CT7	CT ratio setting*11	1						
295(127 <sub>H</sub> )	CT8	CT ratio setting*11							
296(128 <sub>H</sub> ) to 543(21F <sub>H</sub> )	_	System area				_	_	_	_
544(220 <sub>H</sub> )	CH1	2-point sensor cor value)*9	mpensation offset	0	R/W	0	0	Page 394, Appendix 2 (63)	
545(221 <sub>H</sub> )	CH1	· ·	2-point sensor compensation offset value compensation value)*9				0	0	Page 394, Appendix 2 (64)
546(222 <sub>H</sub> )	CH1	2-point sensor co	0	R/W	0	0	Page 395, Appendix 2 (65)		
547(223 <sub>H</sub> )	CH1	2-point sensor coll (compensation va		value	0	R/W	0	0	Page 395, Appendix 2 (66)
548(224 <sub>H</sub> )	CH1	2-point sensor co	mpensation offset	t latch request*9	0	R/W	×	×	Page 396, Appendix 2 (67)
549(225 <sub>H</sub> )	CH1	2-point sensor co	mpensation offset	t latch completion	0	R	×	×	Page 396, Appendix 2 (68)
550(226 <sub>H</sub> )	CH1	2-point sensor co	mpensation gain l	atch request*9	0	R/W	×	×	Page 397, Appendix 2 (69)
551(227 <sub>H</sub> )	CH1	2-point sensor co	mpensation gain l	atch completion	0	R	×	×	Page 397, Appendix 2 (70)
552(228 <sub>H</sub> ) to 563(233 <sub>H</sub> )	_	System area			_	_	_	_	_
564(234 <sub>H</sub> )	CH1	Setting change ra	te limiter (temper	ature drop)*12	0	R/W	×	0	Page 369, Appendix 2 (28)
565(235 <sub>H</sub> ) to 572(23C <sub>H</sub> )	_	System area	area				_	_	_
573(23D <sub>H</sub> )	CH1	AT simultaneous temperature rise parameter calculation flag	System area	0	R	×	×	Page 398, Appendix 2 (71)	
574(23E <sub>H</sub> )	CH1	Self-tuning setting	System area	System area	0	R/W	×	0	Page 399, Appendix 2 (72)

	Target	S	etting content	s				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
575(23F <sub>H</sub> )	CH1	Self-tuning flag	System area	System area	0	R	×	×	Page 400, Appendix 2 (73)
576(240 <sub>H</sub> )	CH2	2-point sensor corvalue)*9	mpensation offset	value (measured	0	R/W	0	0	Page 394, Appendix 2 (63)
577(241 <sub>H</sub> )	CH2	2-point sensor collaboration va	•	value	0	R/W	0	0	Page 394, Appendix 2 (64)
578(242 <sub>H</sub> )	CH2	2-point sensor con value)*9	mpensation gain v	value (measured	0	R/W	0	0	Page 395, Appendix 2 (65)
579(243 <sub>H</sub> )	CH2	2-point sensor con (compensation va	-	/alue	0	R/W	0	0	Page 395, Appendix 2 (66)
580(244 <sub>H</sub> )	CH2	2-point sensor con	oint sensor compensation offset latch request <sup>*9</sup>				×	×	Page 396, Appendix 2 (67)
581(245 <sub>H</sub> )	CH2	2-point sensor cor	point sensor compensation offset latch completion				×	×	Page 396, Appendix 2 (68)
582(246 <sub>H</sub> )	CH2	2-point sensor cor	2-point sensor compensation gain latch request*9				×	×	Page 397, Appendix 2 (69)
583(247 <sub>H</sub> )	CH2	2-point sensor cor	mpensation gain l	atch completion	0	R	×	×	Page 397, Appendix 2 (70)
584(248 <sub>H</sub> ) to 595(253 <sub>H</sub> )	_	System area			_	_	_	_	_
596(254 <sub>H</sub> )	CH2	Setting change ra	te limiter (tempera	ature drop)*12	0	R/W	×	0	Page 369, Appendix 2 (28)
597(255 <sub>H</sub> ) to 604(25C <sub>H</sub> )	_	System area			_	_	_	_	_
605(25D <sub>H</sub> )	CH2	AT simultaneous temperature rise parameter calculation flag	System area	System area	0	R	×	×	Page 398, Appendix 2 (71)
606(25E <sub>H</sub> )	CH2	Self-tuning setting	System area	System area	0	R/W	×	0	Page 399, Appendix 2 (72)
607(25F <sub>H</sub> )	CH2	Self-tuning flag				R	×	×	Page 400, Appendix 2 (73)
608(260 <sub>H</sub> )	СНЗ	2-point sensor cor value)*9	pint sensor compensation offset value (measured			R/W	0	0	Page 394, Appendix 2 (63)
609(261 <sub>H</sub> )	СНЗ		2-point sensor compensation offset value (compensation value)*9			R/W	0	0	Page 394, Appendix 2 (64)
610(262 <sub>H</sub> )	СНЗ	2-point sensor cor value)*9	mpensation gain v	value (measured	0	R/W	0	0	Page 395, Appendix 2 (65)

	Target	s	etting content	S				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
611(263 <sub>H</sub> )	CH3	2-point sensor col		/alue	0	R/W	0	0	Page 395, Appendix 2 (66)
612(264 <sub>H</sub> )	CH3	2-point sensor co	mpensation offset	latch request*9	0	R/W	×	×	Page 396, Appendix 2 (67)
613(265 <sub>H</sub> )	CH3	2-point sensor col	mpensation offset	latch completion	0	R	×	×	Page 396, Appendix 2 (68)
614(266 <sub>H</sub> )	CH3	2-point sensor con	mpensation gain l	atch request <sup>*9</sup>	0	R/W	×	×	Page 397, Appendix 2 (69)
615(267 <sub>H</sub> )	CH3	2-point sensor cor	mpensation gain l	atch completion	0	R	×	×	Page 397, Appendix 2 (70)
616(268 <sub>H</sub> ) to 627(273 <sub>H</sub> )	_	System area	ystem area				_	_	_
628(274 <sub>H</sub> )	СНЗ	Setting change ra	Setting change rate limiter (temperature drop)*12				×	0	Page 369, Appendix 2 (28)
629(275 <sub>H</sub> ) to 636(27C <sub>H</sub> )	_	System area			_	_	_	_	_
637(27D <sub>H</sub> )	СНЗ	AT simultaneous temperature rise parameter calculation flag	System area	AT simultaneous temperature rise parameter calculation flag	0	R	×	×	Page 398, Appendix 2 (71)
638(27E <sub>H</sub> )	СНЗ	Self-tuning setting	System area	Self-tuning setting	0	R/W	×	0	Page 399, Appendix 2 (72)
639(27F <sub>H</sub> )	СНЗ	Self-tuning flag	System area	Self-tuning flag	0	R	×	×	Page 400, Appendix 2 (73)
640(280 <sub>H</sub> )	CH4	2-point sensor cor value)*9	mpensation offset	value (measured	0	R/W	0	0	Page 394, Appendix 2 (63)
641(281 <sub>H</sub> )	CH4	2-point sensor col	•	value	0	R/W	0	0	Page 394, Appendix 2 (64)
642(282 <sub>H</sub> )	CH4	2-point sensor con value)*9	mpensation gain v	value (measured	0	R/W	0	0	Page 395, Appendix 2 (65)
643(283 <sub>H</sub> )	CH4	-	-point sensor compensation gain value compensation value)*9			R/W	0	0	Page 395, Appendix 2 (66)
644(284 <sub>H</sub> )	CH4	2-point sensor con	2-point sensor compensation offset latch request*9			R/W	×	×	Page 396, Appendix 2 (67)
645(285 <sub>H</sub> )	CH4	2-point sensor con	mpensation offset	latch completion	0	R	×	×	Page 396, Appendix 2 (68)

	Target	S				Non-			
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
646(286 <sub>H</sub> )	CH4	2-point sensor co	mpensation gain la	atch request*9	0	R/W	×	×	Page 397, Appendix 2 (69)
647(287 <sub>H</sub> )	CH4	2-point sensor co	mpensation gain l	atch completion	0	R	×	×	Page 397, Appendix 2 (70)
648(288 <sub>H</sub> ) to 659(293 <sub>H</sub> )	_	System area			_		_	_	_
660(294 <sub>H</sub> )	CH4	Setting change ra	te limiter (tempera	ature drop) <sup>*12</sup>	0	R/W	×	0	Page 369, Appendix 2 (28)
661(295 <sub>H</sub> ) to 668(29C <sub>H</sub> )	_	System area	simultaneous AT simultaneous			_	_	_	_
669(29D <sub>H</sub> )	CH4	AT simultaneous temperature rise parameter calculation flag	System area		0	R	×	×	Page 398, Appendix 2 (71)
670(29E <sub>H</sub> )	CH4	Self-tuning setting	System area	Self-tuning setting	0	R/W	×	0	Page 399, Appendix 2 (72)
671(29Fн)	CH4	Self-tuning flag	System area	Self-tuning flag	0	R	×	×	Page 400, Appendix 2 (73)
672(2A0 <sub>H</sub> ) to 688(2B0 <sub>H</sub> )	_	System area			_	_	_	_	_
689(2B1 <sub>H</sub> )	CH1	Temperature production another analog m		input with	0	R/W	×	×	
690(2B2 <sub>H</sub> )	CH2	Temperature process value (PV) for input with another analog module	Temperature process value (PV) for input with another analog module	Temperature process value (PV) for input with another analog module *7	0	R/W	×	×	
691(2B3 <sub>H</sub> )	CH3	Temperature process value (PV) for input with another analog module	Temperature process value (PV) for input with another analog module*6	Temperature process value (PV) for input with another analog module	0	R/W	×	×	Page 402, Appendix 2 (74)
692(2B4 <sub>H</sub> )	CH4	Temperature process value (PV) for input with another analog module	Temperature process value (PV) for input with another analog module*6	Temperature process value (PV) for input with another analog module	0	R/W	×	×	
693(2B5 <sub>H</sub> )	_	System area	·		_	1	_	_	
694(2B6 <sub>H</sub> )		System area			_			_	

	Target		Setting contents	s				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
695(2B7 <sub>H</sub> )	CH2	System area	System area	Temperature conversion setting *14	0	R/W	×	0	
696(2B8 <sub>H</sub> )	СНЗ	System area	Temperature conversion setting	System area	0	R/W	×	0	Page 403, Appendix 2 (76)
697(2B9 <sub>H</sub> )	CH4	System area	Temperature conversion setting	System area	0	R/W	×	0	
698(2BA <sub>H</sub> ) to 703(2BF <sub>H</sub> )	_	System area			_	_	_	_	_
704(2C0 <sub>H</sub> )	CH1	System area	Manipulated value for cooling (MVc)	Manipulated value for cooling (MVc)	0	R	×	×	
705(2C1 <sub>H</sub> )	CH2	System area	Manipulated value for cooling (MVc)	Manipulated value for cooling (MVc)*7	0	R	×	×	Page 339,
706(2C2 <sub>H</sub> )	СНЗ	System area	Manipulated value for cooling (MVc)*6	System area	0	R	×	×	Appendix 2 (5)
707(2C3 <sub>H</sub> )	CH4	System area	Manipulated value for cooling (MVc)*6	System area	0	R	×	×	
708(2C4 <sub>H</sub> )	CH1	System area	Manipulated value of cooling (MVc) for output with another analog module	Manipulated value of cooling (MVc) for output with another analog module	0	R	×	×	
709(2C5 <sub>H</sub> )	CH2	System area	Manipulated value of cooling (MVc) for output with another analog module	Manipulated value of cooling (MVc) for output with another analog module*7	0	R	×	×	Page 383,
710(2C6 <sub>H</sub> )	СНЗ	System area	Manipulated value of cooling (MVc) for output with another analog module*6	System area	0	R	×	×	Appendix 2 (47)
711(2C7 <sub>H</sub> )	CH4	System area	Manipulated value of cooling (MVc) for output with another analog module*6	System area	0	R	×	×	

	Target	S	etting content	s				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference
712(2C8 <sub>H</sub> )	CH1	System area	Cooling transistor output flag	Cooling transistor output flag	0	R	×	×	
713(2C9 <sub>H</sub> )	CH2	System area	Cooling transistor output flag	Cooling transistor output flag *7	0	R	×	×	Page 341,
714(2CA <sub>H</sub> )	СНЗ	System area	Cooling transistor output flag *6	System area	0	R	×	×	Appendix 2 (7)
715(2CB <sub>H</sub> )	CH4	System area	Cooling transistor output flag *6	System area	0	R	×	×	
716(2CC <sub>H</sub> ) to 718(2CE <sub>H</sub> )	_	System area	,	,	_	_	_	_	_
719(2CF <sub>H</sub> )	All CHs	System area	Cooling method setting	Cooling method setting	0	R/W	×	0	Page 404, Appendix 2 (77)
720(2D0 <sub>H</sub> )	CH1	System area	Cooling proportional band (Pc) setting	Cooling proportional band (Pc) setting	30	R/W	×	0	Page 355, Appendix 2 (15)
721(2D1 <sub>H</sub> )	CH1	System area	Cooling upper limit output limiter	Cooling upper limit output limiter	1000	R/W	×	0	Page 360, Appendix 2 (19)
722(2D2 <sub>H</sub> )	CH1	System area	Cooling control output cycle setting	Cooling control output cycle setting	30/300	R/W	×	0	Page 364, Appendix 2 (23)
723(2D3 <sub>H</sub> )	CH1	System area	Overlap/dead band setting	Overlap/dead band setting	0	R/W	×	0	Page 404, Appendix 2 (78)
724(2D4 <sub>H</sub> )	CH1	Manual reset amo	ount setting		0	R/W	×	0	Page 405, Appendix 2 (79)
725(2D5 <sub>H</sub> )	CH1	Process value (P <sup>1</sup> setting*9	V) scaling function	enable/disable	0	R/W	×	0	Page 405, Appendix 2 (80)
726(2D6 <sub>H</sub> )	CH1	Process value (P	V) scaling lower lin	mit value <sup>*9</sup>	0	R/W	×	0	Page 406,
727(2D7 <sub>H</sub> )	CH1	Process value (P	V) scaling upper li	mit value <sup>*9</sup>	0	R/W	×	0	Appendix 2 (81)
728(2D8 <sub>H</sub> )	CH1	Process value (P	V) scaling value		0	R	×	×	Page 406, Appendix 2 (82)
729(2D9 <sub>H</sub> )	CH1	Derivative action	selection*9		0	R/W	×	0	Page 407, Appendix 2 (83)
730(2DA <sub>H</sub> )	CH1	Simultaneous temperature rise group setting*9	System area	System area	0	R/W	×	0	Page 407, Appendix 2 (84)
731(2DB <sub>H</sub> )	CH1	Simultaneous temperature rise gradient data	System area	System area	0	R/W	0	0	Page 408, Appendix 2 (85)

	Target	S	etting contents	s				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
732(2DC <sub>H</sub> )	CH1	Simultaneous temperature rise dead time	System area	System area	0	R/W	0	0	Page 408, Appendix 2 (86)
733(2DD <sub>H</sub> )	CH1	Simultaneous temperature rise AT mode selection	System area	System area	0	R/W	×	0	Page 409, Appendix 2 (87)
734(2DE <sub>H</sub> )	CH1	Simultaneous temperature rise status	System area	System area	0	R	×	×	Page 410, Appendix 2 (88)
735(2DF <sub>H</sub> )	CH1	Setting change ra	Setting change rate limiter unit time setting*9			R/W	×	0	Page 411, Appendix 2 (89)
736(2E0 <sub>H</sub> )	CH2	System area	Cooling proportional band (Pc) setting	Cooling proportional band (Pc) setting* <sup>7</sup>	30	R/W	×	0	Page 355, Appendix 2 (15)
737(2E1 <sub>H</sub> )	CH2	System area	Cooling upper limit output limiter	Cooling upper limit output limiter*7	1000	R/W	×	0	Page 360, Appendix 2 (19)
738(2E2 <sub>H</sub> )	CH2	System area	Cooling control output cycle setting	Cooling control output cycle setting*7	30/300	R/W	×	0	Page 364, Appendix 2 (23)
739(2E3 <sub>H</sub> )	CH2	System area	Overlap/dead band setting	Overlap/dead band setting*7	0	R/W	×	0	Page 404, Appendix 2 (78)
740(2E4 <sub>H</sub> )	CH2	Manual reset amount setting	Manual reset amount setting	Manual reset amount setting*7	0	R/W	×	0	Page 405, Appendix 2 (79)
741(2E5 <sub>H</sub> )	CH2	Process value (PV) scaling function enable/disable setting*9	Process value (PV) scaling function enable/disable setting*9	Process value (PV) scaling function enable/disable setting*7*9	0	R/W	×	0	Page 405, Appendix 2 (80)
742(2E6 <sub>H</sub> )	CH2	Process value (PV) scaling lower limit value*9	Process value (PV) scaling lower limit value*9	Process value (PV) scaling lower limit value*7*9	0	R/W	×	0	Page 406,
743(2E7 <sub>H</sub> )	CH2	Process value (PV) scaling upper limit value*9	Process value (PV) scaling upper limit value*9	Process value (PV) scaling upper limit value*7*9	0	R/W	×	0	Appendix 2 (81)
744(2E8 <sub>H</sub> )	CH2	Process value (PV) scaling value	Process value (PV) scaling value	Process value (PV) scaling value *7	0	R	×	×	Page 406, Appendix 2 (82)
745(2E9 <sub>H</sub> )	CH2	Derivative action selection	Derivative action selection	Derivative action selection *7*9	0	R/W	×	0	Page 407, Appendix 2 (83)
746(2EA <sub>H</sub> )	CH2	Simultaneous temperature rise group setting*9	System area	System area	0	R/W	×	0	Page 407, Appendix 2 (84)
747(2EB <sub>H</sub> )	CH2	Simultaneous temperature rise gradient data	System area	System area	0	R/W	0	0	Page 408, Appendix 2 (85)

	Target	S	etting contents	5				Non-		
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability	Reference	
748(2EC <sub>H</sub> )	CH2	Simultaneous temperature rise dead time	System area	System area	0	R/W	0	0	Page 408, Appendix 2 (86)	
749(2ED <sub>H</sub> )	CH2	Simultaneous temperature rise AT mode selection	System area	System area	0	R/W	×	0	Page 409, Appendix 2 (87)	
750(2EE <sub>H</sub> )	CH2	Simultaneous temperature rise status	System area	System area	0	R	×	×	Page 410, Appendix 2 (88)	
751(2EF <sub>H</sub> )	CH2	Setting change rate limiter unit time setting*9	Setting change rate limiter unit time setting*9	Setting change rate limiter unit time setting *7*9	0	R/W	×	0	Page 411, Appendix 2 (89)	
752(2F0 <sub>H</sub> )	CH3	System area	Cooling proportional band (Pc) setting*6	System area	30	R/W	×	0	Page 355, Appendix 2 (15)	
753(2F1 <sub>H</sub> )	СНЗ	System area	Cooling upper limit output limiter*6	System area	1000	R/W	×	0	Page 360, Appendix 2 (19)	
754(2F2 <sub>H</sub> )	CH3	System area	Cooling control output cycle setting*6	System area	30/300	R/W	×	0	Page 364, Appendix 2 (23)	
755(2F3 <sub>H</sub> )	СНЗ	System area	Overlap/dead band setting*6	System area	0	R/W	×	0	Page 404, Appendix 2 (78)	
756(2F4 <sub>H</sub> )	СНЗ	Manual reset amount setting	Manual reset amount setting*6	Manual reset amount setting	0	R/W	×	0	Page 405, Appendix 2 (79)	
757(2F5 <sub>H</sub> )	СНЗ	Process value (PV) scaling function enable/disable setting*9	Process value (PV) scaling function enable/disable setting*6*9	Process value (PV) scaling function enable/disable setting*9	0	R/W	×	0	Page 405, Appendix 2 (80)	
758(2F6 <sub>H</sub> )	СНЗ	Process value (PV) scaling lower limit value*9	Process value (PV) scaling lower limit value*6*9	Process value (PV) scaling lower limit value*9	0	R/W	×	0	Page 406,	
759(2F7 <sub>H</sub> )	СНЗ	Process value (PV) scaling upper limit value*9	Process value (PV) scaling upper limit value*6*9	Process value (PV) scaling upper limit value*9	0	R/W	×	0	Appendix 2 (81)	
760(2F8 <sub>H</sub> )	СНЗ	Process value (PV) scaling value	Process value (PV) scaling value*6	Process value (PV) scaling value	0	R	×	×	Page 406, Appendix 2 (82)	
761(2F9 <sub>H</sub> )	СНЗ	Derivative action selection	Derivative action selection *6*9	Derivative action selection	0	R/W	×	0	Page 407, Appendix 2 (83)	
762(2FA <sub>H</sub> )	СНЗ	Simultaneous temperature rise group setting*9	System area	Simultaneous temperature rise group setting*9	0	R/W	×	0	Page 407, Appendix 2 (84)	

	Target	S	etting contents	<b>3</b>				Non-		
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference	
763(2FB <sub>H</sub> )	СНЗ	Simultaneous temperature rise gradient data	System area	Simultaneous temperature rise gradient data	0	R/W	0	0	Page 408, Appendix 2 (85)	
764(2FC <sub>H</sub> )	СНЗ	Simultaneous temperature rise dead time	System area	Simultaneous temperature rise dead time	0	R/W	0	0	Page 408, Appendix 2 (86)	
765(2FD <sub>H</sub> )	СНЗ	Simultaneous temperature rise AT mode selection	System area	Simultaneous temperature rise AT mode selection	0	R/W	×	0	Page 409, Appendix 2 (87)	
766(2FE <sub>H</sub> )	СНЗ	Simultaneous temperature rise status	System area	Simultaneous temperature rise status	0	R	×	×	Page 410, Appendix 2 (88)	
767(2FF <sub>H</sub> )	CH3	Setting change rate limiter unit time setting*9	Setting change rate limiter unit time setting*6*9	Setting change rate limiter unit time setting*9	0	R/W	×	0	Page 411, Appendix 2 (89)	
768(300 <sub>H</sub> )	CH4	System area	Cooling proportional band (Pc) setting*6	System area	30	R/W	×	0	Page 355, Appendix 2 (15)	
769(301 <sub>H</sub> )	CH4	System area	Cooling upper limit output limiter*6	System area	1000	R/W	×	0	Page 360, Appendix 2 (19)	
770(302 <sub>H</sub> )	CH4	System area	Cooling control output cycle setting*6	System area	30/300	R/W	×	0	Page 364, Appendix 2 (23)	
771(303 <sub>H</sub> )	CH4	System area	Overlap/dead band setting*6	System area	0	R/W	×	0	Page 404, Appendix 2 (78)	
772(304 <sub>H</sub> )	CH4	Manual reset amount setting	Manual reset amount setting*6	Manual reset amount setting	0	R/W	×	0	Page 405, Appendix 2 (79)	
773(305 <sub>H</sub> )	CH4	Process value (PV) scaling function enable/disable setting	Process value (PV) scaling function enable/disable setting*6*9	Process value (PV) scaling function enable/disable setting	0	R/W	×	0	Page 405, Appendix 2 (80)	
774(306 <sub>H</sub> )	CH4	Process value (PV) scaling lower limit value*9	Process value (PV) scaling lower limit value*6*9	Process value (PV) scaling lower limit value*9	0	R/W	×	0	Page 406,	
775(307 <sub>H</sub> )	CH4	Process value (PV) scaling upper limit value*9	Process value (PV) scaling upper limit value*6*9	Process value (PV) scaling upper limit value*9	0	R/W	×	0	Appendix 2 (81)	
776(308 <sub>H</sub> )	CH4	Process value (PV) scaling value	Process value (PV) scaling value*6	Process value (PV) scaling value	0	R	×	×	Page 406, Appendix 2 (82)	
777(309 <sub>H</sub> )	CH4	Derivative action selection*9	Derivative action selection *6*9	Derivative action selection	0	R/W	×	0	Page 407, Appendix 2 (83)	

	Target	S	etting contents	<b>S</b>				Non-	
Address (decimal (hexadecimal))	channel or current sensor (CT)	Standard control	Heating- cooling control	Mix control	Default value *1	Read/ Write *2	Automatic setting *3	volatile memory write availability *4	Reference
778(30A <sub>H</sub> )	CH4	Simultaneous temperature rise group setting*9	System area	Simultaneous temperature rise group setting*9	0	R/W	×	0	Page 407, Appendix 2 (84)
779(30B <sub>H</sub> )	CH4	Simultaneous temperature rise gradient data	System area	Simultaneous temperature rise gradient data	0	R/W	0	0	Page 408, Appendix 2 (85)
780(30C <sub>H</sub> )	CH4	Simultaneous temperature rise dead time	System area	Simultaneous temperature rise dead time	0	R/W	0	0	Page 408, Appendix 2 (86)
781(30D <sub>H</sub> )	CH4	Simultaneous temperature rise AT mode selection	System area	Simultaneous temperature rise AT mode selection	0	R/W	×	0	Page 409, Appendix 2 (87)
782(30E <sub>H</sub> )	CH4	Simultaneous temperature rise status	System area	Simultaneous temperature rise status	0	R	×	×	Page 410, Appendix 2 (88)
783(30F <sub>H</sub> )	CH4	Setting change rate limiter unit time setting*9	Setting change rate limiter unit time setting*6*9	Setting change rate limiter unit time setting*9	0	R/W	×	0	Page 411, Appendix 2 (89)
784(310 <sub>H</sub> )	All CHs	Peak current suppression control group setting*9	System area	System area	0	R/W	×	0	Page 412, Appendix 2 (90)
785(311 <sub>H</sub> )	All CHs	Sensor compensa	ation function selec	ction*9	0	R/W	×	0	Page 413, Appendix 2 (91)
786(312 <sub>H</sub> )	All CHs	Temperature conv	version completion	flag	0	R	×	×	Page 413, Appendix 2 (92)
787(313 <sub>H</sub> )	All CHs	Function extensio	n bit monitor		0	R	×	×	Page 414, Appendix 2 (93)
788(314 <sub>H</sub> )	All CHs	Sampling cycle m	onitor		0	R	×	×	Page 414, Appendix 2 (94)
789(315 <sub>H</sub> ) to 1278(4FE <sub>H</sub> )		System area					_		_
1279(4FF <sub>H</sub> ) to 4095(FFF <sub>H</sub> )			Buffer memory	y for error history (	Page	e 76, Sectio	on 3.5 (2))		
4096(1000 <sub>H</sub> ) to 53247(CFFF <sub>H</sub> )	_	System area			_	_	_	_	_

- \*1 This default value is set after the module is turned off and on or after the CPU module is reset and the reset is cancelled.
- \*2 This column indicates whether data can be read from or written to the buffer memory area through sequence programs. R: Reading enabled
  - W: Writing enabled
- \*3 This column indicates whether the setting in the buffer memory area is automatically changed when the input range is changed. Enable/disable of automatic change can be set on Switch Setting. For details, refer to Page 234, Section 8.3.3.
- \*4 Whether writing to the non-volatile memory by turning off and on Set value backup instruction (Yn8) is enabled in this column. For details, refer to Page 235, Section 8.3.4.
- \*5 (TT) indicates the L60TCTT4 and L60TCTT4BW. (RT) indicates the L60TCRT4 and L60TCRT4BW.
- \*6 Available only when the heating-cooling control (expanded mode) is set on Switch Setting. With other models, this area is handled as a system area.
- \*7 Available only when the mix control (expanded mode) is set on Switch Setting. With other models, this area is handled as a system area.
- \*8 Available only when the L60TCTT4 or L60TCTT4BW is used. With other models, this area is handled as a system area.
- \*9 Available only in the setting mode. To enable the setting contents, turn off, on, and on Setting change instruction (YnB) when Setting/operation mode instruction (Yn1) is off (during setting mode). Note that a write data error (error code:
- \*10 By using the setting change rate limiter, whether to set temperature rise/temperature drop in a batch or individually can be selected on Switch Setting. In the batch setting, the target of setting change rate limiter is only this area. In the individual setting, this area is the setting target for the temperature rise. For details, refer to Page 155, Section 8.2.10.
- \*11 Available only when the L60TCTT4BW or L60TCRT4BW is used. With other models, this area is handled as a system area.
- \*12 By using the setting change rate limiter, whether to set temperature rise/temperature drop in a batch or individually can be selected on Switch Setting. In the batch setting, this area is handled as a system area. In the individual setting, this area is the setting target for the temperature drop. For details, refer to Page 155, Section 8.2.10.
- \*13 Available only when the heating-cooling control (normal mode) is set on Switch Setting. With other models, this area is handled as a system area.
- \*14 Available only when the mix control (normal mode) is set on Switch Setting. With other models, this area is handled as a system area.

## (2) Buffer memory address for error history

Address (decimal (hexadecimal))	Target channel		Setting contents			Default value <sup>*1</sup>	Read/ Write *2	Automatic setting	Non- volatile memory write availability	Reference
1279(4FF <sub>H</sub> )	All CHs	Latest add	Latest address of error history			0	R	×	×	Page 415, Appendix 2 (95)
1280(500 <sub>H</sub> )			Error code							
1281(501 <sub>H</sub> )				Upper 2 digits of year	Lower 2 digits of year					Page 415,
1282(502 <sub>H</sub> )	All CHs	History 1	Error occurrence	Month	Day	0	R	×	×	Appendix 2
1283(503 <sub>H</sub> )			time	Hour	Minute					(96)
1284(504 <sub>H</sub> )				Second	Day of the week					
1285(505 <sub>H</sub> )										
to	_	System ar	System area			_	_	_	_	_
1287(507 <sub>H</sub> )										
1288(508 <sub>H</sub> )			History 2 Error code, error occurrence time (Data structure is the same as that of History 1.)							Page 415,
to	All CHs	History 2				0	R	×	×	Appendix 2 (96)
1292(50C <sub>H</sub> )									(00)	
1293(50D <sub>H</sub> )										
to	_	System ar	System area			_	_	_	_	_
1295(50F <sub>H</sub> )										
1296(510 <sub>H</sub> )	All Oll-	11:-4	Error code, e	error occurrence	time (Data		Б			Page 415,
to 1300(514 <sub>H</sub> )	All CHs	History 3	structure is the	he same as tha	t of History 1.)	0	R	×	×	Appendix 2 (96)
1301(515 <sub>H</sub> )										
to		System ar	ea				_	_	_	_
1303(517 <sub>H</sub> )		Oystein ai	ca					_	_	_
1304(518 <sub>H</sub> )										
to	All CHs	History 4		error occurrence	•	0	R	×	×	Page 415, Appendix 2
1308(51C <sub>H</sub> )			structure is the	he same as tha	t of History 1.)					(96)
1309(51D <sub>H</sub> )										
to	_	System ar	ea			_	_	_	_	_
1311(51F <sub>H</sub> )										
1312(520 <sub>H</sub> )										Page 415,
to	All CHs	History 5		error occurrence		0	R	×	×	Appendix 2
1316(524 <sub>H</sub> )		structure is the same as that of History 1.)							(96)	
1317(525 <sub>H</sub> )										
to	_	System ar	ea			_	_	_	_	_
1319(527 <sub>H</sub> )										
1320(528 <sub>H</sub> )			Error code	error oocurror	timo (Data					Page 415,
to	All CHs	History 6		error occurrence he same as that		0	R	×	×	Appendix 2
1324(52C <sub>H</sub> )										(96)

Address (decimal (hexadecimal))	Target channel		Setting contents		Read/ Write *2	Automatic setting *3	Non- volatile memory write availability	Reference
1325(52D <sub>H</sub> )								
to	_	System ar	ea	_	_	_	_	_
1327(52F <sub>H</sub> )								
1328(530 <sub>H</sub> )			Error code, error occurrence time (Data					Page 415,
to	All CHs	History 7	structure is the same as that of History 1.)	0	R	×	×	Appendix 2 (96)
1332(534 <sub>H</sub> )								(90)
1333(535 <sub>H</sub> )								
to	_	System ar	rea	_	_	_	_	_
1335(537 <sub>H</sub> )								
1336(538 <sub>H</sub> )			Error code, error occurrence time (Data					Page 415,
to	All CHs	History 8	structure is the same as that of History 1.)	0	R	×	×	Appendix 2 (96)
1340(53C <sub>H</sub> )								(00)
1341(53D <sub>H</sub> )			System area					
to	_	System ar			_	_	_	_
1343(53F <sub>H</sub> )			T					
1344(540 <sub>H</sub> )			Error code, error occurrence time (Data		_			Page 415,
to	All CHs	History 9	structure is the same as that of History 1.)	0	R	×	×	Appendix 2 (96)
1348(544 <sub>H</sub> )								(00)
1349(545 <sub>H</sub> )								
to	_	System ar	ea	_	_	_	_	_
1351(547 <sub>H</sub> )			T					
1352(548 <sub>H</sub> )	All Clie	History	Error code, error occurrence time (Data	0	R	×	×	Page 415,
to 1356(54C <sub>H</sub> )	All CHs	10	structure is the same as that of History 1.)	0	K		^	Appendix 2 (96)
1357(54D <sub>H</sub> )								
to		System ar	22					
1359(54F <sub>H</sub> )		Oystein ai	ea			_	_	_
1360(550 <sub>H</sub> )			T					
to	All CHs	History	Error code, error occurrence time (Data	0	R	×	×	Page 415, Appendix 2
1364(554 <sub>H</sub> )	7 111 01 10	11	structure is the same as that of History 1.)	Ŭ				(96)
1365(555 <sub>H</sub> )			<u> </u>					
to	_	System ar	rea	_		_	_	_
1367(557 <sub>H</sub> )								
1368(558 <sub>H</sub> )								D 445
to	All CHs	History	Error code, error occurrence time (Data	0	R	×	×	Page 415, Appendix 2
1372(55C <sub>H</sub> )		12	structure is the same as that of History 1.)					(96)
1373(55D <sub>H</sub> )			1					
to	_	System area		_	_	_	_	_
1375(55F <sub>H</sub> )		•						
1376(560 <sub>H</sub> )								Page 415,
to	All CHs	History 13			R	×	×	Appendix 2
1380(564 <sub>H</sub> )		"	Substance is the same as that of History 1.)					(96)


Address (decimal (hexadecimal))	Target channel	Setting contents		Default value <sup>*1</sup>	Read/ Write *2	Automatic setting *3	Non- volatile memory write availability	Reference
1381(565 <sub>H</sub> )								
to	_	System ar	ea	_	_	_	_	_
1383(567 <sub>H</sub> )								
1384(568 <sub>H</sub> )								Page 415,
to	All CHs	History 14	Error code, error occurrence time (Data structure is the same as that of History 1.)	0	R	×	×	Appendix 2
1388(56C <sub>H</sub> )								(96)
1389(56D <sub>H</sub> )								
to	_	System ar	ea	_	_	_	_	_
1391(56F <sub>H</sub> )								
1392(570 <sub>H</sub> )								Page 415,
to	All CHs	History 15	Error code, error occurrence time (Data structure is the same as that of History 1.)	0	R	×	×	Appendix 2
1396(574 <sub>H</sub> )		10	ordinate is the same as that of thistory 1.7					(96)
1397(575 <sub>H</sub> )								,
to	_	System ar	ea	_	_	_	_	_
1399(577 <sub>H</sub> )								
1400(578 <sub>H</sub> )								Page 415,
to	All CHs	History 16	Error code, error occurrence time (Data structure is the same as that of History 1.)	0	R	×	×	Appendix 2
1404(57C <sub>H</sub> )		10	Suddule is the same as that of filstory 1.)					(96)
1405(57D <sub>H</sub> )								
to	_	System ar	System area		_	_	_	_
4095(FFF <sub>H</sub> )								

- \*1 This default value is set after the module is turned off and on or after the CPU module is reset and the reset is cancelled.
- \*2 This column indicates whether data can be read from or written to the buffer memory area through sequence programs. R: Reading enabled
  - W: Writing enabled
- \*3 This column indicates whether the setting in the buffer memory area is automatically changed when the input range is changed. Enable/disable of automatic change can be set on Switch Setting. For details, refer to Page 234, Section 8.3.3.
- \*4 Whether writing to the non-volatile memory by turning off and on Set value backup instruction (Yn8) is enabled in this column. For details, refer to Page 235, Section 8.3.4.


## CHAPTER 4 PROCEDURE BEFORE OPERATION

This chapter describes the procedure before operating the L60TC4.

Using the module as a temperature input module



Using the module as a temperature control module



Point P

When using the L60TCTT4 and the L60TCTT4BW which use the thermocouples as the temperature sensors, temperature compensation must be executed properly. Perform warm-up operation about 15 minutes before starting operation.

## Memo


## **CHAPTER 5** SYSTEM CONFIGURATION

This chapter describes the total configuration of the L60TC4, number of connectable modules, and applicable software version.


## **5.1** Total Configuration

This section describes examples of system configurations when using the L60TC4.

#### (1) Connecting to a CPU module



#### (2) Connecting to a head module



## **5.2** Applicable Systems

#### (1) Number of connectable modules

A CPU module and a head module recognize one L60TCTT4BW or L60TCRT4BW as two modules. Therefore, number of connectable modules reduces to half of other modules.

For the number of connectable modules, refer to the following manuals.

- MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

#### (2) Applicable software version

For applicable software version, refer to the following manuals.

- MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

#### (3) Temperature sensor

For usable temperature sensors, refer to the following.

• Types of usable temperature sensor ( Page 36, Section 3.2.2)

#### (4) Current sensor for heater disconnection detection

The following table lists current sensors for heater disconnection detection available with the L60TCTT4BW or L60TCRT4BW.

Model name	Remarks	Manufacturer
CTL-12-S36-8 (0.0 to 100.0A)*1		
CTL-12-S36-10 (0.0 to 100.0A)		
CTL-12-S56-10 (0.0 to 100.0A)	_	U.R.D.Co., LTD.
CTL-6-P (0.00 to 20.00A)*1		
CTL-6-P-H (0.00 to 20.00A)		

<sup>\*1</sup> The CTL-12-S36-8 and CTL-6-P can be used although they have been discontinued.

For how to select current sensors for heater disconnection detection, refer to the following.

- Selecting a current sensor for heater disconnection detection ( Page 392, Appendix 2 (60))
- Setting of the number of second-winding of connected current sensor (Page 393, Appendix 2 (62))

## **5.3** Precautions for System Configuration

The L60TC4 measures temperature based on the temperature of the terminal block. Therefore, depending on the system configuration, temperature distribution of the terminal block can be uneven due to the effect of heat generated from modules, and the measured temperature may differ from actual temperature (especially when two or more L60TC4 modules are connected next to each other or the L60TC4 is mounted next to the power supply module or CPU module).

In this case, the difference between measured value and actual temperature can be reduced by the following methods.

#### (1) Using the sensor compensation function

The measured temperature can be corrected to the actual temperature by this function. For details on the sensor compensation function, refer to the following.

Page 223, Section 8.3.2

## **CHAPTER 6** INSTALLATION AND WIRING

This chapter describes the installation and wiring of the L60TC4.

## **6.1** Installation Environment and Installation Position

For p	recautions for installation environment and installation position, refer to the following.
	MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
	MELSEC-L CC-Link IE Field Network Head Module User's Manual

## 6.2 Terminal Block

## 6.2 Terminal Block

#### (1) Precautions

Tighten the terminal block screws within the following specified torque range.

Undertightening screws may cause module dropping, failures, or malfunction. Overtightening screws can damage the screw and/or module, resulting in module dropping, short-circuit, or malfunction.

Screw location	Tightening torque range			
Terminal screw (M3 screw)	0.42 to 0.58N • m			
Terminal block mounting screw (M3.5 screw)	0.66 to 0.89N • m			


The following table shows the applicable solderless terminal installed to the terminal block. For wiring, use the wire applicable to the following wire and mount with the applicable tightening torque. Use a UL-approved solderless terminal and tools recommended by the manufacturer of the solderless terminal. The sleeve solderless terminal cannot be used.

Solderle	ess terminal	Wire					
Model name	Applicable tightening torque	Wire diameter	Туре	Material	Temperature rating		
R1.25-3	0.42 to 0.58N • m	22 to 18 AWG	Stranded wire	Copper wire	75°C or more		

#### (2) Signal names of terminal blocks

The following shows signal names of terminal blocks.

#### (a) L60TCTT4, L60TCTT4BW (terminal block for I/O)




Terminal	Indication	Temp	erature input	Stan	dard control
number	illuication	Symbol	Name	Symbol	Name
1	OUT1	_	Unused	L1	CH1 Output
2	OUT2	_	Unused	L2	CH2 Output
3	OUT3	_	Unused	L3	CH3 Output
4	OUT4	_	Unused	L4	CH4 Output
5	COM	_	Unused	COM-	Output common
6	NC	NC	Unused	NC	Unused
7	IN1+	MT1+	Monitor 1 thermocouple +	CH1+	CH1 Thermocouple +
8	IN2+	MT2+	Monitor 2 thermocouple +	CH2+	CH2 Thermocouple +
9	IN1-	MT1-	Monitor 1 thermocouple -	CH1-	CH1 Thermocouple -
10	IN2-	MT2-	Monitor 2 thermocouple -	CH2-	CH2 Thermocouple -
11	NC	NC	Unused	NC	Unused
12	CJ	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor
13	NC	NC	Unused	NC	Unused
14	CJ	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor
15	IN3+	MT3+	Monitor 3 thermocouple +	CH3+	CH3 Thermocouple +
16	IN4+	MT4+	Monitor 4 thermocouple +	CH4+	CH4 Thermocouple +
17	IN3-	MT3-	Monitor 3 thermocouple -	CH3-	CH3 Thermocouple -
18	IN4-	MT4-	Monitor 4 thermocouple -	CH4-	CH4 Thermocouple -

Torminal		Heating-cooling control		Heating-cooling control		Mix control		Mix control	
Terminal number	Indication	(normal mode)		(expanded mode)		(normal mode)		(expanded mode)	
number		Symbol	Name	Symbol	Name	Symbol	Name	Symbol	Name
1	OUT1	L1H	CH1 Heating output	L1H	CH1 Heating output	L1H	CH1 Heating output	L1H	CH1 Heating output
2	OUT2	L1C	CH1 Cooling output	L1C	CH1 Cooling output	L1C	CH1 Cooling output	L1C	CH1 Cooling output
3	OUT3	L2H	CH2 Heating output	L2H	CH2 Heating output	L3	CH3 Output	L3	CH3 Output
4	OUT4	L2C	CH2 Cooling output	L2C	CH2 Cooling output	L4	CH4 Output	L4	CH4 Output
5	COM	COM-	Output common	COM-	Output common	COM-	Output common	COM-	Output common
6	NC	NC	Unused	NC	Unused	NC	Unused	NC	Unused
7	IN1+	CH1+	CH1 Thermocouple +	CH1+	CH1 Thermocouple +	CH1+	CH1 Thermocouple +	CH1+	CH1 Thermocouple +
8	IN2+	CH2+	CH2 Thermocouple +	CH2+	CH2 Thermocouple +	MT2+	Monitor 2 thermocouple +	CH2+	CH2 Thermocouple +
9	IN1-	CH1-	CH1 Thermocouple -	CH1-	CH1 Thermocouple -	CH1-	CH1 Thermocouple -	CH1-	CH1 Thermocouple -
10	IN2-	CH2-	CH2 Thermocouple -	CH2-	CH2 Thermocouple -	MT2-	Monitor 2 thermocouple -	CH2-	CH2 Thermocouple -
11	NC	NC	Unused	NC	Unused	NC	Unused	NC	Unused
12	CJ	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor
13	NC	NC	Unused	NC	Unused	NC	Unused	NC	Unused
14	CJ	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor	CJ	Cold junction temperature compensation resistor
15	IN3+	MT3+	Monitor 3 thermocouple +	CH3+	CH3 Thermocouple +	CH3+	CH3 Thermocouple +	CH3+	CH3 Thermocouple +
16	IN4+	MT4+	Monitor 4 thermocouple +	CH4+	CH4 Thermocouple +	CH4+	CH4 Thermocouple +	CH4+	CH4 Thermocouple +
17	IN3-	МТ3-	Monitor 3 thermocouple -	CH3-	CH3 Thermocouple -	CH3-	CH3 Thermocouple -	СН3-	CH3 Thermocouple -
18	IN4-	MT4-	Monitor 4 thermocouple -	CH4-	CH4 Thermocouple -	CH4-	CH4 Thermocouple -	CH4-	CH4 Thermocouple -



Do not remove the cold junction temperature compensation resistor from the terminal block.


#### (b) L60TCRT4, L60TCRT4BW (terminal block for I/O)




Terminal	Indication	Temperature input		Standard control		
number	indication	Symbol	Name	Symbol	Name	
1	OUT1	_	Unused	L1	CH1 Output	
2	OUT2	_	Unused	L2	CH2 Output	
3	OUT3	_	Unused	L3	CH3 Output	
4	OUT4	_	Unused	L4	CH4 Output	
5	COM	_	Unused	COM-	Output common	
6	NC	NC	Unused	NC	Unused	
7	IN1 A	MT1 A	Monitor 1 resistance thermometer A	CH1 A	CH1 Resistance thermometer A	
8	IN2 A	MT2 A	Monitor 2 resistance thermometer A	CH2 A	CH2 Resistance thermometer A	
9	IN1 B	MT1 B	Monitor 1 resistance thermometer B	CH1 B	CH1 Resistance thermometer B	
10	IN2 B	MT2 B	Monitor 2 resistance thermometer B	CH2 B	CH2 Resistance thermometer B	
11	IN1 b	MT1 b	Monitor 1 resistance thermometer b	CH1 b	CH1 Resistance thermometer b	
12	IN2 b	MT2 b	Monitor 2 resistance thermometer b	CH2 b	CH2 Resistance thermometer b	
13	IN3 A	МТЗ А	Monitor 3 resistance thermometer A	СНЗ А	CH3 Resistance thermometer A	
14	IN4 A	MT4 A	Monitor 4 resistance thermometer A	CH4 A	CH4 Resistance thermometer A	
15	IN3 B	МТЗ В	Monitor 3 resistance thermometer B	СНЗ В	CH3 Resistance thermometer B	
16	IN4 B	MT4 B	Monitor 4 resistance thermometer B	CH4 B	CH4 Resistance thermometer B	
17	IN3 b	MT3 b	Monitor 3 resistance thermometer b	СН3 b	CH3 Resistance thermometer b	
18	IN4 b	MT4 b	Monitor 4 resistance thermometer b	CH4 b	CH4 Resistance thermometer b	

Terminal Indicatio		Heating-cooling control (normal mode)		Heating-cooling control (expanded mode)		Mix control (normal mode)		Mix control (expanded mode)	
number		Symbol	Name	Symbol	Name	Symbol	Name	Symbol	Name
1	OUT1	L1H	CH1 Heating output	L1H	CH1 Heating output	L1H	CH1 Heating output	L1H	CH1 Heating output
2	OUT2	L1C	CH1 Cooling output	L1C	CH1 Cooling output	L1C	CH1 Cooling output	L1C	CH1 Cooling output
3	OUT3	L2H	CH2 Heating output	L2H	CH2 Heating output	L3	CH3 Output	L3	CH3 Output
4	OUT4	L2C	CH2 Cooling output	L2C	CH2 Cooling output	L4	CH4 Output	L4	CH4 Output
5	COM	COM-	Output common	COM-	Output common	COM-	Output common	COM-	Output common
6	NC	NC	Unused	NC	Unused	NC	Unused	NC	Unused
7	IN1 A	CH1 A	CH1 Resistance thermometer A	CH1 A	CH1 Resistance thermometer A	CH1 A	CH1 Resistance thermometer A	CH1 A	CH1 Resistance thermometer A
8	IN2 A	CH2 A	CH2 Resistance thermometer A	CH2 A	CH2 Resistance thermometer A	MT2 A	Monitor 2 resistance thermometer A	CH2 A	CH2 Resistance thermometer A
9	IN1 B	CH1 B	CH1 Resistance thermometer B	CH1 B	CH1 Resistance thermometer B	CH1 B	CH1 Resistance thermometer B	CH1 B	CH1 Resistance thermometer B
10	IN2 B	CH2 B	CH2 Resistance thermometer B	CH2 B	CH2 Resistance thermometer B	MT2 B	Monitor 2 resistance thermometer B	CH2 B	CH2 Resistance thermometer B
11	IN1 b	CH1 b	CH1 Resistance thermometer b	CH1 b	CH1 Resistance thermometer b	CH1 b	CH1 Resistance thermometer b	CH1 b	CH1 Resistance thermometer b
12	IN2 b	CH2 b	CH2 Resistance thermometer b	CH2 b	CH2 Resistance thermometer b	MT2 b	Monitor 2 resistance thermometer b	CH2 b	CH2 Resistance thermometer b
13	IN3 A	MT3 A	Monitor 3 resistance thermometer A	СНЗ А	CH3 Resistance thermometer A	СНЗ А	CH3 Resistance thermometer A	СНЗ А	CH3 Resistance thermometer A
14	IN4 A	MT4 A	Monitor 4 resistance thermometer A	CH4 A	CH4 Resistance thermometer A	CH4 A	CH4 Resistance thermometer A	CH4 A	CH4 Resistance thermometer A
15	IN3 B	МТЗ В	Monitor 3 resistance thermometer B	СНЗ В	CH3 Resistance thermometer B	СНЗ В	CH3 Resistance thermometer B	СН3 В	CH3 Resistance thermometer B
16	IN4 B	MT4 B	Monitor 4 resistance thermometer B	CH4 B	CH4 Resistance thermometer B	CH4 B	CH4 Resistance thermometer B	CH4 B	CH4 Resistance thermometer B
17	IN3 b	MT3 b	Monitor 3 resistance thermometer b	CH3 b	CH3 Resistance thermometer b	СН3 b	CH3 Resistance thermometer b	СН3 b	CH3 Resistance thermometer b
18	IN4 b	MT4 b	Monitor 4 resistance thermometer b	CH4 b	CH4 Resistance thermometer b	CH4 b	CH4 Resistance thermometer b	CH4 b	CH4 Resistance thermometer b

#### (c) L60TCTT4BW (terminal block for CT), L60TCRT4BW (terminal block for CT)






Terminal	Indication	Standard control			
number	marcation	Symbol	Name		
1	NC	NC	Unused		
2	CT1	CT1	CT input 1		
3	CT1	CT1	CT input 1		
4	CT2	CT2	CT input 2		
5	CT2	CT2	CT input 2		
6	CT3	CT3	CT input 3		
7	CT3	CT3	CT input 3		
8	CT4	CT4	CT input 4		
9	CT4	CT4	CT input 4		
10	CT5	CT5	CT input 5		
11	CT5	CT5	CT input 5		
12	CT6	CT6	CT input 6		
13	CT6	CT6	CT input 6		
14	CT7	CT7	CT input 7		
15	CT7	CT7	CT input 7		
16	CT8	CT8	CT input 8		
17	CT8	CT8	CT input 8		
18	NC	NC	Unused		


#### (3) Removal and installation of the terminal block

The following shows how to remove and install the terminal block.

#### (a) Removal procedure




 Open the terminal cover and loosen the terminal block mounting screw.




2. Using the terminal block fixing hole as a supporting point, remove the terminal block.





 Fully insert the projections on the top of the terminal block into the terminal block fixing holes of the module and press the terminal block until it snaps into place.



2. Open the terminal cover and tighten the terminal block mounting screw.

## **6.3** Wiring precautions

External wiring that is less susceptible to noise is required as a condition of enabling a highly reliable system and making full use of the capabilities of the L60TC4.

The following figure shows the wiring precautions.

- Use separate cables with the AC control circuit and the L60TC4's external input signals to avoid the influence of AC side surges and induction.
- Do not bunch the cables with the main circuit cable, high-voltage cable, or load cables from other than the programmable controller, or install them close to each other.
  - Install the cables far apart from high-frequency circuit cable, such as the high-voltage cable and inverter load main circuit, as much as possible.
  - This increases the noises, surges, and induction.
- Ground the shield line or shielded cable at one end on the programmable controller side. However, depending on the external noise condition, it should be grounded externally.

MELSEC-L CC-Link IE Field Network Head Module User's Manual

• For conformance of this product with the EMC Directive and Low Voltage Directive, refer to the following.

MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)

92


# 6.4 External wiring 6.4.1 L60TCTT4

## **6.4** External wiring

The following figure shows the external wiring.


## **6.4.1** L60TCTT4

#### (1) In the temperature input mode




\*1 Use the shielded compensation lead wire.

#### Point P




#### (2) In the temperature control mode

#### (a) In the standard control




- \*1 Use the shielded compensation lead wire.
- \*2 Use the shielded cable.

## Point P




#### (b) In the heating-cooling control




- \*1 Use the shielded compensation lead wire.
- \*2 Use the shielded cable.

#### Point P




## **6.4.2** L60TCTT4BW

#### (1) In the temperature input mode




\*1 Use the shielded compensation lead wire.

### Point P



#### (2) In the temperature control mode


#### (a) In the standard control




- \*1 Use the shielded compensation lead wire.
- \*2 Use the shielded cable.

#### Point P

- To use the heater disconnection detection function, the CT input channel assignment must be set. Since the CT1 is used
  in the loop of CH1 in the above wiring example, set CH1(1) to CT1 CT input channel assignment setting (Un\G264).
- Use the compensation lead wire for the cable of thermocouple. If the compensation lead wire is not used, and when the
  cold junction temperature compensation resistor is away from the end tip of thermocouple, the (ambient) temperature
  difference may lead to a faulty temperature process value (PV).




#### (b) In the heating-cooling control



- \*1 Use the shielded compensation lead wire.
- \*2 Use the shielded cable.


#### Point P

- To use the heater disconnection detection function, the CT input channel assignment must be set. Since the CT1 is used in the loop of CH1 in the above wiring example, set CH1(1) to CT1 CT input channel assignment setting (Un\G264).
- Use the compensation lead wire for the cable of thermocouple. If the compensation lead wire is not used, and when the cold junction temperature compensation resistor is away from the end tip of thermocouple, the (ambient) temperature difference may lead to a faulty temperature process value (PV).




## **6.4.3** L60TCRT4

#### (1) In the temperature input mode




#### (2) In the temperature control mode

#### (a) In the standard control




#### (b) In the heating-cooling control




## **6.4.4** L60TCRT4BW

#### (1) In the temperature input mode



#### (2) In the temperature control mode

#### (a) In the standard control




\*1 Use the shielded cable.

#### Point P

To use the heater disconnection detection function, the CT input channel assignment must be set. Since the CT1 is used in the loop of CH1 in the above wiring example, set CH1(1) to CT1 CT input channel assignment setting (Un\G264).

#### (b) In the heating-cooling control




\*1 Use the shielded cable.

#### Point P

To use the heater disconnection detection function, the CT input channel assignment must be set. Since the CT1 is used in the loop of CH1 in the above wiring example, set CH1(1) to CT1 CT input channel assignment setting (Un\G264).

## 6.5 Heater disconnection detection wiring and setting example for three-phase heater

The following figure shows a wiring and setting example to detect a three-phase heater disconnection by using the heater disconnection detection function.



Three-phase heater disconnection detection is executed by measuring the currents of two of the three cables. In the above wiring example, set CT CT input channel assignment setting (Un\G264 to Un\G271) as indicated below.

CT input	Buffer memory address	Set value
CT1	Un\G264	1
CT2	Un\G265	1
CT3	Un\G266	2
CT4	Un\G267	2
CT5	Un\G268	3
CT6	Un\G269	4
CT7	Un\G270	0
CT8	Un\G271	0

## 6.6 Unused Channel Setting

When no temperature sensor is connected to a channel, the L60TC4 performs upscale processing for the channel. Therefore, when a temperature sensor is not connected to a channel where no temperature control is performed, the module determines that the temperature process value (PV) has exceeded the temperature measurement range for the input range, and the ALM LED blinks.

Once the unused channel setting is configured, no alert will occur for a channel where a temperature sensor is not connected. To prevent faulty alert detection, configure the unused channel setting.

#### (1) Setting method

Set a value in CH  $\Box$  unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157).

For details on the setting, refer to the following.

Page 376, Appendix 2 (35)

The following table shows the relationship between the setting value and control status.

Set value	Control status					
Set value	PID control Temperature judgment		Alert judgment			
0: Use	The controls are performed. (However, it depends on other setting status.)					
1: Unused	The controls are not performed.					



Even if the unused channel setting is configured, the sampling cycle does not change.

# **CHAPTER 7** VARIOUS SETTINGS

This chapter describes the setting procedures of the L60TC4.



After writing the contents of the new module, switch setting, parameter setting and auto refresh setting into the CPU module, reset the CPU module, switch STOP  $\rightarrow$  RUN  $\rightarrow$  STOP  $\rightarrow$  RUN, or turn off and on the power, to enable the setting contents.


# 7.1 Addition of Modules

Add the model name of the L60TC4 to use on the project.

# (1) Addition procedure

Open the "New Module..." window.

Project window ❖ [Intelligent Function Module] ❖ Right-click ❖ [New Module...]



	Item	Description	
Module Selection	Module Type	Set "Temperature Control Module".	
Module Selection	Module Name	Select the module name to connect.	
	Mounted Slot No.	Set the slot No. where the module is connected.	
Mount Position	Specify start XY address	The start I/O number (hexadecimal) of the target module is set according to the mounted slot No An arbitrary start I/O number can be also set.	
Title Setting	Title	Set an arbitrary title.	

# 7.2 Switch Setting


Configure settings such as the output setting at CPU stop error and the control mode selection which are used in each channel.

## (1) Setting method

Open the "Switch Setting" window.

Project window ▷ [Intelligent Function Module] ▷ Module name ▷ [Switch Setting]


## (a) When using the L60TC4 as a temperature input module



Item	Description	Set value	Reference
Auto-setting at Input Range Change	Set this item to change data of the related buffer memory automatically when the input range is changed so that an error outside the setting range does not occur.	0: Disable     1: Enable	Page 234, Section 8.3.3
Sampling Cycle Selection*1	Select the sampling cycle.	• 0: 500ms (default value) • 1: 250ms	Page 117, Section 8.1.2

<sup>\*1</sup> Immediately after the setting is changed, a set value discrepancy error (error code: 0□□E<sub>H</sub>) occurs. To clear the set value discrepancy error, turn off, on, and off Set value backup instruction (Yn8).

# (b) When using the L60TC4 as a temperature control module



Item	Description	Set value	Reference
Output Setting at CPU Stop Error	Set whether to hold or clear the transistor output status when a CPU stop error occurs or when a CPU module is switched from RUN to STOP.	0: CLEAR (default value)     1: HOLD	Page 128, Section 8.2.2
Control Mode Selection*1	Set the control mode.	0: Standard Control     1: Heating/Cooling Control (Normal Mode)     2: Heating/Cooling Control (Expanded Mode)     3: Mix Control (Normal Mode)     4: Mix Control (Expanded Mode)	Page 126, Section 8.2.1
Setting Change Rate Limiter Setting	Select "batch" setting or "individual" setting for the variation limiter set value at temperature rise and drop when setting the variation of the set value (SV).	O: Temperature Rise/Temperature Drop Batch setting     1: Temperature Rise/Temperature Drop Individual setting	Page 155, Section 8.2.10
Control Output Cycle Unit Selection Setting*1	Select 0.1s or 1s as a unit for the cycle of turning on and off the transistor output.	0: 1s cycle (default value)     1: 0.1s cycle	Page 140, Section 8.2.6
Auto-setting at Input Range Change	Set this item to change data of the related buffer memory automatically when the input range is changed so that an error which is out of the setting does not occur.	0: Disable     1: Enable	Page 234, Section 8.3.3
Sampling Cycle Selection*1	Select the sampling cycle.	0: 500ms (default value)     1: 250ms	_

Immediately after the setting is changed, a set value discrepancy error (error code: 0□□E<sub>H</sub>) occurs. To clear the set value discrepancy error, turn off, on, and off Set value backup instruction (Yn8).

# 7.3 Parameter Setting

Set the parameter for each channel.


By setting parameters here, the parameter setting is not required on a program.

#### (1) Setting method

Open the "Parameter" window.

1. Start up "Parameter" on the Project window.

Project window 🗢 [Intelligent Function Module] 🗢 Module name 🗢 [Parameter]



- 2. Click Clear Value for Gray Cells to set items unnecessary for the mode set on Switch Setting to 0.
- 3. Double-click the item to change the setting, and enter the setting value.
  - Items to select from a pull-down list
     Double-click the item to set to display the pull-down list. Select the item.
  - Items to enter in a text box
     Double-click the item to set, and enter the value.

Remark

If writing is performed without setting unnecessary items for the mode set on Switch Setting to 0, a write data error (error code:  $\Box\Box\Box\Box_H$ ) may occur.

For details on setting values, refer to the following.

Operation mode	Setting item	Reference	
	Input range	Page 345, Appendix 2 (12)	
	Conversion enable/disable setting	Page 402, Appendix 2 (75)	
	Sensor correction value setting	Page 363, Appendix 2 (21)	
	Primary delay digital filter setting	Page 365, Appendix 2 (24)	
	Process value (PV) scaling function enable/disable setting	Page 405, Appendix 2 (80)	
	Process value (PV) scaling lower limit value	Dage 406 Appendix 2 (91)	
	Process value (PV) scaling upper limit value		
	Cold junction temperature compensation selection	Page 384, Appendix 2 (49)	
Temperature Input Mode	Process alarm alert output enable/disable setting	Page 387, Appendix 2 (53)	
input wode	Process alarm lower lower limit value		
	Process alarm lower upper limit value	Dago 200 Annondiy 2 (E4)	
	Process alarm upper lower limit value	Page 388, Appendix 2 (54)	
	Process alarm upper upper limit value		
	Rate alarm alert output enable/disable setting	Page 389, Appendix 2 (55)	
	Rate alarm alert detection cycle	Page 389, Appendix 2 (56)	
	Rate alarm upper limit value	Dana 200 Annondiy 0 (57)	
	Rate alarm lower limit value	Page 390, Appendix 2 (57)	

Operation mode	Setting item	Reference	
	Input range	Page 345, Appendix 2 (12)	
	Set value (SV) setting	Page 354, Appendix 2 (14)	
	Unused channel setting	Page 376, Appendix 2 (35)	
	Proportional band (P) setting/Heating control proportional band setting (Ph)	Page 355, Appendix 2 (15)	
	Cooling proportional band (Pc) setting		
	Integral time (I) setting	Page 357, Appendix 2 (16)	
	Derivative time (D) setting	Page 357, Appendix 2 (17)	
	Control output cycle setting/Heating control output cycle setting	Page 364, Appendix 2 (23)	
	Control response parameter	Page 366, Appendix 2 (25)	
	Stop Mode Setting	Page 353, Appendix 2 (13)	
	PID continuation flag	Page 381, Appendix 2 (43)	
	Forward/reverse action setting	Page 371, Appendix 2 (30)	
	Upper limit setting limiter	Page 372, Appendix 2 (31)	
	Lower limit setting limiter	1 age 372, Appendix 2 (31)	
Temperature	Setting change rate limiter or Setting change rate limiter (Temperature rise)	Page 369, Appendix 2 (28)	
control mode	Setting change rate limiter (Temperature drop)		
	Sensor correction value setting	Page 363, Appendix 2 (21)	
	Primary delay digital filter setting	Page 365, Appendix 2 (24)	
	Upper limit output limiter/Heating upper limit output limiter  Lower limit output limiter	Page 360, Appendix 2 (19)	
	Output variation limiter	Page 362, Appendix 2 (20)	
	Adjustment sensitivity (dead band) setting	Page 363, Appendix 2 (22)	
	Self-tuning setting	Page 399, Appendix 2 (72)	
	Temperature conversion setting	Page 403, Appendix 2 (76)	
	Cooling method setting	Page 404, Appendix 2 (77)	
	Cooling upper limit output limiter	Page 360, Appendix 2 (19)	
	Cooling control output cycle setting	Page 364, Appendix 2 (23)	
	Overlap/dead band setting	Page 404, Appendix 2 (78)	
	Process value (PV) scaling function enable/disable setting	Page 405, Appendix 2 (80)	
	Process value (PV) scaling lower limit value	D 400 A 11 0 (21)	
	Process value (PV) scaling upper limit value	Page 406, Appendix 2 (81)	
	Derivative action selection	Page 407, Appendix 2 (83)	

Operation mode	Setting item	Reference
mode		
	Simultaneous temperature rise group setting	Page 407, Appendix 2 (84)
	Simultaneous temperature rise AT mode selection	Page 409, Appendix 2 (87)
	Setting change rate limiter Unit time setting	Page 411, Appendix 2 (89)
	Peak current suppression control group setting	Page 412, Appendix 2 (90)
	Automatic backup setting after auto tuning of PID constants	Page 378, Appendix 2 (37)
	Cold junction temperature compensation selection	Page 384, Appendix 2 (49)
	Alert 1 mode setting to Alert 4 mode setting	Page 386, Appendix 2 (52)
	Alert set value 1 to Alert set value 4	Page 358, Appendix 2 (18)
	Alert dead band setting	Page 379, Appendix 2 (38)
	Number of alert delay	Page 379, Appendix 2 (39)
	Loop disconnection detection judgment time	Page 374, Appendix 2 (33)
	Loop disconnection detection dead band	Page 375, Appendix 2 (34)
T	Heater disconnection alert setting	Page 373, Appendix 2 (32)
Temperature Control Mode	Heater disconnection/output off-time current error detection delay count	Page 380, Appendix 2 (40)
	Heater disconnection compensation function selection	Page 381, Appendix 2 (44)
	AT Bias	Page 370, Appendix 2 (29)
	Auto tuning mode selection	Page 385, Appendix 2 (51)
	Temperature rise completion range setting	Page 380, Appendix 2 (41)
	Temperature rise completion soak time setting	Page 381, Appendix 2 (42)
	Transistor output monitor ON delay time setting	Page 382, Appendix 2 (45)
	Resolution of the manipulated value for output with another analog module	Page 384, Appendix 2 (48)
	CT monitor method switching	Page 382, Appendix 2 (46)
	CT□ CT input channel assignment setting	Page 391, Appendix 2 (59)
	CT□ CT selection	Page 392, Appendix 2 (60)
	CT□ Reference heater current value	Page 393, Appendix 2 (61)
	CT□ CT ratio setting	Page 393, Appendix 2 (62)

4. When using CH2 to CH4, follow the step 3 described earlier.

# 7.4 Auto Refresh


Buffer memory data can be transferred to specified devices using this function.

By using this auto refresh setting, reading or writing is not required on a program.

### (1) Setting method

Open the "Auto\_Refresh" window.

- 1. Start "Auto\_Refresh" on the Project window.
  - Project window ▷ [Intelligent Function Module] ▷ Module name ▷ [Auto\_Refresh]
- 2. Click the item to set, and enter the auto refresh target device.



# 7.5 Auto Tuning

For how to execute auto tuning, refer to the following.

Page 144, Section 8.2.7 (5)

# 7.6 Sensor Correction

For how to execute sensor correction, refer to the following.

Page 223, Section 8.3.2

# 8

# **CHAPTER 8** FUNCTIONS

This chapter explains the details of the L60TC4 functions and how to set each function.

For details on I/O signals and the buffer memory, refer to the following:

- Details of I/O signals (Page 323, Appendix 1)
- Details of the buffer memory ( Page 334, Appendix 2)




For the functions indicated with the icons standard and teating-cooling, or with common, the following terms are used, unless otherwise specified.

- Proportional band (P): includes heating proportional band (Ph) and cooling proportional band (Pc)
- · Manipulated value (MV): includes manipulated value for heating (MVh) and manipulated value for cooling (MVc)
- Manipulated value (MV) for output with another analog module: includes manipulated value of heating (MVh) for output with another analog module and manipulated value of cooling (MVc) for output with another analog module
- Transistor output: includes heating transistor output and cooling transistor output
- Upper limit output limiter value: includes heating upper limit output limiter value and cooling upper limit output limiter value
- · Control output cycle: includes heating control output cycle and cooling control output cycle

# 8.1 Temperature Input Mode

The L60TC4 can be used as a temperature input module using this function.



# (1) Setting method

Set the L60TC4 to the temperature input mode on Switch Setting. (Page 108, Section 7.2)

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Switch Setting]



# (2) Precaution

When resolution is "1", the temperature process value (PV) of the L60TC4 is rounded off from the actual temperature.

When the actual temperature is 1299.5°C, the temperature process value (PV) of the L60TC4 is 1300°C. To measure temperature by every 0.1°C, set resolution to "0.1". (Fig. Page 345, Appendix 2 (12)) Note that the temperature process value (PV) is not rounded off for the process alarm and rate alarm. (Fig. Page 121, Section 8.1.3 (1) (d), Page 123, Section 8.1.3 (2) (d))

# 8.1.1 Conversion enable/disable function




Temperature conversion can be enabled or disabled for each channel using this function. By disabling unused channels, unnecessary disconnection detection or alert output can be prevented.

# (1) Setting method

Set "Conversion enable/disable setting" to "0: Enable".

Project window <> [Intelligent Function Module] <> Module name <> [Parameter]



# **8.1.2** Temperature conversion method



In the L60TC4, a measured value is stored into CH $\square$  Temperature process value (PV) (Un\G9 to Un\G12) in every sampling cycle. In addition, the use of the primary delay digital filter smoothens the temperature process value (PV), and its drastic change can be absorbed.


## (1) Sampling cycle

A sampling cycle can be selected from 250ms or 500ms.

#### (a) How to set the sampling cycle

Select a sampling cycle on "Sampling Cycle Selection".

Project window ⇔ [Intelligent Function Module] ⇔ Module name ⇔ [Switch Setting]




#### (b) How to check the sampling cycle


The selected sampling cycle can be checked in Sampling cycle monitor (Un\G788).

# (2) Primary delay digital filter

The primary delay digital filter smoothens extreme noise before outputting the temperature process value (PV).




For the primary delay digital filter, set the time until the temperature process value (PV) changes by 63.3% (time constant).



#### (a) How to set the primary digital filter


In "Primary delay digital filter setting", set the time until the temperature process value (PV) changes by 63.3% (time constant).

Project window 🖒 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]



Ex. When 3(3s) is set in "Primary delay digital filter setting"

The change shown below will happen if the Temperature process value (PV) changes from 250°C to 260°C under the condition where 3(3s) is set in "Primary delay digital filter setting".



The temperature reaches 256.3 °C which is 63.3% of the temperature process value (PV) three seconds after the temperature input value reached 260.0 °C.

# **8.1.3** Alert output function



An alert can be output when the temperature process value (PV) meets the condition set in advance using this function. Use this function to activate danger signals of devices or safety devices.

There are two types of alert: process alarm and rate alarm.

#### (1) Process alarm

An alert occurs when the temperature process value (PV) reaches the process alarm upper upper limit value or more, or the process alarm lower lower limit value or less.

The alert is cleared when the process value reaches a value less than the process alarm upper lower limit value, or a value more than the process alarm lower upper limit value. An alert is not cleared even by resetting the error or switching to the setting mode.

#### (a) Checking the alert occurrence


When an alert occurs, CH $\square$  Alert occurrence flag (XnC to XnF) turns on, and the ALM LED turns on. In CH $\square$  Alert definition (Un\G5 to Un\G8), whether it is an upper limit alert or lower limit alert can be checked. (Fig. Page 336, Appendix 2 (3))

#### (b) Checking the alert clearance

CH Process alarm upper limit (b2 of Un\G5 to Un\G8) or CH Process alarm lower limit (b3 of Un\G5 to Un\G8) becomes 0 (OFF). Also, CH Alert occurrence flag (XnC to XnF) turns off, and the ALM LED turns off.




In CH $\square$  Alert occurrence flag (XnC to XnF) and on the ALM LED, the alert is not cleared when an alert other than the process alarm is occurring.



#### (c) How to set process alarm

Set "Process alarm alert output enable/disable setting" to "0: Enable". Then, set the lower lower limit value, lower upper limit value, upper lower limit value, and upper upper limit value of the process alarm.

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Parameter]



## (d) Precaution

When resolution is "1", the temperature process value (PV) of the L60TC4 is rounded off from the actual temperature. For the process alarm also, the temperature process value (PV) rounded off from the actual temperature determines the alert occurrence.

#### (2) Rate alarm

The temperature process value (PV) is monitored every rate alarm alert detection cycle. An alert occurs when the change from the previous monitoring is greater than the rate alarm upper limit value, or smaller than the rate alarm lower limit value. The rate alarm is helpful to monitor the change of the temperature process value (PV) in a limited range.

```
PV Present value - PV Previous value ≥ Rate alarm upper limit value
PV Present value - PV Previous value ≤ Rate alarm lower limit value
```

The alert is cleared when the temperature process value reaches within the range of the formulas above. An alert is not cleared even by resetting the error or switching to the setting mode.

#### (a) Checking the alert occurrence

While the rate alarm is occurring, CH□ Alert occurrence flag (XnC to XnF) turns on, and the ALM LED turns on. \*1

In CH $\square$  Alert definition (Un\G5 to Un\G8), whether it is an upper limit alert or lower limit alert can be checked. (FP Page 336, Appendix 2 (3))


\*1 The ALM LED prioritizes the detection of other errors for which the ALM LED flashes (such as the detection of loop disconnection).

#### (b) Checking the alert clearance

CH□ Rate alarm upper limit (b4 of Un\G5 to Un\G8) or CH□ Rate alarm lower limit (b5 of Un\G5 to Un\G8) becomes 0 (OFF). Also, CH□ Alert occurrence flag (XnC to XnF) turns off, and the ALM LED turns off.




In CH $\square$  Alert occurrence flag (XnC to XnF) and on the ALM LED, the alert is not cleared when an alert other than the rate alarm is occurring.



# (c) How to set rate alarm

Set "Rate alarm alert output enable/disable setting" to "0: Enable". Then, set the alert detection cycle, upper limit value, and lower limit value of the rate alarm.


Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]




#### (d) Precaution

When resolution is "1", the temperature process value (PV) of the L60TC4 is rounded off from the actual temperature. For the rate alarm also, the temperature process value (PV) rounded off from the actual temperature determines the alert occurrence.


Ex. A setting example of the rate alarm upper limit value and lower limit value to monitor that the temperature process value (PV) is rising within the specified range



Ex. A setting example of the rate alarm upper limit value and lower limit value to monitor that the temperature process value (PV) is falling within the specified range




Ex. A setting example of the rate alarm upper limit value and lower limit value to monitor that the temperature process value (PV) is changing within the specified range




# **8.2** Temperature Control Mode

The L60TC4 can be used as a temperature control module using this function.

· Standard control (heating)



· Heating-cooling control (heating and cooling)



# (1) Setting method

Set the L60TC4 to the temperature control mode on Switch Setting. (FP Page 108, Section 7.2)

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Switch Setting]



# 8.2.1 Control Mode Selection Function



A control mode can be selected using this function.

This section explains selectable control modes of the L60TC4.

## (1) Standard control and heating-cooling control

There are two types of control modes in the L60TC4: standard control and heating-cooling control.

#### (a) Standard control

The control method is either one of heating (reverse action) or cooling (forward action). When the control method is heating, of a heater for example, cooling is controlled by simply turning off the heating. When the control method is cooling, of cold water for example, heating is controlled by simply turning off the cooling.

#### (b) Heating-cooling control

The control method is both heating and cooling. To heat up the target subject, its heating mean is turned on, and its cooling mean is turned off. To cool down the target subject, its heating mean is turned off, and its cooling mean is turned on.

### (2) Selectable control mode

A control mode can be selected from five modes.

Select the control mode on Switch Setting.

For details on the setting method, refer to the following.

Page 108, Section 7.2

Control mode	Contents	Number of controllable loops
Standard control	Performs the standard control of four channels	Standard control 4 loops
Heating-cooling control (normal mode)	Performs the heating-cooling control. CH3 and CH4 cannot be used.	Heating-cooling control 2 loops
Heating-cooling control (expanded mode)	Performs the heating-cooling control. The number of loops is expanded using an output module and others in the system.	Heating-cooling control 4 loops
Mix control (normal mode)	Performs the standard control and the heating-cooling control. CH2 cannot be used.	Standard control 2 loops Heating-cooling control 1 loop
Mix control (expanded mode)	Performs the standard control and the heating-cooling control. The number of loops is expanded using an output module and others in the system.	Standard control 2 loops Heating-cooling control 2 loops

Control for each channel is as follows.


Channel	Standard Heating-co		oling control	Mix control	
	control	Normal mode	Expanded mode	Normal mode	Expanded mode
CH1	Standard control	Heating-cooling control	Heating-cooling control	Heating-cooling control	Heating-cooling control
CH2	Standard control	Heating-cooling control	Heating-cooling control	*1	Heating-cooling control*2
CH3	Standard control	*1	Heating-cooling control*2	Standard control	Standard control
CH4	Standard control	*1	Heating-cooling control*2	Standard control	Standard control

<sup>\*1</sup> Only temperature measurement using a temperature input terminal can be performed. (FF Page 212, Section 8.2.23)

<sup>\*2</sup> Heating-cooling control is performed using an output module in the system. (FP Page 127, Section 8.2.1 (3))

## (3) Expanded mode

In the heating-cooling control (expanded mode) or the mix control (expanded mode), the number of loops for heating-cooling control can be expanded using an output module and others in the system. To use an expanded mode, construct a system such as the one shown below.





When the heating-cooling control (expanded mode) is selected, heating/cooling transistor output of CH3 and CH4 are activated. Also, when the mix control (expanded mode) is selected, heating/cooling transistor output of CH2 is activated. These areas are activated only when an expanded mode is selected. When a normal mode is selected, these areas are used for the system. If data is written into these areas when it is used by the system, a write data error occurs. (error  $code: \Box\Box\Box\Box_{H}$ )

The following is an example of using an expanded mode.

A program in which CH3 Heating transistor output flag (b0 of Un\G23) is assigned to Y20 of an output module (The start I/O number of the L60TC4 is set to 10 in the following program example.)

```
U1\G23.0 (Y20 )
```

# 8.2.2 Control output setting at CPU stop error



When a stop error occurs on the CPU module or when CPU's status is changed from RUN to STOP, whether to hold or clear the status of transistor output can be selected using this function.

Configure "Output Setting at CPU Stop Error" on Switch Setting.

For details on the setting method, refer to the following.

Page 108, Section 7.2

Processing for each status is describes in the following table.

Status		Processing				Reference
Output Setting at CPU Stop Error		CLEAR HO		OLD	Page 108, Section 7.2	
Setting of PID continuation flag (Un\G169)		Stop	Continue	Stop	Continue	Page 381, Appendix 2 (43)
	L60TC4 Write data error	Follow the operation of when an error occurs				Page 315, Section 11.6
Error	L60TC4 Hardware error	Depends on the symptom of the hardware				_
	CPU Stop error	Stops the operation external output	on and turns off	Follows the stop mode setting*1	Stops the operation and performs external output	_
CPU operation	$RUN \to STOP$	Follows the stop mode setting*1	Stops the operation and performs external output	Follows the stop mode setting*1	Stops the operation and performs external output	_
	Resetting	The module is inc	apable to operate,	and not performs ex	ternal output	_

<sup>\*1</sup> CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) ([ ] Page 353, Appendix 2 (13))

#### Important

- Fully pay attention to the setting of PID continuation flag (Un\G169) which controls external output.
- By the failure of an output element or internal circuit, an abnormal output may occur. Construct a circuit to monitor output signals that could cause a serious accident.

# 8.2.3 Control method



The following control methods can be applied by setting the proportional band (P), integral time, and derivative time(D).

- Two-position control ( Page 129, Section 8.2.3 (1))
- P control ( Page 131, Section 8.2.3 (2))
- PI control ( Page 132, Section 8.2.3 (3))
- PD control ( Page 133, Section 8.2.3 (4))
- PID control ( Page 133, Section 8.2.3 (5))



For P control and PD control, the manual reset function is activated. (FP Page 137, Section 8.2.4)

## (1) Two-position control

Two-position control is a control method that uses 0% manipulated value (MV) and 100% manipulated value (MV). Turning on and off the manipulated value (MV) repeatedly, the temperature process value comes close to the set value (SV), then is kept constant.




By the setting in CH $\square$  Adjustment sensitivity (dead band) setting (Un\G46, Un\G78, Un\G110, Un\G142) the chattering of transistor output under two-position control can be prevented. Set a dead band toward the set value (SV) in CH $\square$  Adjustment sensitivity (dead band) setting (Un\G46, Un\G78, Un\G110, Un\G142). ( $\square$  Page 363, Appendix 2 (22))

#### (a) Standard control

The module operates as follows outside the range of CH $\square$  Adjustment sensitivity (dead band) setting (Un\G46, Un\G78, Un\G110, Un\G142).


Condition	Transistor output status
The temperature process value (PV) is below the lower limit of the adjustment sensitivity (dead band).	ON
The temperature process value (PV) is above the upper limit of the adjustment sensitivity (dead band).	OFF



# (b) Heating-cooling control

The module operates as follows outside the range of CH $\square$  Adjustment sensitivity (dead band) setting (Un\G46, Un\G78, Un\G110, Un\G142).

Condition	Heating transistor output status	Cooling transistor output status
The temperature process value (PV) is below the lower limit of the adjustment sensitivity (dead band).	ON	OFF
The temperature process value (PV) is above the upper limit of the adjustment sensitivity (dead band).	OFF	ON



#### (c) Three-position control

Three-position control can also be performed by setting a dead band.


For more details, refer to the following.

Page 211, Section 8.2.22 (3)

# (d) Setting method

Set "Proportional band (P) setting/Heating control proportional band setting (Ph)" to 0.0%.

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]




# (2) P Control

P control is a control method in which the manipulated value (MV) is determined proportional to the deviation (E) between the temperature process value (PV) and set value (SV).

#### (a) Standard control

The manipulated value is 50% in the following conditions.

- Temperature process value (PV) = Set value (SV)
- CHI Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772) is set to 0 (0.0%). (Fig. Page 405, Appendix 2 (79))




- The value actually output is within the output limiter range set in CH□ Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140). (☐ Page 362, Appendix 2 (20))
- \*2 The set value (SV) is in the center of the proportional band.

#### (b) Heating-cooling control

The manipulated value for heating (MVh) and the manipulated value for cooling (MVc) are both 0% in the following conditions.

- Temperature process value (PV) = Set value (SV)
- CHI Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772) is set to 0 (0.0%). (FF Page 405, Appendix 2 (79))




\*1 The value actually output is within the output limiter range set in CH□ Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140). (☐ Page 362, Appendix 2 (20))

# (c) Setting method

Set each item as follows.

- "Proportional band (P) setting/Heating control proportional band setting (Ph)" : any value
- "Integral time (I) setting": 0s
- "Derivative time (D) setting": 0s
  - Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



### (3) PI Control


PI control is a control method in which integral elements are added to P control, and an offset (remaining deviation) is compensated. By setting the integral time (I) properly, the temperature process value (PV) and the set value (SV) can be met.

PI control is a control method in which integral elements are added to P control, thereby an offset (remaining deviation) is compensated. By setting the integral time (I) properly, the temperature process value (PV) matches with the set value (SV)

#### (a) Setting method

Set each item as follows.

- "Proportional band (P) setting/Heating control proportional band setting (Ph)" : any value
- "Integral time (I) setting": any value
- "Derivative time (D) setting": 0s
  - Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]




## (4) PD Control

PD control is a control method in which the derivative time (D) is set in addition to PD control. The control mechanism is the same as P control.

#### (a) Setting method

Set each item as follows.

- "Proportional band (P) setting/Heating control proportional band setting (Ph)": any value
- "Integral time (I) setting": 0s
- "Derivative time (D) setting": any value
  - Project window 🖒 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]




## (5) PID Control

PID control is a control method in which derivative elements are added to PI control, thereby the temperature shifts to a stable status in a short period of time even when a drastic change has occurred. By setting the derivative time (D) properly, the control subject shifts to a stable status in a short period of time.

### (a) Setting method

Set any value to "Proportional band (P) setting/Heating control proportional band setting (Ph)", "Integral time (I) setting", and "Derivative time (D) setting".

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



## (6) Condition to perform PID control

The condition to be able to perform PID control\*1 depends on the settings of the followings.

- Setting/operation mode instruction (Yn1) (FP Page 330, Appendix 1.2 (1))
- PID continuation flag (Un\G169)) (FPage 381, Appendix 2 (43))
- CH□ PID control forced stop instruction (YnC to YnF) ( Page 333, Appendix 1.2 (7))
- CH Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) (FPage 353, Appendix 2 (13))

The following table shows the relationship between the status of PID control\*1 and each of the settings above.

O: Performed ×: Not performed

Setting/operation mode instruction (Yn1)*2	PID continuation flag (Un\G169)	CH□ PID control forced stop instruction (YnC to YnF)	CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129)	Control status of PID control*1
Setting mode at power-ON	Stop (0)/Continue (1)	OFF/ON	Stop (0)/Monitor (1)/Alert (2)	×
Operation mode	Stop (0)/Continue (1)	OFF	Stop (0)/Monitor (1)/Alert (2)	0
(operating)	(1)	ON	Stop (0)/Monitor (1)/Alert (2)	×
	Stop (0)	OFF/ON	Stop (0)/Monitor (1)/Alert (2)	×
Setting mode (after operation)	Continue (1)	OFF	Stop (0)/Monitor (1)/Alert (2)	0
	Continue (1)	ON	Stop (0)/Monitor (1)/Alert (2)	×

<sup>\*1</sup> Here, this is the generic term for two-position control, P control, PI control, PD control, and PID control.

Even though the conditions above are met, PID control is not performed when CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1). ([☐F Page 376, Appendix 2 (35))



The manipulated value (MV) and manipulated value (MV) for output with another analog module of when CH□ PID control forced stop instruction (YnC to YnF) is turned on from off are as follows.

Buffer memory area name	В	uffer mem	ory addres	ss	Stored value	Reference	
Buller memory area name	CH1	CH2	СНЗ	CH4	Stored value	Reference	
CH□ Manipulated value (MV)	Un\G13	Un\G14	Un\G15	Un\G16	-50 (-5.0%)	Page 339, Appendix 2 (5)	
CH□ Manipulated value (MV) for output with another analog module	Un\G177	Un\G178	Un\G179	Un\G180	0	Page 383, Appendix 2 (47)	
CH□ Manipulated value for heating (MVh) (Un\G13 to Un\G16)	Un\G13	Un\G14	Un\G15	Un\G16	-50 (-5.0%)	Page 339, Appendix 2 (5)	
CH□ Manipulated value of heating (MVh) for output with another analog module	Un\G177	Un\G178	Un\G179	Un\G180	0	Page 383, Appendix 2 (47)	
CH□ Manipulated value for cooling (MVc)	Un\G704	Un\G705	Un\G706	Un\G707	-50 (-5.0%)	Page 339, Appendix 2 (5)	
CH□ Manipulated value of cooling (MVc) for output with another analog module	Un\G708	Un\G709	Un\G710	Un\G711	0	Page 383, Appendix 2 (47)	

When  $CH\square$  PID control forced stop instruction (YnC to YnF) is turned off from on, the forced stop of PID control is released. PID operation resumes with the manipulated value (MV) which was being output when the PID control was forcibly stopped.

<sup>\*2</sup> For the timing of each, refer to Page 324, Appendix 1.1 (2)

# (7) Buffer memory areas related to control method

The following table shows the buffer memory areas related to control method.

Duffa	Вι	ıffer mem	ory addre	ess	Setting range						
Buffer memory area name	CH1	CH2	СНЗ	CH4	Two- position control	P control	PD control	PI control	PID control	Reference	
CH□ Input range	Un\G32	Un\G64	Un\G96	Un\G128	Thermocoupl 117, 130 to 1 Platinum resi 143, 201 to 2	Page 345, Appendix 2 (12)					
CH□ Set value (SV) setting	Un\G34	Un\G66	Un\G98	Un\G130		Set a value within the temperature measurement range of the set input range					
CH□ Proportional band (P) setting	Un\G35	Un\G67	Un\G99	Un\G131	Fix the	Configure the setting in the range from 0 to 10000 (0.0% to 1000.0%) toward the full scale of the set input range.  Configure the setting in the range from 1 to 10000 (0.1% to 1000.0%) toward the full scale of the set input range.				Page 355, Appendix 2 (15)	
CH□ Heating proportional band (Ph) setting	Un\G35	Un\G67	Un\G99	Un\G131	setting to 0.						
CH□ Cooling proportional band (Pc) setting	Un\G720	Un\G736	Un\G752	Un\G768	The setting is ignored*1						
CH□ Integral time (I) setting	Un\G36	Un\G68	Un\G100	Un\G132	The setting is ignored*1	Fix the setting to 0.	Fix the setting to 0.	1 to 3600 (s)	1 to 3600 (s)	Page 357, Appendix 2 (16)	
CH□ Derivative time (D) setting	Un\G37	Un\G69	Un\G101	Un\G133	The setting is ignored*1	Fix the setting to 0.	1 to 3600 (s)	Fix the setting to 0.	1 to 3600 (s)	Page 357, Appendix 2 (17)	
CH□ Upper limit output limiter	Un\G42	Un\G74,	Un\G106	Un\G138		50 to 405	- Page 360, Appendix 2 (19)				
CH□ Lower limit output limiter	Un\G43	Un\G75	Un\G107	Un\G139		-50 to 1050 (-5.0% to 105.0%)  0 to 1050 (0.0% to 105.0%)					
CH□ Heating upper limit output limiter	Un\G42	Un\G74	Un\G106	Un\G138	The setting is ignored*1						
CH□ Cooling upper limit output limiter	Un\G721	Un\G737	Un\G753	Un\G769		0 10 1030					
CH□ Output variation limiter setting	Un\G44	Un\G76	Un\G108	Un\G140	The setting is ignored*1	1 to 1000	Page 362, Appendix 2 (20)				
CH□ Adjustment sensitivity (dead band) setting	Un\G46	Un\G78	Un\G110	Un\G142	Configure the setting in the range from 1 to 100 (0.1% to 10.0%) toward the full scale of the set input range.	The setting is ignored <sup>*1</sup>				Page 363, Appendix 2 (22)	

Buffer	Вι	ıffer mem	ory addre	ss						
memory area name	CH1	CH2	СНЗ	CH4	Two- position control	P PD control		PI control	PID control	Reference
CH□ Control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143		The control output cycle unit selection				
CH□ Heating control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	The setting is ignored*1	setting on Switch Setting is 1s: 1 to 100 (1s to 100s)  • The control output cycle unit selection setting on Switch Setting is 0.1s: 5 to				Page 364, Appendix 2 (23)
CH□ Cooling control output cycle setting	Un\G722	Un\G738	Un\G754	Un\G770		_	.5s to 100.0	· ·		
CH□ Overlap/dead band setting	Un\G723	Un\G739	Un\G755	Un\G771	Configure the 10.0% to 10.0 range.	Page 404, Appendix 2 (78)				
CH□ Manual reset amount setting	Un\G724	Un\G740	Un\G756	Un\G772	The setting is ignored*1	Configure setting in the from -1000 (-100.0 to toward the of the set range.	the range 0 to 1000 100.0%) e full scale	The setting	g is	Page 405, Appendix 2 (79)

<sup>\*1</sup> When outside the setting range, a write data error (error code: □□□4<sub>H</sub>) occurs.



The L60TC4 automatically sets optimum PID constants if the following functions are used.

- Auto tuning function (Page 141, Section 8.2.7)
- Self-tuning function (FP Page 175, Section 8.2.15)

# 8.2.4 Manual Reset Function



The position of the stable condition in P control or PD control can be shifted manually using this function.

By shifting the proportional band (P), an offset (remaining deviation) is manually reset.

The offset is reset by determining and setting the amount to shift the value of the manipulated value (MV) in a stable condition from the reference value.

The reference value is 50% for standard control, and 0% for heating-cooling control.




This function can be active only in P control and PD control. This function is inactive when integral time (I) is other than 0. CH $\square$  Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772) is ignored even if it is set. (Note that a write data error (error code:  $\square$  $\square$  $\square$ 4<sub>H</sub>) occurs if it is outside the setting range.)

# (1) Standard control

The set value (SV) is set where the manipulated value (MV) is 50%. Due to this, as long as the temperature process value (PV) and the set value (SV) is not in equilibrium at 50% of manipulated value, an offset (remaining deviation) generates.

When an offset generates, the proportional band (P) can be manually shifted by the amount of the offset (remaining deviation).

- Ex. When using the manual reset function in the following conditions
- Control method: P control
- CHI Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772): 300 (30%)
   The L60TC4 shifts the manipulated value (MV) by which the temperature is stabilized at the set value (SV) from 50% to 80%.




## (2) Heating-cooling control

The set value (SV) is set where the manipulated value for heating (MVh)/manipulated value for cooling (MVc) is 0%. Due to this, as long as the temperature process value (PV) and the set value (SV) is not in equilibrium at 0% of manipulated value for heating (MVh)/manipulated value for cooling (MVc), an offset (remaining deviation) generates. When an offset generates, the heating proportional band (Ph)/cooling proportional band (Pc) can be manually shifted by the amount of the offset (remaining deviation).

- Ex. When using the manual reset function in the following conditions
  - Control method: P control
     CH□ Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772): 800 (80%)

     The L60TC4 shifts the manipulated value for heating (MVh) by which the temperature is stabilized at the set value (SV) from 0% to 80%.



#### (3) Setting method

Set a value in the following buffer memory area.

• CH□ Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772) (☐ Page 405, Appendix 2 (79))

# 8.2.5 Manual Control



Manual control is a form of control for which the user sets the manipulated value (MV) manually instead of obtaining it automatically by PID control.

The manipulated value (MV) is checked every 250ms or 500ms<sup>\*1</sup>, and is reflected to transistor output.

\*1 This depends on the setting in "Sampling Cycle Selection". (Fig. Page 109, Section 7.2 (1) (b))

#### (1) Setting method

Follow the following procedure for setting.

- 1. Shift to the MAN (manual) mode. (Set MAN (1) in CH□ AUTO/MAN mode shift (Un\G50, Un\G82, Un\G114, Un\G146).) (☐ Page 367, Appendix 2 (26))
- 2. Set the manipulated value (MV) in CH□ MAN output setting (Un\G51, Un\G83, Un\G115, Un\G147)\*1 (□ Page 368, Appendix 2 (27))
- \*1 The setting range differs for standard control and heating-cooling control. Standard control: -50 to 1050 (-5.0% to 105.0%)

  Heating-cooling control: -1050 to 1050 (-105.0% to 105.0%)

# 8.2.6 Control output cycle unit selection function



The unit of the control output cycle can be selected from 1s or 0.1s using this function.

When the control output cycle is set in 0.1s, control can be more attentive.

The control output cycle is the ON/OFF cycle of transistor output for the temperature control function.


The cycle can be set in the following buffer memory areas.

Control mode	Buffer memory area name	В	uffer mem	Reference		
Control mode	Duner memory area name	CH1	CH2	CH3	CH4	Keierence
Standard control	CH□ Control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	
Heating-cooling control	CH□ Heating control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	Page 364, Appendix 2 (23)
			Un\G738	Un\G754	Un\G770	

## (1) Setting method

Select 1s cycle or 0.1s cycle in "Control Output Cycle Unit Selection Setting".

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Switch Setting]



# Point P

- The setting range and default value of the control output cycle depends on this setting. (Fig. Page 364, Appendix 2 (23))
- A setting value discrepancy error (error code: 002EH) occurs right after changing this setting. To recover from the error status, turn Set value backup instruction (Yn8) as follows: OFF→ON→OFF. Then, register the setting after the change to the L60TC4.

# **8.2.7** Auto tuning function




The auto tuning function is designed for the L60TC4 to set the optimum PID constants automatically. In auto tuning, the PID constants are calculated according to the hunting cycle and amplitude generated by repeated overshoot and undershoot of the manipulated value (MV) toward the set value (SV).

# (1) Auto tuning operation

The L60TC4 operates as follows:

	Operation of the L60TC4							
1	Outputs for auto-tuning							
2	Collects data from the point when the temperature process value (PV) reaches the set value (SV) after the first overshoot and undershoot							
3	After data collection, auto tuning ends when PID constants and loop disconnection detection judgment time are set.							



## (2) Buffer memory areas related to auto tuning

Auto tuning can be executed when the following data are set.

Note that other data must be preset to the values used for actual operation since actual control starts on completion of auto tuning.

When "0" is set to the proportional band (P)/heating proportional band (Ph), auto tuning is not executed.

(Frage 355, Appendix 2 (15))

Buffer memory area name		Buffer mem	Reference		
Buller memory area name	CH1	CH2	CH3	CH4	Reference
CH□ Input range	Un\G32	Un\G64	Un\G96	Un\G128	Page 345, Appendix 2 (12)
CH□ Set value (SV) setting	Un\G34	Un\G66	Un\G98	Un\G130	Page 354, Appendix 2 (14)
CH□ Upper limit output limiter	Un\G42	Un\G74	Un\G106	Un\G138	
CH□ Lower limit output limiter	Un\G43	Un\G75	Un\G107	Un\G139	Dogo 260 Annondiy 2 (10)
CH□ Heating upper limit output limiter	Un\G42	Un\G74	Un\G106	Un\G138	- Page 360, Appendix 2 (19)
CH□ Cooling upper limit output limiter	Un\G721	Un\G737	Un\G753	Un\G769	
CH□ Output variation limiter setting	Un\G44	Un\G76	Un\G108	Un\G140	Page 362, Appendix 2 (20)
CH□ Sensor correction value setting	Un\G45	Un\G77	Un\G109	Un\G141	Page 363, Appendix 2 (21)
CH□ Control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	
CH□ Heating control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	Page 364, Appendix 2 (23)
CH□ Cooling control output cycle setting	Un\G722	Un\G738	Un\G754	Un\G770	
CH□ Primary delay digital filter setting	Un\G48	Un\G80	Un\G112	Un\G144	Page 365, Appendix 2 (24)
CH□ AUTO/MAN mode shift	Un\G50	Un\G82	Un\G114	Un\G146	Page 367, Appendix 2 (26)
CH□ AT bias	Un\G53	Un\G85	Un\G117	Un\G149	Page 370, Appendix 2 (29)
CH□ Forward/reverse action setting	Un\G54	Un\G86	Un\G118	Un\G150	Page 371, Appendix 2 (30)
CH□ Auto tuning mode selection	Un\G184	Un\G185	Un\G186	Un\G187	Page 385, Appendix 2 (51)

## (3) Storing the calculated value after auto tuning

After auto tuning is completed, the calculated values are stored into the following buffer memory areas.

Buffer memory area name		Buffer mem	Reference		
Bullet memory area name	CH1	CH2	CH3	CH4	Neierence
CH□ Proportional band (P) setting	Un\G35	Un\G67	Un\G99	Un\G131	
CH□ Heating proportional band (Ph) setting	Un\G35	Un\G67	Un\G99	Un\G131	Page 355, Appendix 2 (15)
CH□ Cooling proportional band (Pc) setting	Un\G720	Un\G736	Un\G752	Un\G768	
CH□ Integral time (I) setting	Un\G36	Un\G68	Un\G100	Un\G132	Page 357, Appendix 2 (16)
CH□ Derivative time (D) setting	Un\G37	Un\G69	Un\G101	Un\G133	Page 357, Appendix 2 (17)
CH□ Loop disconnection detection judgment time*1	Un\G59	Un\G91	Un\G123	Un\G155	Page 374, Appendix 2 (33)

<sup>\*1</sup> A value twice greater than the one in CHD Integral time (I) setting (Un\G36, Un\G68, Un\G100, Un\G132) is automatically set. However, if this setting is 0(s) when auto tuning is in process, the loop disconnection detection judgment time is not stored.

# (4) Backup of the calculated value on completion of auto tuning

By setting the following buffer memory area to Enable (1) at the start of auto tuning, the calculated value (Fig. Page 142, Section 8.2.7 (3)) is automatically backed up into a non-volatile memory on completion of auto tuning.

• CHI Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159) (FP Page 378, Appendix 2 (37))

To read the calculated value (Page 142, Section 8.2.7 (3)) from the non-volatile memory, set the following buffer memory area to Requested (1).

• CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) ([☐FPage 377, Appendix 2 (36))



To use the PID constants stored in the buffer memory also after the power is turned off, follow the methods below.

- Use the initial setting of GX Works2. (FP Page 110, Section 7.3)
- Keep the PID constants in the non-volatile memory, and transfer them when the power is turned on from off or when the CPU module is released from the reset status. ( Page 235, Section 8.3.4)
- Write the value directly into the buffer memory through a program.

# (5) Procedure of auto tuning


# (a) GX Works2

Start from "Auto Tuning...".

(Tool) ⇒ [Intelligent Function Module Tool] ⇒ [Temperature Control Module] ⇒ [Auto Tuning...]




Select the module by which auto tuning is executed,
 and click OK




2. Click the "Auto Tuning Setting" tab.

(To the next page)



(From the previous page)


3. Configure the auto tuning setting.




4. Click Change Setting .




5. Click Yes






6. Click Change Mode.

 $\downarrow$ 



7. Click <u>Yes</u>.




**8.** Click the "Auto Tuning Execution" tab.

(To the next page)




`↓




9. Click start of the channel where auto tuning is to be executed.



**10.** Click Yes .




11. Check that "Status" has changed from "Executing" to "Tuned", and click Close



12. Click OK .

# (b) Program

The execution procedure of auto tuning is as follows.



# (6) Conditions where auto tuning cannot be executed

If one of the following conditions applies, auto tuning cannot be executed.

	Conditions to start auto tuning	Reference	
1	The module is in the setting mode (Setting/operation mode status (Xn1): OFF).	Page 324, Appendix 1.1 (2)	
2	In standard control, CH $\square$ Proportional band (P) setting (Un\G35, Un\G67, Un\G99, Un\G131) is set to 0. (operating in two-position control)	Page 355, Appendix 2 (15)	
2	In heating-cooling control, CH□ Heating proportional band (Ph) setting (Un\G35, Un\G67, Un\G99, Un\G131) is set to 0. (operating in two-position control)	1 rage 333, Appendix 2 (13)	
3	CH□ AUTO/MAN mode shift (Un\G50, Un\G82, Un\G114, Un\G146) is set to MAN (1).	Page 367, Appendix 2 (26)	
4	Toward the corresponding channel, CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1).	Page 376, Appendix 2 (35)	
5	CH□ PID control forced stop instruction (YnC to YnF) is turned on.	Page 333, Appendix 1.2 (7)	
6	Hardware failure has occurred. (The ERR. LED is on.)	Page 310, Section 11.3.2	
7	CH□ Temperature process value (PV) (Un\G9 to Un\G12) has exceeded the temperature measurement range (CH□ Input range upper limit (b0 of Un\G5 to Un\G8) or CH□ Input range lower limit (b1 of Un\G5 to Un\G8) is 1 (ON)).	Page 336, Appendix 2 (3)	
8	CHI Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) is set to Requested (1).	Page 377, Appendix 2 (36)	
9	CH□ Write completion flag (b4 to b7 of Un\G31) is on.	Page 343, Appendix 2 (11)	

# (a) When one of the conditions 1 to 5 applies

Auto tuning starts when the condition no longer applies.

# (b) When the condition 7 applies

CH $\square$  Auto tuning status (Xn4 to Xn7) turns on for a moment. Even though the temperature process value (PV) goes back within the temperature measurement range, auto tuning does not start until CH $\square$  Auto tuning instruction (Yn4 to Yn7) is turned on from off once again.

### (c) When the condition 8 or 9 applies

Even though the internal processing of auto tuning is completed and PID constants are stored, CH $\square$  Auto tuning status (Xn4 to Xn7) does not turn off, therefore the auto tuning is not completed.

# (7) Conditions where auto tuning ends in fail

The conditions are described below.

#### (a) Shift from the operation mode to the setting mode

Shifting from the operation mode to the setting mode (Setting/operation mode instruction (Yn1) is turned off from on) ends auto tuning in fail. Note that an exception is when PID continuation flag (Un\G169) is set to Continue (1). (Page 381, Appendix 2 (43))

#### (b) Setting change of the buffer memory during the execution of auto tuning

If a setting in the following buffer memory areas is changed during the execution of auto tuning, the processing ends in fail.

Duffer memory even neme	Buffer memory address				Reference	
Buffer memory area name	CH1	CH2	CH3	CH4	Reference	
CH□ Set value (SV) setting	Un\G34	Un\G66	Un\G98	Un\G130	Page 354, Appendix 2 (14)	
CH□ Upper limit output limiter	Un\G42	Un\G74	Un\G106	Un\G138		
CH□ Lower limit output limiter	Un\G43	Un\G75	Un\G107	Un\G139	Page 360, Appendix 2 (19)	
CH□ Cooling upper limit output limiter	Un\G721	Un\G737	Un\G753	Un\G769	1	
CH□ Sensor correction value setting	Un\G45	Un\G77	Un\G109	Un\G141	Page 363, Appendix 2 (21)	
CH□ Control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	Page 364, Appendix 2 (23)	
CH□ Cooling control output cycle setting	Un\G722	Un\G738	Un\G754	Un\G770		
CH□ Primary delay digital filter setting	Un\G48	Un\G80	Un\G112	Un\G144	Page 365, Appendix 2 (24)	
CH□ AUTO/MAN mode shift	Un\G50	Un\G82	Un\G114	Un\G146	Page 367, Appendix 2 (26)	
CH□ AT bias	Un\G53	Un\G85	Un\G117	Un\G149	Page 370, Appendix 2 (29)	
CH□ Forward/reverse action setting	Un\G54	Un\G86	Un\G118	Un\G150	Page 371, Appendix 2 (30)	
CH□ Unused channel setting	Un\G61	Un\G93	Un\G125	Un\G157	Page 376, Appendix 2 (35)	
Cold junction temperature compensation selection	Un\G182		Page 384, Appendix 2 (49)			

#### (c) Out of the temperature measurement range

If CH $\square$  Temperature process value (PV) (Un\G9 to Un\G12) exceeds the temperature measurement range (CH $\square$  Input range upper limit (b0 of Un\G5 to Un\G8) or CH $\square$  Input range lower limit (b1 of Un\G5 to Un\G8) becomes 1 (ON)), auto tuning ends in fail. ( $\square$  Page 336, Appendix 2 (3))

# (d) Time until the temperature process value (PV) reaches the set value (SV) for the first time or a half the hunting cycle of the temperature process value (PV)

If the time below exceeds two hours, auto tuning ends in fail.

- Time from the start of auto tuning until CH□ Temperature process value (PV) (Un\G9 to Un\G12) reaches the set value (SV) for the first time
- A half the hunting cycle of CH□ Temperature process value (PV) (Un\G9 to Un\G12)



For the time above not to exceed two hours, bring the temperature of the subject close to the set value (SV) in advance, then execute auto tuning.

#### (e) Calculated values of PID constants after auto tuning

If a calculated value of PID constants after auto tuning exceeds one of the following ranges, auto tuning ends in fail.

- CH□ Proportional band (P) setting (Un\G35, Un\G67, Un\G99, Un\G131): 1 to 10000 (0.1% to 1000.0%)
- CH□ Integral time (I) setting (Un\G36, Un\G68, Un\G100, Un\G132): 1 to 3600 (1s to 3600s)
- CH
   — Derivative time (D) setting (Un\G37, Un\G69, Un\G101, Un\G133): 0 to 3600 (0s to 3600s)



If auto tuning ends in fail due to the calculated value of PID constants as described above, the system configuration needs to be reconsidered (such as selecting proper heater capacity).

# (f) Change of the upper limit setting limiter or lower limit setting limiter and the set value (SV)

If the set value (SV) goes out of the setting range due to the change in one of the following buffer memory areas, auto tuning ends in fail.

- CH□ Upper limit setting limiter (Un\G55, Un\G87, Un\G119, Un\G151)
- CH□ Lower limit setting limiter (Un\G56, Un\G88, Un\G120, Un\G152)

#### (g) Other conditions

In addition to the conditions described up until here, if any of the following conditions applies, auto tuning ends in fail.

- CH□ PID control forced stop instruction (YnC to YnF) has been turned on from off. (『 Page 333, Appendix 1.2 (7))
- · Hardware failure has occurred.
- In standard control, CH□ Proportional band (P) setting (Un\G35, Un\G67, Un\G99, Un\G131) has been set to 0. (has been set to two-position control) ( F Page 355, Appendix 2 (15))
- In heating-cooling control, CH□ Heating proportional band (Ph) setting (Un\G35, Un\G67, Un\G99, Un\G131) has been set to 0. (has been set to two-position control) (☐ Page 355, Appendix 2 (15))

#### (8) Operation on completion of auto tuning

#### (a) Normal completion

The L60TC4 operates as follows.

- Turns off CH□ Auto tuning status (Xn4 to Xn7)
- Stores the PID constants in the buffer memory (PP Page 142, Section 8.2.7 (3))
- Stores a value in CH□ Loop disconnection detection judgment time (Un\G59, Un\G91, Un\G123, Un\G155) (If this was set to 0 (s) at the start of auto tuning, the setting remains unchanged.)

#### (b) Abnormal completion

The L60TC4 operates as follows.

- Turns off CH□ Auto tuning status (Xn4 to Xn7).
- Does not store the PID constants in the buffer memory. (FP Page 142, Section 8.2.7 (3))

# (9) Checking the completion of auto tuning

The completion of auto tuning can be checked by the status change from on to off in CH□ Auto tuning status (Xn4 to Xn7).

# (10)Adjustment after auto tuning

To change the control response toward the PID constants calculated by auto tuning, change the setting in the following buffer memory area.

• CH Control response parameter (Un\G49, Un\G81, Un\G113, Un\G145) (FPage 366, Appendix 2 (25))

# 8.2.8 Simple Two-degree-of-freedom



This is the simplified control form of the two-degree-of-freedom PID control. In this form of PID control, the L60TC4 controls the target subject using not only PID constants but also the control response parameter. The response speed toward the change of the set value (SV) can be selected from three levels.


General PID control is called one-degree-of freedom PID control. In the one-degree-of freedom PID control, when PID constants to improve "response to the change of the set value (SV)" are set, "response to the disturbance" degrades. Conversely, when PID constants to improve "response to the disturbance" are set, "response to the change of the set value (SV)" degrades.

On the other hand, in the two-degree-of-freedom PID control, "response to the change of the set value (SV)" and "response to the disturbance" can be compatible with each other.

Note that required parameter settings increase and PID constants can hardly be auto-set by the auto tuning function for complete two-degree-of-freedom PID control. Therefore, the L60TC4 operates in the simple two-degree-of-freedom PID control for which parameters are simplified.

The level of "response to the change of the set value (SV)" can be selected from the following, maintaining the PID constants that improve "response to the disturbance".

- Fast
- Normal
- Slow



#### (1) Setting method

Set a value on "Control response parameter".

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]



# 8.2.9 Derivative Action Selection Function



An derivative action appropriate for each of fixed value action and ramp action can be selected and the action characteristic can be improved using this function.

### (1) Action

Each type of derivative action operates as shown below.

CH□ Derivative action selection (Un\G729, Un\G745, Un\G761, Un\G777)	Action			
Measured value derivation (0)	Fixed value action  Disturbance	Ramp action  Set value (SV)  Temperature process value (PV)	This setting effectively prevents the temperature from being affected by disturbance, though the performance to follow the set value can be low.	
Deviation derivation (1)	Fixed value action  Disturbance	Set value (SV)  Temperature process value (PV)	This setting allows the temperature to follow the set value well, though the disturbance effect is great.	

# (2) Setting method

Set a value on "Derivative action selection".

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



# 8.2.10 Setting Change Rate Limiter Setting Function



When the set value (SV) is changed, the change rate in the specified time unit can be set on "Setting Change Rate Limiter Setting". The user can select whether to set this rate for temperature rise and temperature drop individually or at once.

# (1) Setting method

#### (a) Batch/individual setting for temperature rise and temperature drop

Select the value on "Setting Change Rate Limiter Setting".

▼ Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Switch Setting]



# (b) Change rate setting


For batch-change, set "Setting change rate limiter or Setting change limiter (Temperature rise)" only.

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]



For individual setting, set "Setting change rate limiter or Setting change limiter (Temperature rise)" and "Setting change rate limiter (Temperature drop)".

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]




# (c) Time unit setting

Set the time unit of the setting change rate limiter on "Setting change rate limiter Unit time setting".

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]

Item	CH1
Setting change rate limiter Unit time setting	5 s

Ex. Operation of when individual setting is selected on Switch Setting



Default value of CH□ Setting change rate limiter unit time setting (Un\G735, Un\G751, Un\G767, Un\G783)

# 8.2.11 Alert Function



When the process value (PV) or deviation reaches the value set in advance, the system is set in an alert status. Use this function to activate danger signals of devices or safety devices.


The alert function is classified into input alerts and deviation alerts depending on the setting of the alert mode.

- Input alert: upper limit input alert, lower limit input alert (FP Page 157, Section 8.2.11 (1))
- Deviation alert: upper limit deviation alert, lower limit deviation alert, upper lower limit deviation alert, withinrange alert (Page 158, Section 8.2.11 (2))

# (1) Input alert

With the upper limit input alert, when the process value (PV) is equal to or greater than the alert set value, the system is put in an alert status.

With the lower limit input alert, when the process value (PV) is equal to or less than the alert set value, the system is put in an alert status.



#### (a) Setting method

Set the alert mode. (FP Page 167, Section 8.2.11 (7) (a))

- Upper limit input alert: Set the alert mode to "1: Upper Limit Input Alert".
- Lower limit input alert: Set the alert mode to "2: Lower Limit Input Alert".

#### (2) Deviation alert

With the deviation alert, when the deviation (E) between the temperature process value (PV) and the set value (SV) meets a particular condition, the system is put in an alert status.

The set value (SV) to be referred is either "set value (SV) monitor" or "set value (SV) setting" depending on the alert mode. When a setting change rate limiter is specified, "set value (SV) monitor" follows the set value (SV) by the specified change rate. (For details on the setting change rate limiter setting, refer to Page 369, Appendix 2 (28).)


The following table describes the use of each set value (SV) of when a setting change rate limiter is specified, and can be referred to use a deviation alert.

Reference area of the set value (SV)	Use (when the set value (SV) is changed)
CH□ Set value (SV) monitor (Un\G25 to Un\G28)	This value is used when the temperature process value (PV) needs to follow the changing set value (SV) within a consistent deviation (E). If the temperature process value (PV) does not follow the set value (SV) and strays out of the set deviation range, an alert occurs.
CH□ Set value (SV) setting (Un\G34, Un\G66, Un\G98, Un\G130)	This value is used for the alert occurrence to be determined only by the deviation (E) from the set value (SV). In this case, how well the temperature process value (PV) is following the changing set value (SV) does not matter. Even if the value in CH $\square$ Set value (SV) monitor (Un\G25 to Un\G28) is changing, an alert can occur depending on the deviation (E) from the set value (SV).


#### (a) Set value (SV) and the setting change rate limiter setting

The following figures show the relationships of two types of set value (SV) depending on whether the setting change rate limiter is specified or not.

• When the setting change rate limiter is not specified: The two types of set value (SV) are the same value.




• When the setting change rate limiter is specified: The value in CH□ Set value (SV) monitor (Un\G25 to Un\G28) follows the set value (SV) of after the setting is reflected.



#### (b) Upper limit deviation alert


When the deviation (E) is equal to or greater than the alert set value, the system is put in an alert status.



Depending on the alert mode, this value becomes "set value (SV) monitor" or "set value (SV) setting". (Fig. Page 158, Section 8.2.11 (2) (a))

#### (c) Lower limit deviation alert

When the deviation (E) is equal to or less than the alert set value, the system is put in an alert status.




Depending on the alert mode, this value becomes "set value (SV) monitor" or "set value (SV) setting". (Fig. Page 158, Section 8.2.11 (2) (a))

#### (d) Upper lower limit deviation alert

When one of the following conditions is satisfied, the system is put in an alert status.

- Deviation (E) ≥ Alert set value
- Deviation (E) ≤ -(Alert set value)




<sup>\*1</sup> Depending on the alert mode, this value becomes "set value (SV) monitor" or "set value (SV) setting". (Fig. Page 158, Section 8.2.11 (2) (a))

# (e) Within-range alert

When the following condition is satisfied, the system is put in an alert status.

• -(Alert set value)  $\leq$  Deviation (E)  $\leq$  Alert set value



Depending on the alert mode, this value becomes "set value (SV) monitor" or "set value (SV) setting". (Fig. Page 158, Section 8.2.11 (2) (a))

# (f) Setting method (alert mode and the set value (SV) to be referred)

Select one of the two types of set value (SV) described in Page 158, Section 8.2.11 (2) by specifying an alert mode.

• When the alert judgment requires the value in CH□ Set value (SV) monitor (Un\G25 to Un\G28), set one of the following values.

Alert mode setting (FP Page 167, Section 8.2.11 (7) (a))		
Setting value	Alert mode name	
3	Upper Limit Deviation Alert	
4	Lower Limit Deviation Alert	
5	Upper/Lower Deviation Alert	
6	Within-Range Alert	
9	Upper Limit Deviation Alert with Wait	
10	Lower Limit Deviation Alert with Wait	
11	Upper/Lower Limit Deviation Alert with Wait	
12	Upper Limit Deviation Alert with Re-Wait	
13	Lower Limit Deviation Alert with Re-Wait	
14	Upper/Lower Limit Deviation Alert with Re-Wait	

• When the alert judgment requires the value in CH□ Set value (SV) setting (Un\G34, Un\G66, Un\G98, Un\G130), set one of the following values.


Alert mode setting (『 Page 167, Section 8.2.11 (7) (a))		
Setting value	Alert mode name	
15	Upper Limit Deviation Alert (Use Set Value (SV) Setting Value)	
16	Lower Limit Deviation Alert (Use Set Value (SV) Setting Value)	
17	Upper lower deviation alert (Use Set Value (SV) Setting Value)	
18	Within-range deviation alert (Use Set Value (SV) Setting Value)	
19	Upper Limit Deviation Alert with Wait (Use Set Value (SV) Setting Value)	
20	Lower Limit Deviation Alert with Wait (Use Set Value (SV) Setting Value)	
21	Upper/Lower Limit Deviation Alert with Wait (Use Set Value (SV) Setting Value)	
22	Upper Limit Deviation Alert with Re-Wait (Use Set Value (SV) Setting Value)	
23	Lower Limit Deviation Alert with Re-Wait (Use Set Value (SV) Setting Value)	
24	Upper/Lower Limit Deviation Alert with Re-Wait (Use Set Value (SV) Setting Value)	

# (3) Alert with standby

Even if the temperature process value (PV) or deviation (E) is in a condition to be in an alert status when the module's status is changed from the setting mode to the operation mode (Setting/operation mode instruction (Yn1): OFF→ON), the alert does not occur. The alert function can be disabled until the temperature process value (PV) or deviation (E) strays out of the condition to be in an alert status.

Ex. When the alert mode is set to Lower limit deviation alert with standby (10)

The alert function is inactive until the deviation (E) exceeds the alert set value (right figure below).



\*1 Depending on the alert mode, this value becomes "set value (SV) monitor" or "set value (SV) setting". ( Page 158, Section 8.2.11 (2) (a))



When the system goes into the non-alert status even once after an alert judgment started following the setting of the alert mode, the alert with standby will be inactive even if the mode is changed to the one with standby.

#### (a) Setting method

Select one of the following alert modes.


Alert mode setting (FP Page 167, Section 8.2.11 (7) (a))			
Setting value	Alert mode name		
7	Upper Limit Input Alert with Wait		
8	Lower Limit Input Alert with Wait		
9	Upper Limit Deviation Alert with Wait		
10	Lower Limit Deviation Alert with Wait		
11	Upper/Lower Limit Deviation Alert with Wait		
19	Upper Limit Deviation Alert with Wait (Use Set Value (SV) Setting Value)		
20	Lower Limit Deviation Alert with Wait (Use Set Value (SV) Setting Value)		
21	Upper/Lower Limit Deviation Alert with Wait (Use Set Value (SV) Setting Value)		

### (4) Alert with standby (second time)

A function to deactivate the alert function once again when the set value (SV) is changed is added to an alert with standby. This is called an alert with standby (second time).

When control needs the set value (SV) change, the alert supposed to occur can be avoided when the set value is changed by selecting an alert with standby (second time).

Ex. When the temperature process value (PV) is on the position as below before the set value (SV) change



Depending on the alert mode, this value becomes "set value (SV) monitor" or "set value (SV) setting". (Fig. 2) Page 158, Section 8.2.11 (2) (a))

For a deviation alert, when the set value (SV) is changed, the temperature process value (PV) goes into the alert area; therefore, the system goes into an alert status.

To prevent the case above, the alert output is put on standby.

#### (a) Setting method

Select one of the following alert modes.

Alert mode setting (FP Page 167, Section 8.2.11 (7) (a))			
Setting value	Alert mode name		
12	Upper Limit Deviation Alert with Re-Wait		
13	Lower Limit Deviation Alert with Re-Wait		
14	Upper/Lower Limit Deviation Alert with Re-Wait		
22	Upper Limit Deviation Alert with Re-Wait (Use Set Value (SV) Setting Value)		
23	Lower Limit Deviation Alert with Re-Wait (Use Set Value (SV) Setting Value)		
24	Upper/Lower Limit Deviation Alert with Re-Wait (Use Set Value (SV) Setting Value)		



If a setting change rate limiter is specified, an alert with standby (second time) is not active even though one of the following alert modes is selected.

Alert mode setting ( Page 167, Section 8.2.11 (7) (a))		
Setting value	Alert mode name	
12	Upper Limit Deviation Alert with Re-Wait	
13	Lower Limit Deviation Alert with Re-Wait	
14	Upper/Lower Limit Deviation Alert with Re-Wait	

The standby (second time) is used to prevent alert occurrence when the set value (SV) is changed. If a setting change rate limiter is specified, the value in CH $\square$  Set value (SV) monitor (Un\G25 to Un\G28) gradually changes following the set value (SV) when the set value (SV) is changed. Suppose that the standby (second time) function is activated under such occasion. The alert standby would be always active; therefore an alert would not be output even when the temperature process value (PV) is not following the value in CH $\square$  Set value (SV) monitor (Un\G25 to Un\G28). To prevent such cases, the standby (second time) function is deactivated if a setting change rate limiter is used.

# (5) Condition for alert judgment

Whether alert occurrence is judged or not depends on the settings of the followings:

- Setting/operation mode instruction (Yn1) ( Page 330, Appendix 1.2 (1))
- PID continuation flag (Un\G169) (FPage 381, Appendix 2 (43))
- CH□ PID control forced stop instruction (YnC to YnF) ( Page 333, Appendix 1.2 (7))
- CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) ([ → Page 353, Appendix 2 (13))

The following table shows the relationship between each setting above and the execution of alert judgment.

O: Judged x: Not judged

Setting/operation mode instruction (Yn1)*1	PID continuation flag (Un\G169)	CH□ PID control forced stop instruction (YnC to YnF)	CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129)	Alert judgment
D 011	01 (0)(0 1)		Stop (0)	×
Power ON, Setting mode	Stop (0)/Continue (1)	OFF/ON	Monitor (1)	×
octaing mode	(1)		Alert (2)	0
		OFF	Stop (0)/Monitor (1)/Alert (2)	0
Operation mode	Stop (0)/Continue (1)		Stop (0)	×
(operating)		ON	Monitor (1)	×
			Alert (2)	0
	Stop (0)	OFF/ON	Stop (0)	×
			Monitor (1)	×
			Alert (2)	0
Setting mode (after operation)		OFF	Stop (0)/Monitor (1)/Alert (2)	0
(antor operation)	Continue (1)		Stop (0)	×
		ON	Monitor (1)	×
			Alert (2)	0

<sup>\*1</sup> For details, refer to Page 324, Appendix 1.1 (2).

Even if the conditions above are satisfied, when CH $\square$  Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1), alert judgment is not executed. ( $\square$  Page 376, Appendix 2 (35))

# (6) Condition where CH□ Alert occurrence flag (XnC to XnF) turns off

The condition where CH□ Alert occurrence flag turns off differs depending on the setting of the following buffer memory area.

• CH Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) (FPage 353, Appendix 2 (13))

CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129)	Condition where CH□ Alert occurrence flag (XnC to XnF) turns off
Stop (0)	When the cause of the alert is resolved, or when the system is shifted from the
Monitor (1)	operation mode to the setting mode (when Setting/operation mode instruction (Yn1) is turned off from on).
Alert (2)	When the cause of the alert is resolved,


#### (7) Setting alert modes and alert set values

Settings of the alert mode and alert set value are described below.

#### (a) Alert mode

Set the alert mode. Up to four modes can be set for each channel. Set modes in "Alert 1 mode setting" to "Alert 4 mode setting".

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



Each alert mode for alert 1 to 4 corresponds to alert set value 1 to 4.

### (b) Alert set value

Set the value where CH Alert 1 (b8 of Un\G5 to Un\G8) to CH Alert 4 (b11 of Un\G5 to Un\G8) turns on according to the set alert mode. Up to four values can be set for each channel. Set values in "Alert set value 1" to "Alert set value 4".

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]



Alert set value 1 to 4 corresponds to each alert mode for alert 1 to 4.

#### (8) Setting the alert dead band

When the temperature process value (PV) or deviation (E) is close to the alert set value, alert status and non-alert status may alternates repeatedly due to inconsistent input.

Such case can be prevented by setting an alert dead band.

#### (a) Setting method


Set a value on "Alert dead band setting".

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Parameter]

Item	CH1
Alert dead band setting	0.5 %
Number of alert delay	N Times

When the alert mode is set to Upper limit input alert (1) (Page 157, Section 8.2.11 (1))

When a value other than 0 (0.0%) is set in Alert dead band setting (Un\G164), the system is put in the alert status when upper limit input becomes equal to or greater than the alert set value. The system is put in the non-alert status when the upper limit falls below the alert dead band (figure on the right).



# (9) Setting the number of alert delay

Set the number of sampling to judge alert occurrence. The system is set in the alert status when the process value (PV) that has reached the alert set value remains in the alert range until the number of sampling becomes equal to or greater than the preset number of alert delays.


#### (a) Setting method

Set a value on "Number of alert delay".

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Parameter]



When the alert mode is set to Upper limit input alert (1) (Page 157, Section 8.2.11 (1))
When 5 is set as the number of alert delay, the system is not put in the alert status if the number of sampling is 4 or less.



# (10)Alert mode and settings

The following table shows the alert modes and validity/availability of related settings.

(Active/Yes: O, Inactive/No: —)

(Active Tes. C, inactive Tv					, , , ,
Alert		Alert dead band setting (Fig. Page 168, Section 8.2.11 (8))	Number of alert delay (Fig. Page 169, Section 8.2.11 (9))	Alert with standby  (Fig. Page 163, Section 8.2.11  (3))	Alert with standby (second time) (Page 164, Section 8.2.11 (4))
	T	(0))	(9))	(3))	0.2.11 (4))
Input alert	Upper limit input alert (FF Page 157, Section 8.2.11 (1))	0	0	0	_
	Lower limit input alert (FF Page 157, Section 8.2.11 (1))	0	0	0	_
Deviation	Upper limit deviation alert				
	( Page 159, Section 8.2.11 (2) (b))	0	0	0	0
	Upper limit deviation alert (using the				
	set value (SV)) (FF Page 159, Section 8.2.11 (2) (b))	0	0	0	0
	Lower limit deviation alert				
	([Page 160, Section 8.2.11 (2) (c))	0	0	0	0
	Lower limit deviation alert (using the				
	set value (SV)) (FF Page 160, Section 8.2.11 (2) (c))	0	0	0	0
alert	Upper lower limit deviation alert				
	([	0	0	0	0
	Upper lower limit deviation alert	0	0	0	0
	(using the set value (SV))				
	(l) Page 160, Section 8.2.11 (2) (d))				
	Within-range alert (Fig. Page 161, Section 8.2.11 (2) (e))	0	0	_	_
	Within-range alert (using the set				
	value (SV)) ( Page 161, Section 8.2.11 (2) (e))	0	0	_	_

#### 8.2.12 **RFB Limiter Function**





The RFB (reset feed back) function operates when deviation (E) continues for a long period of time. In such occasion, this function limits the PID operation result (manipulated value (MV)) from an integral action so that it does not exceed the valid range of the manipulated value (MV).

This function operates automatically on execution of PID control; therefore, a setting by the user is unnecessary.



When the PID operation result exceeds the upper limit output limiter value, the L60TC4 operates as follows:

• The RFB function levels the manipulated value (MV) to the upper limit output limiter value by feeding back the exceeded value to the integral value.

When the PID operation result is below the lower limit output limiter value, the L60TC4 operates as follows:

• The RFB function levels the manipulated value (MV) to the lower limit output limiter value by feeding back the lacking value to the integral value.

# 8.2.13 Input/output (with another analog module) function



Input and output can be processed using other analog modules (such as an A/D converter module or D/A converter module) in the system.

# (1) Input


In general, a temperature control module uses the temperature measured through thermocouples or platinum resistance thermometers connected to the module as a temperature process value (PV).


In the L60TC4, the digital input value of current or voltage converted by other analog modules (such as an A/D converter module) in the system can also be used as a temperature process value (PV).

#### (a) Setting method

Follow the procedure below.

 Select "Input range" from one of "201:Input with Another Analog Module Measured Temperature Range (0 to 4000)" to "205:Input with Another Analog Module Measured Temperature Range (0 to 32000)".





2. Store the value of another analog module (such as an A/D converter module) into CH□

Temperature process value (PV) for input with another analog module (Un\G689 to Un\G692).

Store the value of another analog module (such as an A/D converter module) into CH□

Temperature process value (PV) for input with another analog module. (Un\G689 to Un\G692)

(□ Page 402, Appendix 2 (74))

# Point P

- If the second procedure above is executed ahead of the first procedure, a write data error (error code: □□□4<sub>H</sub>) occurs.
- When this function is used, the value in the following buffer memory area is used for the temperature process value (PV) scaling function.
  - CH $\square$  Temperature process value (PV) for input with another analog module (Un\G689 to Un\G692) For details on the temperature process value (PV) scaling function, refer to the following.

Page 221, Section 8.3.1

# (2) Output

Instead of the transistor output from the temperature control module, analog output values from other analog modules (such as a D/A converter module) can be used as the manipulated value (MV).

#### (a) Setting method

Follow the procedure below (for the standard control).

- 1. Select the value on "Resolution of the manipulated value for output with another analog module".
  - Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



2. Store the value in CH Manipulated value (MV) for output with another analog module (Un\G177 to Un\G180) into the buffer memory in other analog module (such as a D/A converter module). (FP Page 383, Appendix 2 (47))




- When the manipulated value (MV) is -5.0% to 0.0%, 0 is stored in Manipulated value (MV) for output with another analog module. When the manipulated value (MV) is 100.0% to 105.0%, 4000/12000/16000/20000 is stored in Manipulated value (MV) for output with another analog module.
- The manipulated value (MV) in a percentage value is stored into Manipulated value (MV) for output with another analog
  module (digital output value) in real time.

# 8.2.14 ON delay output function



This function allows the user to set the delay (response/scan time delay) of transistor output. By setting a delay, and monitoring the ON delay output flag and external output on the program, disconnection of external output can be judged. The following figure is an example using the ON delay flag.



# (1) Setting method

Set a value on "Transistor output monitor ON delay time setting".

Project window 🖒 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]



# 8.2.15 Self-tuning function



The L60TC4 constantly monitors the control state. When the control system is oscillatory, this function allows PID constants to be automatically changed under the following situations such as:

- · After the control has been just started
- · When the set value (SV) is changed
- When the characteristics of a controlled object fluctuates

Unlike the auto tuning function, a normal control response waveform is monitored and PID constants are automatically calculated and set. This allows an object to be controlled with the most suitable PID constants all the time without disturbance.

# (1) Differences between auto tuning and self-tuning

The following table lists the differences between auto tuning and self-tuning.


Item	Auto tuning	Self-tuning
PID constants calculation	The manipulated value (MV) is turned on/off and PID constants are calculated based on the hunting cycle and amplitude of the temperature process value (PV) for the set value (SV).	PID constants are calculated based on an oscillation occurred under situations such as after the control has been just started, the set value (SV) has been changed, and when a control response is oscillatory.
Execution method	Turning off and on CH□ Auto tuning instruction (Yn4 to Yn7) starts auto tuning and changes PID constants upon completion.	The L60TC4 constantly monitors the control response. PID constants are calculated and changed when the control response is slow.
Control response	PID constants are calculated based on the control response of when the manipulated value (MV) is turned on/off; therefore, the control may become unstable.	PID constants are calculated based on the control response during temperature control; therefore, the control is stable.
Calculation result	The optimum PID constants are calculated by one tuning. In the standard control, CH□ Loop disconnection detection judgment time (Un\G59, Un\G91, Un\G123, Un\G155) is also calculated.	The optimum PID constants may not be obtained by one tuning. CH□ Loop disconnection detection judgment time (Un\G59, Un\G91, Un\G123, Un\G155) is not calculated.
PID constants setting when the characteristics of a controlled object fluctuate	Users perform auto tuning again to change PID constants.	The L60TC4 automatically changes PID constants.
Available control mode	The standard control and heating-cooling control	The standard control only

# (2) Starting ST and vibration ST

Two types of self-tuning are available depending on the state of the control system: starting ST (self-tuning) and vibration ST.

- Starting ST: Self-tuning is performed immediately after the control is started or when the set value (SV) is changed.
- Vibration ST: Self-tuning is performed when the control system in a stable state has become oscillatory due to reasons such as disturbance.






#### (a) How to set starting ST

Select one of the following four setting values for "Self-tuning setting".


- 1: Starting ST (PID Constant Only)
- 2: Starting ST (Simultaneous Temperature Rise Parameter Only)
- 3: Starting ST (PID Constant and Simultaneous Temperature Rise Parameter)
- 4: Starting ST plus Vibration ST (PID Constant Only)
  - Project window 💠 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]



#### (b) How to set vibration ST


Set the following for "Self-tuning setting".

- 4: Starting ST plus Vibration ST (PID Constant Only)
  - Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



# (3) Procedure for the self-tuning control

The following is the flow chart for the control.




# (4) Operation with starting ST

This section explains the operation of when the temperature control is started or the set value (SV) is changed (starting ST).

With starting ST, the module monitors the response waveform of the temperature process value (PV) of when the temperature control is started or when the set value (SV) is changed. Then PID constants are automatically corrected. The following table lists the operations of the module with starting ST.

Operation with starting ST				
1	CH□ PID auto-correction status (b0 of Un\G575, Un\G607, Un\G639, Un\G671) is turned 0 (OFF). In addition, CH□ Auto tuning status (Xn4 to Xn7) is turned on.			
2	Temperature is controlled using the PID constants set.			
3	When a control response is poor, PID constants are calculated based on the response waveform and are set in the buffer memory. In addition, CH $\square$ PID auto-correction status (b0 of Un\G575, Un\G607, Un\G639, Un\G671) is turned 1 (ON). When a control response is good, CH $\square$ PID auto-correction status (b0 of Un\G575, Un\G607, Un\G639, Un\G671) remains 0 (OFF) and PID constants are not changed.			
4	CH□ Auto tuning status (Xn4 to Xn7) is turned off.			



#### (a) Conditions for self-tuning (starting ST)

Self-tuning is executed under the following conditions:

- When the setting mode is shifted to the operation mode (Setting/operation mode instruction (Yn1) is turned off and on) the first time after the power is turned off and on or after the CPU module is reset and the reset is cancelled
- When the setting mode is shifted to the operation mode the second time or later after the power is turned off and on or after the CPU module is reset and the reset is cancelled (only when the temperature process value (PV) has been stable for two minutes or longer before the mode is shifted)
- When the set value (SV) is changed (only when the set value (SV) after the change is greater than that
  before the change and when the temperature process value (PV) before the change has been stable for
  two minutes or longer



If the starting ST is started when the temperature process value (PV) is not stable, incorrect PID constants may be determined. Execute the starting ST after the temperature process value (PV) has been stable for two minutes or longer.


### (5) Operation with vibration ST

This section explains the operation of when a control response is oscillatory (vibration ST).

With vibration ST, PID constants are automatically corrected to settle a vibration when a control response becomes oscillatory due to reasons such as the change in the characteristic of a controlled object and conditions for operation.

The following table lists the operations of the module with vibration ST. (The listed operations are those under the state where temperature is being controlled with the PID constants set.)

Operation with vibration ST				
1	CH□ PID auto-correction status (b0 of Un\G575, Un\G607, Un\G639, Un\G671) is turned 0 (OFF). In addition, CH□ Auto tuning status (Xn4 to Xn7) is turned on.			
2	PID constants are calculated based on a response waveform.			
3	PID constants are set in the buffer memory and CH□ PID auto-correction status (b0 of Un\G575, Un\G607, Un\G639, Un\G671) is turned 1 (ON).			
4	CH□ Auto tuning status (Xn4 to Xn7) is turned off.			



#### (a) Conditions for self-tuning (vibration ST)

Self-tuning is executed when the temperature process value (PV) goes outside the range that is judged as unstable.

### (b) Precautions

If self-tuning (vibration ST) is executed on the following objects, incorrect PID constants may be determined:

- · Controlled objects where a disturbance periodically occurs
- · Controlled objects with strong mutual interference

### (6) Conditions where self-tuning is not executed


This section explains the conditions where self-tuning is not executed.

### (a) The control method is not the PID control method

When the control method is one of the methods other than the PID control method (two-position control, P control, PD control), the following is operated.

• CH□ Self-tuning disable status (b8 of Un\G575, Un\G607, Un\G639, Un\G671) turns 1 (ON).

When all PID constants of target channels turn to a value other than 0, self-tuning is enabled.



#### (b) Auto tuning is being executed

At the time of when auto tuning is completed, self-tuning is enabled. An error does not occur.

(c) The lower limit output limiter value is lower than the manipulated value (MV) and the manipulated value (MV) is lower than the upper limit output limiter value when the temperature control is started and the set value (SV) is changed

The starting ST does not start. However, self-tuning is enabled at the time of when a control response becomes oscillatory under the following setting.

• CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) is set to Starting ST and vibration ST (4).

(d) The manipulated value (MV) is not changed from the lower limit output limiter value or upper limit output limiter value when the temperature control is started and the set value (SV) is changed

The starting ST does not start. However, self-tuning is enabled at the time of when a control response becomes oscillatory under the following setting.

- CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) is set to Starting ST plus Vibration ST (4).
- (e) The temperature process value (PV) is not within the temperature measurement range

CHD Self-tuning disable status (b8 of Un\G575, Un\G607, Un\G639, Un\G671) turns 1 (ON).

(f) The value set in CH□ Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140) is not 0 (☐ Page 362, Appendix 2 (20))

CHD Self-tuning disable status (b8 of Un\G575, Un\G607, Un\G639, Un\G671) turns 1 (ON).

(g) CH□ AUTO/MAN mode shift (Un\G50, Un\G82, Un\G114, Un\G146) is set to MAN (1) (□ Page 367, Appendix 2 (26))

CH□ Self-tuning disable status (b8 of Un\G575, Un\G607, Un\G639, Un\G671) turns 1 (ON).

### (h) Other conditions

In addition to those described above, self-tuning is not executed under the following conditions.

- The heating-cooling control has been selected for the control mode. (FF Page 108, Section 7.2)
- The following buffer memory areas have been set to values other than 0 (0.0%).

Buffer memory area name	Buffer memory address				Reference
Buller memory area name	CH1	CH2	СНЗ	CH4	Reference
CH□ Setting change rate limiter/Setting change rate limiter (temperature rise)	Un\G52	Un\G84	Un\G116	Un\G148	Page 369, Appendix 2 (28)
CH□ Setting change rate limiter (temperature drop)	Un\G564	Un\G596	Un\G628	Un\G660	1 age 309, Appendix 2 (20)

#### (7) Discontinuation of self-tuning

The following operation during self-tuning discontinues the self-tuning operation.

• The setting in CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) has been changed to Do Not Run the ST (0).

The self-tuning operation in process is discontinued and self-tuning is not performed anymore after that. (An error does not occur.)

Whether self-tuning is being executed can be checked in CH□ Auto tuning status (Xn4 to Xn7). (☐ Page 326, Appendix 1.1 (5))

### (8) Conditions where self-tuning does not complete due to errors

The following are the conditions where an error occurs in self-tuning.

• The setting for the buffer memory areas in the following table was changed during self-tuning.


Duffer memory area name		Buffer mem	ory address		Reference
Buffer memory area name	CH1	CH2	CH3	CH4	Reference
CH□ Proportional band (P) setting	Un\G35	Un\G67	Un\G99	Un\G131	Page 355, Appendix 2 (15)
CH□ Integral time (I) setting	Un\G36	Un\G68	Un\G100	Un\G132	Page 357, Appendix 2 (16)
CH□ Derivative time (D) setting	Un\G37	Un\G69	Un\G101	Un\G133	Page 357, Appendix 2 (17)
CH□ Upper limit output limiter	Un\G42	Un\G74	Un\G106	Un\G138	Dago 260 Annondiy 2 (10)
CH□ Lower limit output limiter	Un\G43	Un\G75	Un\G107	Un\G139	Page 360, Appendix 2 (19)
CH□ Sensor correction value setting	Un\G45	Un\G77	Un\G109	Un\G141	Page 363, Appendix 2 (21)
CH□ Control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	Page 364, Appendix 2 (23)
CH□ Primary delay digital filter setting	Un\G48	Un\G80	Un\G112	Un\G144	Page 365, Appendix 2 (24)
CH□ AUTO/MAN mode shift	Un\G50	Un\G82	Un\G114	Un\G146	Page 367, Appendix 2 (26)
CH□ Setting change rate limiter/Setting change rate limiter (temperature rise)	Un\G52	Un\G84	Un\G116	Un\G148	Page 369, Appendix 2 (28)
CH□ Forward/reverse operation setting	Un\G54	Un\G86	Un\G118	Un\G150	Page 371, Appendix 2 (30)
CH□ Unused channel setting	Un\G61	Un\G93	Un\G125	Un\G157	Page 376, Appendix 2 (35)
CH□ Setting change rate limiter (temperature drop)	Un\G564	Un\G596	Un\G628	Un\G660	Page 369, Appendix 2 (28)

- CH Temperature process value (PV) (Un\G9 to Un\G12) is outside the temperature measurement range. (FP Page 336, Appendix 2 (3))
- The manipulated value (MV) does not reach the upper limit output limiter value or lower limit output limiter value before the measurement is completed and necessary measurement data is not obtained.
- After self-tuning is started with the starting ST, the temperature process value (PV) that is supposed to rise drops by 1°C (°F) or more.
- After self-tuning is started with the starting ST, the temperature process value (PV) that is supposed to drop rises by 1°C (°F) or more.

When an error occurs in self-tuning, CH Self-tuning error (b10 of Un\G575, Un\G607, Un\G639, Un\G671) turns 1 (ON).

### (9) Precautions

• Before starting the temperature control using the L60TC4, power on a controlled object such as a heater. If the temperature control is started with a heater powered off, PID constants are calculated based on a response that differs from the original characteristics using self-tuning.



- Do not use the self-tuning function for controlled objects where a great disturbance (uncontrollable disturbance) occurs periodically. Doing so may cause improper PID constants to be determined by selftuning. If the function is used for such objects, improper PID constants are set and the response for the set value (SV) change or disturbance becomes slow.
- Ex. Temperature control for an injection mold, temperature control for a hot plate for a semiconductor manufacturing equipment

### (10)To forcibly start up self-tuning


Self-tuning is started up when an error occurs with the control operation; therefore, the forced start-up is not required. To forcibly start up self-tuning, operate the following:

- Set CH□ Control response parameter (Un\G49, Un\G81, Un\G113, Un\G145) to Fast (2). (FF Page 366, Appendix 2 (25))
- Set CH□ Integral time (I) setting (Un\G36, Un\G68, Un\G100, Un\G132) to a small value. (☐ Page 357, Appendix 2 (16))
- Set CH□ Derivative time (D) setting (Un\G37, Un\G69, Un\G101, Un\G133) to a small value. (☐ Page 357, Appendix 2 (17))

# 8.2.16 Peak current suppression function



The upper limit output limiter value for each channel is changed automatically and the peak current is suppressed by dividing timing for transistor outputs using this function.



### (1) The number of timing divided and upper limit output limiter

Set the number of timing to be divided (setting in Peak current suppression control group setting (Un\G784) in the setting mode (Setting/operation mode status (Xn1): off). The setting is enabled by turning off, on, and off Setting change instruction (YnB). At the time when the setting is enabled, the following buffer memory area is automatically set according to the number of timing divided.

• CH Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138) ( Page 360, Appendix 2 (19)) The following table lists the setting details.

The no. of timing divided	CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)
2	500 (50.0%)
3	333 (33.3%)
4	250 (25.0%)

The following buffer memory area is set to 0.


CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139) (FF Page 360, Appendix 2 (19))



When using this function, set the control output cycles for target channels to the same value. Even if the following buffer memory area setting is different by each channel, an error does not occur.

• CH $\square$  Control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143) (FF Page 364, Appendix 2 (23)) The module operates according to the value (%) of CH $\square$  Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138) automatically set when this function is used.

### Ex. Timing chart of when timing is divided into four timing



### (2) Examples of dividing timing


### (a) Four timing

The following table shows two examples.

Example	Channel	Group
	CH1	Group 1
Example 1	CH2	Group 2
Lxample	CH3	Group 3
	CH4	Group 4
	CH1	Group 1
Example 2	CH2	Group 2
Example 2	CH3	Not divided
_	CH4	Group 4

The following shows the relationship between groups and the values (%) of CH $\square$  Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138).

Peak current suppression control group setting (Un\G784)



Page 376, Appendix 2 (35)

In Example 2, the maximum number of groups is four; therefore, timing is divided into four timing. Because no channel is set for Group 3, no channel starts transistor output at the timing for Group 3.


### (b) Three timing

The following table shows two examples.

Example	Channel	Group
	CH1	Group 1
Evample 1	CH2	Group 2
Example 1	CH3	Group 2
	CH4	Group 3
	CH1	Group 1
Example 2	CH2	Group 2
Example 2	CH3	Group 3
	CH4	Not divided

The following shows the relationship between groups and the values (%) of CH□ Upper limit output limiter  $(Un\backslash G42,\,Un\backslash G74,\,Un\backslash G106,\,Un\backslash G138).$ 

Peak current suppression control group setting (Un\G784)



can be selected by CH4 Unused channel setting (Un\G157).

Page 376, Appendix 2 (35)


### (c) Two timing

The following table shows two examples.

Example	Channel	Group
	CH1	Group 1
Example 1	CH2	Group 1
Lxample 1	CH3	Group 2
	CH4	Group 2
	CH1	Group 1
Example 2	CH2	Group 2
Example 2	CH3	Not divided
	CH4	Not divided

The following shows the relationship between groups and the values (%) of CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138).


Peak current suppression control group setting (Un\G784)



### (3) Setting method

Set the timing under "Peak current suppression control group setting".

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Parameter]




### 8.2.17 Simultaneous temperature rise function

Standard

This function allows several loops to reach the set value (SV) at the same time. Simultaneous temperature rise can be performed on up to two groups separately by setting a group for the channels to rise at the same time. This function is effective for controlled objects where the temperature rise should complete at the same time. Aligning the time for temperature rise completion can perform even temperature control without partial burning or partial heat expansion. In addition, the channel reaching the set value (SV) first does not need to be kept warm at the set value (SV) until the last channel reaches, leading to energy saving.


Ex. The simultaneous temperature rise function used and not used in CH1



### (1) Operation of the simultaneous temperature rise function

The channel with the temperature rise reaching the set value (SV) last among channels satisfying the condition for start-up in the same group is used as a standard when the simultaneous temperature rise function is started up. The temperature of other channels rises following the temperature of the standard channel. The standard channel is determined based on the simultaneous temperature rise parameter and the deviation (E).


Ex. When all channels are selected for Group 1



<sup>\*1</sup> This becomes Simultaneous temperature rise in process (1) when the temperature rise starts; however, it becomes Simultaneous temperature rise not in process (0) before the temperature rise starts.

### Ex. When channels are divided as following:

CH1 and CH2: Group 1CH3 and CH4: Group 2



\*1 They become Simultaneous temperature rise in process (1) when the temperature rise starts; however, they become Simultaneous temperature rise not in process (0) before the temperature rise starts.

### Remark

- When the operation mode is changed to the setting mode (Setting/operation mode instruction (Yn1) is turned on and off) during simultaneous temperature rise, the control is stopped. In addition, CH□ Simultaneous temperature rise status (Un\G734, Un\G750, Un\G766, Un\G782) changes from Simultaneous temperature rise in process (1) to Simultaneous temperature rise not in process (0). (An error does not occur.)
- When the simultaneous temperature rise function is executed, the setting change rate limiter cannot be used.
   ( Page 369, Appendix 2 (28))

### (2) Conditions for the simultaneous temperature rise function

The simultaneous temperature rise function is executed when all the following conditions are satisfied:

- · When the control is started or the set value (SV) is changed
- When the set value (SV) is larger than the temperature process value (PV)
- When the standard control is selected on Switch Setting (not executed in the heating-cooling control) (FP Page 108, Section 7.2)
- When the simultaneous temperature rise parameter has been determined (or has been set) and is not 0 (the default value)


When the following buffer memory area setting is less than 100%, reaching time may vary.

• CH Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138) (FP Page 360, Appendix 2 (19))

### (3) Setting method (dividing channels into groups)

Set the groups under "Simultaneous temperature rise group setting".

Project window <> [Intelligent Function Module] <> Module name <> [Parameter]



### (4) Simultaneous temperature rise parameter

The simultaneous temperature rise parameter is classified into the following two buffer memory values.

Buffer memory area name	Buffer memory address				Reference
Bullet memory area name	CH1	CH2	CH3	CH4	Kelelelice
CH□ Simultaneous temperature rise gradient data	Un\G731	Un\G747	Un\G763	Un\G779	Page 408, Appendix 2 (85)
CH□ Simultaneous temperature rise dead time	Un\G732	Un\G748	Un\G764	Un\G780	Page 408, Appendix 2 (86)

Before executing the simultaneous temperature rise function, the simultaneous temperature rise parameter needs to be automatically calculated (or arbitrarily set).

#### (a) Automatic calculation

The simultaneous temperature rise parameter can be automatically calculated using the following two methods:

- Simultaneous temperature rise AT (Page 194, Section 8.2.17 (5))
- Simultaneous temperature rise parameter setting using self-tuning (FP Page 197, Section 8.2.17 (6))



If the setting in Peak current suppression control group setting (Un\G784) is changed after the simultaneous temperature rise parameter is calculated, the intended control may not be performed. If so, calculate the simultaneous temperature rise parameter again.

For details on the peak current suppression function, refer to the following.

Page 185, Section 8.2.16

### (5) Simultaneous temperature rise AT

PID constants and the simultaneous temperature rise parameter are calculated. The waveform upon execution is the same as that for the auto tuning function.

For details on the auto tuning function, refer to the following.


Page 141, Section 8.2.7

### (a) How to execute the simultaneous temperature rise AT function

Follow the instructions below.

 Set "1:AT for Simultaneous Temperature Rise" under "Simultaneous temperature rise AT mode selection".

Project window 🖒 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]




- 2. Turn off and on CH Auto tuning instruction (Yn4 to Yn7).
- 3. Set the module to the operation mode (turn off and on Setting/operation mode instruction (Yn1).

### (b) Operation with the simultaneous temperature rise AT function

After the procedure described on Page 194, Section 8.2.17 (5) (a) is executed, the L60TC4 operates as following.

	Operation of the L60TC4					
1	CH□ Auto tuning status (Xn4 to Xn7) is turned on. Then normal auto tuning is performed and the simultaneous temperature rise parameter is calculated.					
2	The calculated value is stored in the buffer memory when the simultaneous temperature rise parameter is normally calculated. In addition, CH $\square$ AT simultaneous temperature rise parameter calculation completion (b0 of Un\G573, Un\G605, Un\G6037, Un\G669) is turned 1 (ON). After auto-tuning is completed, CH $\square$ Auto tuning status (Xn4 to Xn7) is turned off and the module is shifted to the PID control.					




### (c) Condition for the simultaneous temperature rise AT

The simultaneous temperature rise parameter is calculated when all the following conditions are satisfied after the procedure described on Page 194, Section 8.2.17 (5) (a) is executed:

- When the module is in the PID control (all of the proportional band (P), integral time (I), and derivative time (D) are not 0)
- When the temperature process value (PV) is within the temperature measurement range before the simultaneous temperature rise AT is executed. If the temperature process value (PV) goes outside the range after the simultaneous temperature rise AT is executed, an error occurs with the auto tuning function. For the operation of the L60TC4 in that situation, refer to Page 151, Section 8.2.7 (8) (b).
- When CH Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140) is set to 0. (Fig. Page 362, Appendix 2 (20))

If all the conditions described above are not satisfied, the simultaneous temperature rise parameter is not calculated. Only PID constants are calculated.

The following shows how the L60TC4 operates when the simultaneous temperature rise AT has not been executed.




The L60TC4 turns CH $\square$  Simultaneous temperature rise AT disable status (b2 of Un\G573, Un\G605, Un\G637, Un\G669) to 1 (ON). With CH $\square$  Auto tuning status (Xn4 to Xn7) on, the module performs the same processing as normal auto tuning.

### (d) When the simultaneous temperature rise parameter cannot be calculated

The simultaneous temperature rise parameter cannot be calculated under the following conditions:

- · When the maximum gradient is not determined
- · When the saturation time for output is short

The L60TC4 turns CH $\square$  AT simultaneous temperature rise parameter calculation error status (b1 of Un\G573, Un\G605, Un\G637, Un\G669) to 1 (ON).



### (6) The simultaneous temperature rise parameter setting using self-tuning

The control response at the time of temperature rise is constantly monitored during self-tuning and the simultaneous temperature rise parameter is calculated based on the characteristics of a controlled object. For details on the self-tuning function, refer to the following.

Page 175, Section 8.2.15

### (a) Operation with the simultaneous temperature rise parameter setting using selftuning

The L60TC4 operates as following.

Operation of the L60TC4					
1	When self-tuning is normally started up, CH□ Auto tuning status (Xn4 to Xn7) is turned on and the simultaneous temperature rise parameter is calculated.				
2	The calculated value is stored in the buffer memory when the simultaneous temperature rise parameter is normally calculated. Then CH□ Simultaneous temperature rise parameter correction status (b1 of Un\G575, Un\G607, Un\G639, Un\G671) is turned 1 (ON), CH□ Auto tuning status (Xn4 to Xn7) is turned off, and the module is shifted to the PID control.				


CH□ Auto tuning status (Xn4 to Xn7)

Control status

CH□ Simultaneous temperature rise gradient data (Un\G731, Un\G747, Un\G763, Un\G779) and CH□ Simultaneous temperature rise dead time (Un\G732, Un\G748, Un\G764, Un\G780)

CH☐ Simultaneous temperature rise parameter correction status

(b1 of Un\G575, Un\G607, Un\G639, Un\G671)



Temperature control start, set value (SV) change or oscillation detected

----→ Executed by the L60TC4

### (b) Condition for the simultaneous temperature rise parameter setting using self-tuning

The condition is the same as that for the starting ST. (FP Page 178, Section 8.2.15 (4) (a))


When the self-tuning cannot be started up, the L60TC4 operates as following with the PID control continued:

• CH Self-tuning disable status (b8 of Un\G575, Un\G607, Un\G639, Un\G671) is turned 1 (ON). The following shows how the L60TC4 operates when self-tuning is not executed.

CH□ Auto tuning status (Xn4 to Xn7)

Control status

CH□ Self-tuning disable status (b8 of Un\G575, Un\G607, Un\G639, Un\G671)




### (c) When the simultaneous temperature rise parameter cannot be calculated

The simultaneous temperature rise parameter cannot be calculated under the following conditions:

- · When the maximum gradient is not determined
- · When the saturation time for output is short

The L60TC4 turns CH□ Simultaneous temperature rise parameter error status (b9 of Un\G575, Un\G607, Un\G639, Un\G671) to 1 (ON).





To restore CH $\square$  Simultaneous temperature rise parameter error status (b9 of Un\G575, Un\G607, Un\G639, Un\G671) to 0 (OFF), set the following:

• Set CH Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) to Not performing ST (0). To calculate the simultaneous temperature rise parameter, execute self-tuning again after the temperature has dropped.

### (d) Stopping of calculation for the simultaneous temperature rise parameter

The optimum simultaneous temperature rise parameter may not be able to be calculated depending on the characteristics of a controlled object. In addition, the L60TC4 stops calculating the simultaneous temperature rise parameter during self-tuning under the following conditions:


- · When the set value (SV) is changed
- · When 6000s (1 hour and 40 minutes) or longer has passed after the self-tuning operation is started
- When the change rate of the temperature process value (PV) during self-tuning is less than 1.125 (°C/minute)
- When the setting for CH□ Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140) is changed (□ Page 362, Appendix 2 (20))

### (e) How to set the simultaneous temperature rise parameter using self-tuning

Select one of the following setting values under "Self-tuning setting".

- 2: Starting ST (Simultaneous Temperature Rise Parameter Only)
- 3: Starting ST (PID Constant and Simultaneous Temperature Rise Parameter)


▼ Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]



# (7) Operation when the simultaneous temperature rise parameter is calculated with self-tuning and auto tuning


# (a) When the simultaneous temperature rise AT is started before the simultaneous temperature rise parameter is calculated with self-tuning

The simultaneous temperature rise parameter is not calculated neither with self-tuning nor auto tuning. PID constants are changed.




# (b) When the simultaneous temperature rise AT is started after the simultaneous temperature rise parameter is calculated with self-tuning

The simultaneous temperature rise parameter calculated with self-tuning is effective. Then PID constants are changed with auto tuning.




# (c) When CH□ Auto tuning instruction (Yn4 to Yn7) is turned off and on in the setting mode and the module is shifted to the operation mode

After the module is shifted to the operation mode (Setting/operation mode instruction (Yn1) is turned off and on), the simultaneous temperature rise parameter and PID constants are changed with auto tuning.



# (d) When auto tuning is started with the temperature process value (PV) within the stable judgment width (1°C (°F)) after the setting mode is changed to the operation mode

Until the temperature process value (PV) goes outside the stable judgment width (1°C (°F)), the data measured after the module is shifted to the operation mode (Setting/operation mode instruction (Yn1) is turned off and on) can be used. Therefore, the simultaneous temperature rise parameter can be calculated with auto tuning.



### 8.2.18 Forward/reverse action selection function



Whether PID operation is performed with forward action or reverse action can be selected using this function. This function can be used in all the control methods (two-position control, P control, PI control, PD control, and PID control). (Page 129, Section 8.2.3)


For details on the operation, refer to the following.

Page 24, Section 1.4.2

### (1) Setting method

Set the function under "Forward/reverse action setting".

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]



### 8.2.19 Loop disconnection detection function



Using this function detects an error occurring within a control system (control loop) due to reasons such as a load (heater) disconnection, an externally-operable device (such as a magnetic relay) failure, and input disconnection.

### (1) How an error is detected

Since the time a PID operation value becomes 100% or 0%, the amount of changes in the temperature process value (PV) is monitored every unit time and disconnection of a heater and input is detected.

### (2) Examples of the errors detected

The following are the examples of the errors detected.

### (a) When control output is being performed

The L60TC4 detects an error because the temperature does not rise even when control output is being performed under the following conditions:

- · When a heater is disconnected
- · When input is disconnected or short-circuited
- · When the contact point of an externally-operable device does not turn on

After control output is output 100%, an alert is output if the temperature does not rise by 2°C (°F) or more within the loop disconnection detection judgment time set (forward action is changed to reverse action). (FFP Page 203, Section 8.2.18))

### (b) When control output is not being performed

The L60TC4 detects an error because the temperature rises even when control output is not being performed under the following conditions:

- · When input is disconnected
- · When the contact point of an externally-operable device was bonded

After control output drops to 0%, an alert is output if the temperature does not drop by 2°C (°F) or more within the loop disconnection detection judgment time set (forward action is changed to reverse action). (Fig. Page 203, Section 8.2.18))


#### (3) Setting method

Two settings are available for the loop disconnection detection function.

# (a) Setting for the unit time to monitor the amount of changes in the temperature process value (PV)

Set the unit time under "Loop disconnection detection judgement time".

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]





When not using this function, set CH□ Loop disconnection detection judgment time (Un\G59, Un\G91, Un\G123, Un\G155) to 0.

### (b) Setting for the dead band

Set the dead band under "Loop disconnection detection dead band".

Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]






When the loop disconnection detection dead band is set, loop disconnection does not occur even if the temperature does not change by  $2^{\circ}$ C ( $^{\circ}$ F) or more with the set value (SV) 100% or 0% of control output.

# 8.2.20 Proportional band setting function



Proportional band (P) values can be set for heating and cooling separately using this function. Different gradients can be set by using different proportional band (P) values in a heating and cooling area.



### (1) Setting method

### (a) For heating

Set the value under "Proportional band (P) setting/Heating control proportional band setting (Ph)".

Converse Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Parameter]



### (b) For cooling

Set the value under "Cooling proportional band (Pc) setting".

Project window 🖒 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]



# 8.2.21 Cooling method setting function




An auto tuning calculation formula is automatically selected according to the selected cooling method during auto tuning and the operation is started using this function.

Select one of the following characteristics:

- Air Cooled: The cooling characteristic is nonlinear and cooling ability is low.
- Water Cooled: The cooling characteristic is nonlinear and cooling ability is high.
- · Linear: The cooling characteristic is close to the linear shape.

Cooling characteristics (rate of when the manipulated value for cooling (MVc) 100% is 1)

Cooling system and cooling characteristics



PID constants are calculated and executed based on this setting during auto tuning; therefore, more appropriate PID constants can be found by setting more applicable cooling characteristic of a device.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

### (1) Setting method

Set the characteristic under "Cooling method setting".

Project window 🖒 [Intelligent Function Module] 🖒 Module name 🖒 [Parameter]



### Point P

- An auto tuning calculation formula to find PID constants is determined based on this setting; therefore, configure this setting before executing auto tuning.
- "Air Cooled" and "Water Cooled" roughly indicate the level of the cooling ability. When a device is too cooled even if it is set to Air Cooled, set the module to Water Cooled (1H). When a device is not very cooled even if it is set to Water Cooled, set the module to Air Cooled (0H).
- In general, the ability of water cooling is higher than that of air cooling and cooling may be too strong if the same PID constants as air cooling are used. Some time is required until the control becomes stable upon the initial start-up, disturbance, or setting change. Therefore, in auto tuning, PID constants for when the module is set to Water Cooled (1H) become larger than those for when the module is set to Air Cooled (0H).

## 8.2.22 Overlap/dead band function



In heating-cooling control, the temperature process value (PV) significantly changes due to slight heating or cooling control output when the heat produced by a controlled object and natural cooling are being balanced. Consequently, excessive output may be performed.

The temperature where the cooling control output starts can be shifted using this function; therefore, whether control stability is prioritized or energy saving is prioritized can be selected.

### (1) Overlap


Overlap refers to the temperature area where both of heating control and cooling control are performed. In the temperature area where both heating and cooling output overlap, both of the output negate each other, thus the control gain becomes moderate. Consequently, the change amount in the temperature process value (PV) for the output becomes small, improving control stability.

- Ex. When buffer memory values are set as following:
- CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (temperature measurement range: -200.0°C to 400.0°C)
- CH□ Set value (SV) setting (Un\G34, Un\G66, Un\G98, Un\G130): 2000 (200.0°C)
- CH□ Overlapping/dead band setting (Un\G723, Un\G739, Un\G755, Un\G771): -25 (-2.5%) 185.0°C to 200.0°C is the overlapping area.

(Full scale) × (Overlap setting) =  $(400.0^{\circ}\text{C} - (-200.0^{\circ}\text{C})) \times -0.025 = -15.0^{\circ}\text{C}$ 

The temperature where cooling operation starts = (Set value (SV)) - 15.0°C = 185.0°C

As shown below, shifting the temperature where cooling operation starts to the lower temperature side of the set value (SV) produces an overlapping area. (The following is an example of when the module is in P control.)



### (2) Dead band


Dead band refers to the temperature area where neither heating control output nor cooling control output is performed. When the temperature process value (PV) is stable within this area, output is not performed for the slight change in the temperature, resulting in energy saving.

- Ex. When buffer memory values are set as following:
  - CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (temperature measurement range: -200.0°C to 400.0°C)
  - CH□ Set value (SV) setting (Un\G34, Un\G66, Un\G98, Un\G130): 2000 (200.0°C)
  - CH□ Overlapping/dead band setting (Un\G723, Un\G739, Un\G755, Un\G771): 25 (2.5%) 200.0°C to 215.0°C is the area for dead band.

(Full scale) × (Overlap setting) =  $(400.0^{\circ}\text{C} - (-200.0^{\circ}\text{C})) \times 0.025 = 15.0^{\circ}\text{C}$ 

The temperature where cooling operation starts = (Set value (SV)) + 15.0°C = 215.0°C


As shown below, shifting the temperature where cooling operation starts to the higher temperature side of the set value (SV) produces a dead band area. (The following is an example of when the module is in P control.)



### (3) Dead band setting in two-position control (three-position control)

Set the dead band in two-position control.

Three-position control can be achieved by setting a dead band area in addition to areas for the manipulated value for heating (MVh) 100% and the manipulated value for cooling (MVc) 100%.



### (4) Setting method

Set the function under "Overlap/dead band setting".

Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  Module name  $\Leftrightarrow$  [Parameter]



# 8.2.23 Temperature conversion function (using unused channels)



In heating-cooling control (normal mode) and mix control (normal mode), only temperature measurement can be performed by using unused temperature input terminals. When this function is used, temperature control and alert judgment are not performed.

### (1) Temperature input terminals that can be used

Temperature input terminals that can be used for this function differ depending on the control mode. Use the terminals indicating MT2 $\square$  (Monitor CH2), MT3 $\square$  (Monitor CH3), and MT4 $\square$  (Monitor CH4) in the following table.

	Terminal symbol				
	L60TCTT4/L	.60TCTT4BW <sup>*1</sup>	L60TCRT4/L60TCRT4BW <sup>*1</sup>		
Terminal No.	Heating-cooling control (normal mode)	Mix control (normal mode)	Heating-cooling control (normal mode)	Mix control (normal mode)	
1	L1H	L1H	L1H	L1H	
2	L1C	L1C	L1C	L1C	
3	L2H	L3	L2H	L3	
4	L2C	L4	L2C	L4	
5	COM-	COM-	COM-	COM-	
6	Unused	Unused	Unused	Unused	
7	CH1+	CH1+	CH1 A	CH1 A	
8	CH2+	MT2+	CH2 A	MT2 A	
9	CH1-	CH1-	CH1 B	CH1 B	
10	CH2-	MT2-	CH2 B	MT2 B	
11	Unused	Unused	CH1 b	CH1 b	
12	Cl	CJ	CH2 b	MT2 b	
13	Unused	Unused	МТЗА	CH3 A	
14	CJ	Cl	MT4A	CH4 A	
15	MT3+	CH3+	МТ3В	СН3 В	
16	MT4+	CH4+	MT4B	CH4 B	
17	MT3-	CH3-	MT3b	CH3 b	
18	MT4-	CH4-	MT4b	CH4 b	

<sup>\*1</sup> For the L60TCTT4BW and L60TCRT4BW, the terminals in the table above are those on a terminal block for I/O.

### (2) Current consumption of when this function is used

Current consumption differs depending on whether the temperature conversion function is used or not.

### (3) Buffer memory areas that can be used with this function

The following table lists the buffer memory areas that can be used with this function (the terminals used correspond to the buffer memory areas in the table).

Duffer memory even neme		Poforonoo		
Buffer memory area name	MT2 (Monitor CH2)	MT3 (Monitor CH3)	MT4 (Monitor CH4)	Reference
Error code		Un\G0		Page 334, Appendix 2 (1)
CH□ Decimal point position	Un\G2	Un\G3	Un\G4	Page 334, Appendix 2 (2)
CH□ Alert definition	Un\G6	Un\G7	Un\G8	Page 336, Appendix 2 (3)
CH□ Temperature process value (PV)	Un\G10	Un\G11	Un\G12	Page 338, Appendix 2 (4)
Cold junction temperature process value		Un\G29		Page 342, Appendix 2 (9)
CH□ Input range	Un\G64	Un\G96	Un\G128	Page 345, Appendix 2 (12)
CH□ Sensor correction value setting	Un\G77	Un\G109	Un\G141	Page 363, Appendix 2 (21)
CH□ Primary delay digital filter setting	Un\G80	Un\G112	Un\G144	Page 365, Appendix 2 (24)
Cold junction temperature compensation selection		Un\G182		Page 384, Appendix 2 (49)
Control switching monitor		Un\G183		Page 385, Appendix 2 (50)
CH□ 2-point sensor compensation offset value (measured value)	Un\G576	Un\G608	Un\G640	Page 394, Appendix 2 (63)
CH□ 2-point sensor compensation offset value (compensation value)	Un\G577	Un\G609	Un\G641	Page 394, Appendix 2 (64)
CH□ 2-point sensor compensation gain value (measured value)	Un\G578	Un\G610	Un\G642	Page 395, Appendix 2 (65)
CH□ 2-point sensor compensation gain value (compensation value)	Un\G579	Un\G611	Un\G643	Page 395, Appendix 2 (66)
CH□ 2-point sensor compensation offset latch request	Un\G580	Un\G612	Un\G644	Page 396, Appendix 2 (67)
CH□ 2-point sensor compensation offset latch completion	Un\G581	Un\G613	Un\G645	Page 396, Appendix 2 (68)
CH□ 2-point sensor compensation gain latch request	Un\G582	Un\G614	Un\G646	Page 397, Appendix 2 (69)
CH□ 2-point sensor compensation gain latch completion	Un\G583	Un\G615	Un\G647	Page 397, Appendix 2 (70)
Sensor compensation function selection		Un\G785		Page 413, Appendix 2 (91)
Temperature conversion completion flag		Un\G786		Page 413, Appendix 2 (92)
CH□ Temperature conversion setting	Un\G695	Un\G696	Un\G697	Page 403, Appendix 2 (76)

### (4) Setting method

Set whether using this function under "Temperature conversion setting".

Project window <> [Intelligent Function Module] <> Module name <> [Parameter]

Item	CH1	CH2
Temperature conversion		0:Not Used
Cooling method setting	0:Air Cooled	0:Not Used
Cooling upper limit output limiter	100.0 %	1:Use



When heating-cooling control (expanded mode) or mix control (expanded mode) is selected, the setting in CH $\square$  Temperature conversion setting (Un\G695 to Un\G697) is ignored.

### 8.2.24 Heater disconnection detection function



When transistor output is on, whether a heater is disconnected or not can be checked based on a reference heater current value (load current value detected by a current sensor (CT)) using this function. A reference heater current value and heater disconnection alert current value are compared. When the reference heater current value becomes lower than the heater disconnection alert current value, the heater is regarded as disconnected.

Heater disconnection is detected every 500ms. When transistor output is on for 500ms or less, heater disconnection is not detected. (CH $\square$  Heater disconnection detection (b12 of Un\G5 to Un\G8) remains 0 (OFF).) (FF Page 336, Appendix 2 (3))

The following is the timing output as an alert.

• 500ms × Setting value in Heater disconnection/output off-time current error detection delay count (Un\G166) If a heater is disconnected longer than the time described above, Alarm code: 04□AH is stored in Error code (Un\G0). (FP Page 318, Section 11.7)


#### (1) Modules where this function can be used

- L60TCTT4BW
- L60TCRT4BW

#### (2) Setting method


Set the function on "Parameter". Follow the instructions below.

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]




Set the current sensor (CT) to be used under "CT


CT selection".




 When using a current sensor (CT) other than CTL-12-S36-8 and CTL-6-P(-H) manufactured by U.R.D.Co., LTD., set "CT□ CT Ratio setting".




Set the CT input assigned to each channel under "CT CT input channel assignment setting".





4. Monitor CT□ Heater current process value (Un\G256 to Un\G263) and check the current value of when the heater is on. ( Page 390, Appendix 2 (58))



5. Set the value monitored in CT□ Heater current process value (Un\G256 to Un\G263) under "CT□ Reference heater current value".




6. Set the judgment value to perform the heater disconnection detection and output off-time current error detection\*¹ at the rate of the reference heater current value (%) under "Heater disconnection alert setting".



 $\downarrow$ 

 $\downarrow$ 

7. To monitor only the current value of when the heater is on, set "1: ON Current" under "CT monitor method switching". To monitor the current values of when the heater is on and off, set "0: ON/OFF Current".



8. Set how many times heater disconnection is detected successively to regard the heater as disconnected under "Heater disconnection/output off-time current error detection delay count".

\*1 For details on the output off-time current error detection function, refer to FP Page 220, Section 8.2.25.

### Point P

- The standard setting value for CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154) is 80%.
  However, the current value may significantly change depending on the characteristics of a heater or how the heater is used. Check that there is no problem in the actual system.
- A write data error (error code: □□□4<sub>H</sub>) occurs if the current value to be used as a judgment value to detect heater disconnection (reference heater current value × CH□ Heater disconnection alert setting (%)) is within 0.1A under one of the following situations:
  - CT CT selection (Un\G272 to Un\G279) is set to When CTL-12-S36-8 (0.0A to 100.0A) is used (0).
  - CT CT selection (Un\G272 to Un\G279) is set to When CT ratio setting is used (0.0A to 100.0A) (2). In addition, when CTL-6-P(-H) used (0.00A to 20.00A) (1) has been set and the current value to be used as a judgment value to detect heater disconnection (reference heater current value × CH Heater disconnection alert setting (%)) is within 0.01A, Write data error (error code: DD4H) occurs.

#### (3) Heater disconnection correction function

When heater voltage is dropped, heater current is reduced. The L60TCTT4BW and L60TCRT4BW detect heater disconnection by measuring heater current; therefore, an accidental alert may occur due to a voltage change caused by a reduced heater voltage.

The heater disconnection correction function offsets the amount of heater current reduced (heater disconnection correction), preventing disconnection from being detected.

#### (a) Calculation formula for heater disconnection correction

Calculate (CH $\square$  Heater current) - (reference heater current value). The largest positive value is the correction value. When there is no positive value, the value with the smallest gap is the correction value. The heater current for each channel is corrected using a correction value. When the corrected value is larger than the heater disconnection alert setting value, heater disconnection is found.

When CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154) is 80% and the differences between CH□ Heater current and the reference heater current value are the following values:

- CH1: -2%
- CH2: 5%
- CH3: -1%
- CH4: -17%

The following table lists the result.

Channel	CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154)	Difference between CH□ Heater current and reference heater current value	Correction value	Difference between CH□ Heater current and reference heater current value after correction	Disconnection detected
CH1		-2%		-7% (= -2% - 5%)	Not detected
CH2	80 (%)	5%	5%	0% (= 5% - 5%)	Not detected
CH3	00 (70)	-1%	570	-6% (= -1% - 5%)	Not detected
CH4		-17%		-22% (= -17% - 5%)	Detected

In the table above, the correction value is 5%. Heater disconnection is detected based on the differences of -7% for CH1, 0% for CH2, -6% for CH3, and -22% for CH4. When Heater disconnection alert setting is set to 80%, disconnection is detected only for CH4.

Ex. When CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154) is 80% and the differences between CH□ Heater current and the reference heater current value are the following values:

• CH1: -16%

• CH2: -17%

· CH3: -22%

• CH4: -19%

The following table lists the result.

Channel	CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154)	Difference between CH□ Heater current and reference heater current value	Correction value	Difference between CH□ Heater current and reference heater current value after correction	Disconnection detected
CH1	011(G122, 011(G134)	-16%		0% (= -16% - (-16%))	Not detected
CH2	90 (9/)	-17%	-16%	-1% (= -17% - (-16%))	Not detected
CH3	80 ( <b>%</b> )	-22%	-10%	-6% (= -22% - (-16%))	Not detected
CH4		-19%		-3% (= -19% - (-16%))	Not detected

In the table above, the correction value is -16%. Heater disconnection is detected based on the differences of 0% for CH1, -1% for CH2, -6% for CH3, and -3% for CH4. When Heater disconnection alert setting is set to 80%, none of the channels are regarded as disconnected.

#### (b) Restrictions

- When only one channel is used, the heater disconnection correction function does not work. To use this
  function, two channels or more need to be used.
- When several channels are used with a heater on for one channel and heaters off for other channels, the
  heater disconnection correction function does not function. Therefore, disconnection may be detected
  even if there is no disconnection.
- The heater disconnection alert correction value is 20% at maximum. When Heater disconnection alert setting is set to 80% as shown in the two examples on Page 217, Section 8.2.24 (3) (a), the conditions for disconnection detection are satisfied even if correction is performed by 20% with a voltage drop by 40% or more. Consequently, disconnection is detected.

#### (c) Setting method

Set "Heater disconnection compensation function selection" to "1: ON".

Project window <> [Intelligent Function Module] <> Module name <> [Parameter]



#### (4) To clear the disconnection detection status

Disconnection detection is disabled by restoring the disconnection status and turning CH $\square$  Heater disconnection detection (b12 of Un\G5 to Un\G8) from 1 (ON) to 0 (OFF). (Fig. Page 336, Appendix 2 (3)) Under the following setting, however, CH $\square$  Heater disconnection detection (b12 of Un\G5 to Un\G8) does not change from 1 (ON) to 0 (OFF) unless a heater turns on.

• CT monitor method switching (Un\G176) is set to ON Current (1).

The timing when a heater turns on differs depending on the setting for the following buffer memory areas.

Buffer memory area name	Buffer memory address				Reference
Bullet memory area name	CH1	CH2	CH3	CH4	Reference
CH□ Control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	
CH□ Heating control output cycle setting	Un\G47	Un\G79	Un\G111	Un\G143	Page 364, Appendix 2 (23)
CH□ Cooling control output cycle setting	Un\G722	Un\G738	Un\G754	Un\G770	

## 8.2.25 Output off-time current error detection function



Transistor output errors can be detected using this function. The current sensor (CT) for heater disconnection detection is used to check for errors of when transistor output is off.

A heater current measurement value and heater disconnection alert current value are compared. If the heater current measurement value is larger than the heater disconnection alert current value, an output off-time current error occurs. Output off-time current errors are detected every 500ms. When transistor output is off for 500ms or less, output off-time current errors are not detected. (CH $\square$  Output off-time current error (b14 of Un\G5 to Un\G8) stays 0 (OFF).) (Page 336, Appendix 2 (3))

The following is the timing output as an alert.

• 500ms × Setting value for Heater disconnection/output off-time current error detection delay count (Un\G166)

If an output off-time current error status lasts longer than the time described above, Alarm code  $(05\Box A_H)$  is stored in Error code (Un\G0). (Fig. Page 318, Section 11.7)

#### (1) Modules where this function can be used

- L60TCTT4BW
- L60TCRT4BW

#### (2) Setting method

The setting method is the same as that for the heater disconnection detection function. (Fig. Page 215, Section 8.2.24)

### 8.3 Common Functions

This section explains the common functions between the temperature input mode and temperature control mode.

### 8.3.1 Temperature process value (PV) scaling function



The temperature process value (PV) is scaled up or down to the value in a set range, and can be stored into the buffer memory using this function. For example, the range of -100°C to 100°C can be scaled into the value range of 0 to 4000.

#### (1) Monitoring the scaling value

The temperature process value (PV) after scaling processing is stored into the following buffer memory area.

CH□ Process value (PV) scaling value (Un\G728, Un\G744, Un\G760, Un\G776) (FF Page 406, Appendix 2 (82))

The calculation method of a scaling value is as follows:

$$\begin{array}{lll} \text{CH} \square \text{ Process value (PV) scaling value} \\ \text{(Un\G728, Un\G744, Un\G760, Un\G776)} \end{array} &=& \frac{\left(\text{SH-SL}\right) \times \left(\text{Px-PMin}\right)}{\text{PMax-PMin}} + \text{SL} \\ \end{array}$$

Px: CH  $\Box$  Temperature process value (PV) (Un\G9, Un\G10, Un\G11, Un\G12)

PMax: A maximum value of CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)

PMin: A minimum value of CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)

SH: CH A maximum scaling value of process value (PV) (Un\G727, Un\G743, Un\G759, Un\G775)

SL: CH A minimum scaling value of process value (PV) (Un\G726, Un\G742, Un\G758, Un\G774)

#### (a) Calculation example

A calculation example to scale the temperature process value (PV) into percentage is shown below. Set the following buffer memory areas as below.

- CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (Temperature measurement range: -200.0°C to 400.0°C)
- CH Process value (PV) scaling lower limit value (Un\G726, Un\G742, Un\G758, Un\G774): 0
- CH Process value (PV) scaling upper limit value (Un\G727, Un\G743, Un\G759, Un\G775): 100

Suppose that 3600 (360.0°C) is stored in CHI Temperature process value (PV) (Un\G9 to Un\G12).


The scaling value can be calculated as follows:

CH
$$\square$$
 Process value (PV) scaling value (Un\G728, Un\G744, Un\G760, Un\G776) = 
$$\frac{(100 - 0) \times (3600 - (-2000))}{4000 - (-2000)} + 0$$
= 93.333 ···
= 93 (All decimal places are rounded off to an integer.)

#### (2) Setting method

Set the function on "Parameter". Follow the instructions below.

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  Module name  $\Rightarrow$  [Parameter]



End

- Enable or disable the temperature process value (PV) scaling function under "Process value (PV) scaling function enable/disable setting".
- Set a scaling upper limit value and lower limit value under "Process value (PV) scaling lower limit value" and "Process value (PV) scaling upper limit value".

#### Point P

- An error does not occur even though the areas above are set as follows: Lower limit value ≥ Upper limit value. The scaling is processed according to the calculation method described on Page 221, Section 8.3.1 (1).
- If a value outside the temperature measurement range is measured, the value set as a upper limit or lower limit is stored into the following buffer memory area.
  - CH□ Process value (PV) scaling value (Un\G728, Un\G744, Un\G760, Un\G776) (☐ Page 406, Appendix 2 (82))
- Values on other analog modules in the system (such as an A/D converter module) can be scaled to a set range. For that processing, set a 200s value in CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128). (☐ Page 345, Appendix 2 (12))

To input a value from other analog modules (such as an A/D converter module), store the input value into the following buffer memory area.

• CH□ Temperature process value (PV) for input with another analog module (Un\G689 to Un\G692) (□ Page 402, Appendix 2 (74))

To scale an input value from other analog modules (such as an A/D converter module), apply the buffer memory area above to the description in this section.

### 8.3.2 Sensor compensation function



When a difference occurs between the temperature process value (PV) and the actual temperature due to reasons such as a measuring condition, the difference can be corrected using this function. The following two types are available.

- 1-point sensor compensation (standard) function (FP Page 223, Section 8.3.2 (1))
- 2-point sensor compensation function (FP Page 227, Section 8.3.2 (2))


#### (1) 1-point sensor compensation (standard)

The set input range in proportion to the full scale is corrected as a difference correction value using this function.


- Ex. When buffer memory values are set as following:
- CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 21 (temperature measurement range: -200.0°C to 200.0°C)
- CH□ Sensor correction value setting (Un\G45, Un\G77, Un\G109, Un\G141): 50 (0.500%)

  The difference between the temperature process value (PV) and the actual temperature is 2°C that can be corrected.

Temperature process value (PV) - actual temperature =  $\frac{\text{Full scale} \times \text{Sensor correction value setting}}{100}$  $= \frac{400 \times 0.500}{100} = 2 \text{ (°C)}$ 



- (a) How to execute 1-point sensor compensation (standard) (when using GX Works2) Set the setting on the "Sensor Compensation Function" window.
  - [Tool] ⇔ [Intelligent Function Module Tool] ⇔ [Temperature Control Module] ⇔ [Sensor Compensation Function]




 Select the module where sensor correction is executed and click OK.




2. Click <u>Yes</u>.



3. Click OK



4. Select the channel where sensor correction is executed under "Target Channel".




<u>Y</u>es

Νo

(To the next page)

225



(b) How to execute 1-point sensor compensation (standard) (when using the program)


Follow the instructions below.

- Set 1-point sensor compensation (standard) (0<sub>H</sub>) in Sensor compensation function selection (Un\G785). (FP Page 413, Appendix 2 (91))
- 2. Set the correction value in CH□ Sensor correction value setting (Un\G45, Un\G77, Un\G109, Un\G141). (☐ Page 363, Appendix 2 (21))

#### (2) 2-point sensor compensation function

With this function, the difference between the temperature process value (PV) and the actual temperature between the two points selected in advance (a corrected offset value and a corrected gain value) is stored. Based on this gradient, the difference between a sensor and the actual temperature is corrected.


2-point sensor compensation is performed in the setting mode (Setting/operation mode status (Xn1): off). In addition, set CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) to Monitor (1).




#### (a) How to execute 2-point sensor compensation (when using GX Works2)

Set this function on the "Sensor Compensation Function" window.

[Tool] ⇔ [Intelligent Function Module & Tool] ⇔ [Temperature Control Module] ⇔ [Sensor Compensation Function]




1. Select the module where sensor correction is executed and click .




2. Click Yes



3. Click OK.



Select the channel where sensor correction is executed under "Target Channel".






- **6.** Monitor "Temperature process value (PV)" and enter the corrected offset value.\*1
- 7. Set the Temperature process value (PV) to be input under "Compensation Offset Value". Then click

  Offset Setting .
- 8. Click Yes.





- 10. Monitor "Temperature process value (PV)" and enter the corrected gain value.\*1
- 11. Set the temperature process value (PV) to be input under "Compensation Gain Value". Then click

  Gain Setting



Offset setting completed.






\*1 Enter the value using devices such as a thermocouple, platinum resistance thermometer, and standard DC voltage generator, or based on a general resistance value.

#### (b) How to execute 2-point sensor compensation (when using the program)

Follow the instructions below.



- \*1 Enter the value using devices such as a thermocouple, platinum resistance thermometer, and standard DC voltage generator, or based on a general resistance value.
- \*2 When the latch is completed, the temperature process value (PV) is stored in CH□ 2-point sensor compensation offset value (measured value) (Un\G544, Un\G576, Un\G608, Un\G608). (☐ Page 394, Appendix 2 (63))
- \*3 When the latch is completed, the temperature process value (PV) is stored in CH□ 2-point sensor compensation gain value (measured value) (Un\G546, Un\G578, Un\G610, Un\G642). (☐ Page 395, Appendix 2 (65))

### Point P

- If a write data error (error code: □□□7<sub>H</sub>) occurs during 2-point sensor compensation, correctly configure the setting for 2-point sensor compensation again. (The value set for 2-point sensor compensation of when an error occurred is not written in the L60TC4.)
- To use the value set for 2-point sensor compensation even after the power is turned off and on or the CPU module is reset and the reset is cancelled, back up the value with the following method.
  - Turn off and on Setting value backup instruction (Yn8). (FPage 332, Appendix 1.2 (3))

### 8.3.3 Auto configuration at input range change function




When an input range is changed, using this function automatically changes related buffer memory data to prevent an error outside the setting range. Set the function on the "Switch Setting" window.

For details on the setting method, refer to the following.

Page 108, Section 7.2

The following is the setting timing.



<sup>11</sup> This value differs depending on the setting under "Sampling Cycle Selection". ( Page 109, Section 7.2 (1) (b))

#### (1) Buffer memory automatically set

Refer to Page 351, Appendix 2 (12) (d).

## 8.3.4 Buffer memory data backup function



This function allows buffer memory data to be stored in the non-volatile memory and backed up.

The backed-up data is transferred from the non-volatile memory to the buffer memory when the power is turned off and on or the CPU module is reset and the reset is cancelled. Therefore, temperature can be controlled without writing data when the power is turned off and on or the CPU module is reset and the reset is cancelled.

#### (1) Applicable buffer memory areas

Refer to the buffer memory assignment list.

Page 44, Section 3.5

#### (2) Data write to non-volatile memory


This function can be used to back up data directly written in the buffer memory using the PID constants set with the auto tuning function and the programming tool. When data is written to non-volatile memory and the power is turned off and on or the CPU module is reset and the reset is cancelled, the buffer memory setting value is not required to be set again.



For the function that allows PID constants to be automatically backed up after auto tuning, refer to Page 143, Section 8.2.7 (4).

To write data to non-volatile memory, turn off and on Setting value backup instruction (Yn8).

When data write to the non-volatile memory is completed, Backup of the set value completion flag (Xn8) turns on.



If data write to non-volatile memory does not complete, Backup of the set value fail flag (XnA) turns on.

#### (a) Setting change

Change the settings for buffer memory areas when Backup of the set value completion flag (Xn8) is off.

#### (3) Data read from non-volatile memory

Follow the instructions below.

- Turn off and on the power or reset the CPU module and cancel the reset.
- Set CH
   — Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) to Requested
   (1). (FP Page 377, Appendix 2 (36)) Data to be read are the PID constants and loop disconnection
   detection judgment time for the corresponding channel only. (FP Page 374, Appendix 2 (33))

## 8.3.5 Error history function



The error or alert occurred with the L60TC4 is stored in the buffer memory areas (Un\G1280 to Un\G1404) as history. Up to 16 error history data can be stored.

#### (1) Processing of the error history function


An error code and error occurrence time are stored starting from Error history No.1 (the start address is Un\G1280).

#### (2) How to check error history

The start address of the error history where the latest error is stored can be checked in Latest address of error history (Un\G1279).


Ex. If the third error occurred:

The third error is stored in Error history No.3 and 1296 (the start address of Error history No.3) is stored in Latest address of error history (Un\G1279).



#### Ex. If the 17th error occurred:

The 17th error is stored in Error history No.1 and 1280 (the start address of Error history No.1) is overwritten in Latest address of error history (Un\G1279).



#### Point P

- The same processing is performed for an alarm.
- When the storage area for error histories is full, data is overwritten starting from Error history No.1 (Un\G1280 to Un\G1284) and error history recording is continued. (The history before data overwritten is deleted.)
- Recorded error histories are cleared to 0 by turning off and on the power supply or by resetting the CPU module and canceling the reset.


## 8.3.6 Module error history collection function



The errors and alarms occurred with the L60TC4 are collected into the CPU module.

The CPU module keeps the error information collected from the L60TC4 as a module error history in the memory where data is maintained even at the time of the power failure. Therefore, the information of the errors occurred with the L60TC4 can be kept even if the power is turned off and on or the CPU module is reset and the reset is cancelled.

#### (1) Example of the operation of the module error history collection function





For details on the module error history collection function, refer to the following.

MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)

### 8.3.7 Error clear function




When an error occurs, the error can be cleared on the system monitor.

Clicking the Error Glear button on the system monitor clears the error code stored in Error code (Un\G0) and turns off the ERR.LED. The operation is the same as when an error is cleared using Error reset instruction (Yn2). However, the error history is not cleared.

For how to clear an error using Error reset instruction (Yn2), refer to the following.

- Error reset instruction (Yn2) (FP Page 331, Appendix 1.2 (2))
  - [Diagnostics]  $\Rightarrow$  [System Monitor...]  $\Rightarrow$  The module where an error occurred



## CHAPTER 9 DISPLAY UNIT

This chapter describes the functions of the display unit that can be used with the L60TC4.

For details on how to operate the display unit, the functions, and menu structure, refer to the following manual.

MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)

## 9.1 Display Unit

The display unit is an LCD display to be attached to the CPU module. By attaching it to the CPU module, the following operations can be performed without using any software package.

- · Checking the system status
- Changing system set values (only for use as a temperature input module)

When a problem occurs, the cause of the problem can be identified by the displayed error information.

For details on how to check and clear errors from the display unit, refer to the following.


• Checking and clearing errors ( Page 248, Section 9.4)

Remark	• • • • • • • • • • • • • • • •	• • • • • • • • • • • •	• • • • • • • • • • • •
To change system setting values	s in temperature control mode, use	GX Works2. (FF Page 1	07, CHAPTER 7)

### 9.2 Menu Transition


#### (1) Structure list

The following is the menu structure of "MOD MON/TEST" menu and "MOD SETTINGS" menu.



#### (2) Screen transition to the initial setting change screen

The following figure shows the screen transition to the initial setting change screen.



# 9.3 Setting Value Change Screen List

The following table shows the setting value change screen list.


### (1) Displayed in English


Name			Input limits	
Setting item	Screen display	Screen format	Upper limit value	Lower limit value
Conversion enable/disable setting	CONVERSION	Selection	_	_
Primary delay digital filter setting	PRMRY DLY FLTR	Numeric	100	0
Process alarm alert output enable/disable setting	PROCESS ALARM	Selection	_	_
Process alarm upper upper limit value	PRALARM UPR/UPR	Numeric	32767	-32768
Process alarm upper lower limit value	PRALARM UPR/LWR	Numeric	32767	-32768
Process alarm lower upper limit value	PRALARM LWR/UPR	Numeric	32767	-32768
Process alarm lower lower limit value	PRALARM LWR/LWR	Numeric	32767	-32768
Rate alarm alert output enable/disable setting	RTALARM	Selection	_	_
Rate alarm alert detection period	RTALM DTCT PRD	Numeric	6000	1
Rate alarm upper limit value	RTALARM UP LMT	Numeric	32767	-32768
Rate alarm lower limit value	RTALARM LOW LMT	Numeric	32767	-32768
Process value (PV) scaling function enable/disable setting	SCALING	Selection	_	_
Process value (PV) scaling upper limit value	SCALE UP LMT	Numeric	32000	-32000
Process value (PV) scaling lower limit value	SCALE LOW LMT	Numeric	32000	-32000
Cold junction temperature compensation selection	CJ SELECTION	Selection	_	_

#### (2) Conversion enable/disable setting

Select "DISABLE or "ENABLE" in the "Conversion enable and disable setting" screen.

"Conversion enable and disable setting" screen






 Use the ▲ and ▼ buttons to select "DISABLE" or "ENABLE", then make a confirmation with the Jok button.

#### (3) Primary delay digital filter setting

Set the time constant for the primary delay digital filter in the "Primary delay filter" screen.

"Primary delay filter" screen





Move the cursor using the 

 and buttons, then increment or decrement the value at the cursor, using the and buttons, respectively. Make a confirmation with the button.

Table of input items

Input item	Input range			
input item	Input upper limit	Input lower limit		
Primary delay filter	100	0		

#### (4) Process alarm setting

Select "DISABLE or "ENABLE" in the "Process alarm setting" screen.

"Process alarm setting" screen

プロセスアラーム設定 ・禁止 ・許可 PROCESS ALARM
DISABLE
ENABLE

"Process alarm upper upper limit" screen

プロセスアラーム上上限 01300 PRALARM UPR/UPR
01300

"Process alarm upper lower limit" screen

プロセスアラーム上下限 01300 PRALARM UPR/LWR
01300


"Process alarm lower upper limit" screen

7゚ロセスアラーム下上限 000000

PRALARM LWR/UPR
00000

"Process alarm lower lower limit" screen

プ<sup>°</sup>ロセスアラーム下下限 00000



- Use the ▲ and ▼ buttons to select "DISABLE" or "ENABLE", then make a confirmation with the Jok button. (If "ENABLE" is selected, proceed to step 2.)
- 2. Move the cursor using the 

  and buttons, then increment or decrement the value at the cursor, using the and buttons, respectively. Make a confirmation with the button.
- 3. Move the cursor using the 

  and buttons, then increment or decrement the value at the cursor, using the 

  and buttons, respectively. Make a confirmation with the 

  ox button.
- 4. Move the cursor using the 

  and buttons, then increment or decrement the value at the cursor, using the 

  and buttons, respectively. Make a confirmation with the 

  buttons.
- 5. Move the cursor using the 

  and buttons, then increment or decrement the value at the cursor, using the 

  and buttons, respectively. Make a confirmation with the 

  button.

#### Table of input items

Input item	Input range		
input item	Input upper limit	Input lower limit	
Process alarm upper upper limit			
Process alarm upper lower limit	32767	-32768	
Process alarm lower upper limit	32707	-32706	
Process alarm lower lower limit			

#### (5) Rate alarm setting

Select "DISABLE" or "ENABLE" in the "Rate alarm setting" screen.

"Rate alarm setting" screen

レ-トアラーム設定 ・禁止 ・許可 RTALARM
• DISABLE
• ENABLE

"Rate alarm detection period" screen

レートアラーム検出周期 0001

RTALM DTCT PRD 0001


↓
"Rate alarm upper limit" screen

レートアラーム上限 000000

RTALARM UP LMT 00000

↓
"Rate alarm lower limit" screen

レートアラーム下限 000000



 Use the ▲ and ▼ buttons to select "DISABLE" or "ENABLE", then make a confirmation with the ok button. (If "ENABLE" is selected, proceed to step 2.)

2. Move the cursor using the 

and buttons, then increment or decrement the value at the cursor, using the 

and buttons, respectively. Make a confirmation with the 

button.

3. Move the cursor using the 

and buttons, then increment or decrement the value at the cursor, using the 

and buttons, respectively. Make a confirmation with the 

buttons.

4. Move the cursor using the 

and 

buttons, then increment or decrement the value at the cursor, using the 

and 

buttons, respectively. Make a confirmation with the 

ocity button.


Table of input items

Input item	Input range			
input item	Input upper limit	Input lower limit		
Rate alarm detection period	6000	1		
Rate alarm upper limit	32767	-32768		
Rate alarm lower limit	32707			

#### (6) Scaling setting

Select "DISABLE" or "ENABLE" in the "Scaling setting" screen.


"Scaling setting" screen




SCALING
-DISABLE
-ENABLE


"Scaling upper limit" screen





↓
"Scaling lower limit" screen





"ENABLE", then make a confirmation with the lok button. (If "ENABLE" is selected, proceed to step 2.)

Use the ▲ and ▼ buttons to select "DISABLE" or

- 2. Move the cursor using the 

  and buttons, then increment or decrement the value at the cursor, using the 

  and buttons, respectively. Make a confirmation with the button.
- 3. Move the cursor using the 

  and buttons, then increment or decrement the value at the cursor, using the 

  and buttons, respectively. Make a confirmation with the 

  ok

  ok

  ok

  ok

  ok

  button.

Table of input items

Input item	Input range		
input item	Input upper limit	Input lower limit	
Scaling upper limit	32000	-32000	
Scaling lower limit			

#### (7) Cold junction compensation selection

Select "STANDARD TB" or "WITHOUT RTD" in the "Cold junction compensation selection" screen.

"Cold junction compensation selection" screen

冷接点補償選択 ・標準端子台 ・端子台変換ユニット ・使用しない CJ SELECTION
-STANDARD TB
-TB CONV MODULE
-WITHOUT RTD

1. Use the ▲ and ▼ buttons to select "STANDARD TB" or "WITHOUT RTD", then make a confirmation with the ☑κ button. ("TB CONV MODULE" cannot be used.)

## 9.4 Checking and Clearing Errors

By operation from the display unit, the error that occurred in the L60TC4 can be checked. The error that is occurring can also be cleared.


#### (1) Checking the error

The error that occurred in the L60TC4 can be checked by specifying the error code (Un\G0) from "Buffer memory monitor/test".


Ex. When an error occurred in the L60TC4 with the start I/O number 1

"Buffer memory monitor/test" screen


1. Press the ok button.



"Buffer memory address input format selection" screen



"Buffer memory address setting" screen



"Buffer memory monitor" screen



- 2. Use the ▲ and ▼ buttons to select "DEC" for the input format of the buffer memory address, then make a confirmation with the խ button.
- 3. Move the cursor using the ◀ and ▶ buttons, then increment or decrement the value at the cursor, using the ▲ and ▼ buttons, and set the value to 0. Make a confirmation with the <a>DON</a> button.
- 4. The error that occurred can be checked in the "Buffer memory monitor" screen.


#### (2) Clearing the error

To clear the error, remove the error cause and turn Error clear request (Yn2) off, on, and off from "Device monitor/test".

Ex. When an error occurred in the L60TC4 with the start I/O number 1

"CPU monitor/test" screen






"Device monitor" screen





"Device test check" screen





↓
"Device test" screen





2. Set the device to Y and press the <code>ok</code> button.

3. Use the ▲ and ▼ buttons to set the device to Y12, then make a confirmation with the )ok) button.

4. Use the ▲ and ▼ buttons to switch ON/OFF. Press the ok button to set the value set in the device test.

# **CHAPTER 10** PROGRAMMING


This chapter describes the programs of the L60TC4.

When applying any of the program examples introduced in this chapter to the actual system, verify that the control of the target system has no problem thoroughly.

## **10.1** Programming Procedure


#### (1) Temperature input mode

Create a program that performs temperature conversion in the L60TC4 using the following procedure.



#### (2) Temperature control mode

Create a program that performs temperature control in the L60TC4 using the following procedure.



<sup>\*1</sup> In the standard control, the self-tuning can be selected if necessary.

# **10.2** When Using the Module in a Standard System Configuration

This section describes the following program examples.


Mode		Overview of the program example	Reference
Temperature input mode		This is a program example where the L60TC4 is used as a temperature input module.	Page 252, Section 10.2.1
	Standard	This is a program example for operations such as the auto tuning, self-tuning, and error code read.	Page 263, Section 10.2.2
Temperature control mode	control	This is a program example where the peak current suppression function and the simultaneous temperature rise function are used for the control.	Page 274, Section 10.2.3
	Heating- cooling control	This is a program example for the heating-cooling control.	Page 288, Section 10.2.4

#### 10.2.1 When using the L60TC4 as a temperature input module

This section describes the program example of when the L60TC4 is used as a temperature input module.

#### (1) System configuration

The following figure shows the system configuration of when the L60TC4 is used as a temperature input module.





- When using the L26CPU-BT, set the I/O assignment of the built-in CC-Link of the L26CPU-BT to X/YFF0 to X/YFFF so
  that the I/O assignment be the same as that of the system configuration above.
- When the L60TCTT4BW or the L60TCRT4BW is used, the I/O assignment is the same as that of the system configuration shown above.
  - Slot 0: 16 intelligent points
  - · Slot 1: 64 input points
  - · Slot 2: 64 output points

#### (2) Programming condition

This program is designed to read the temperatures measured by the thermocouple (K type, -200.0 to 1300.0°C) connected to CH1 to CH3.


An error code can be read and reset.

The following table lists other programming conditions.

ltem	Description				
item	CH1	CH2	СНЗ		
Sampling cycle	250ms				
Temperature conversion method	Sampling processing	Sampling processing	Primary delay digital filter (time constant 1s)		
Alert output function	_	Process alarm lower lower limit value: 2000 (200.0°C) Process alarm lower upper limit value: 2050 (205.0°C) Process alarm upper lower limit value: 2950 (295.0°C) Process alarm upper upper limit value: 3000 (300.0°C)	Rate alarm alert detection cycle: Four times (1s) Rate alarm upper limit value: 50 (+5.0°C) Rate alarm lower limit value: -50 (-5.0°C)		

#### (3) Wiring example


The following figure shows a wiring example.



#### (4) Switch Setting

Configure settings such as the input mode selection and the auto-setting at the input range change as follows.

Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Switch Setting]



Item	Setting value
Input Mode Selection	Temperature Input Mode
Auto-setting at Input Range Change	0: Disable
Sampling Cycle Selection	1: 250ms

#### (5) Contents of the initial setting

Item	Description					
item	CH1	CH2	CH3	CH4		
Input range	49: Thermocouple K Measured Temperature Range (-200.0 to 1300.0°C)	49: Thermocouple K Measured Temperature Range (-200.0 to 1300.0°C)	49: Thermocouple K Measured Temperature Range (-200.0 to 1300.0°C)	2: ThermocoupleK Measured Temperature Range (0 to 1300.0°C)		
Conversion enable/disable setting	0: Enable	0: Enable	0: Enable	1: Disable		
Primary delay digital filter setting	0 s	0 s	1 s	0 s		
Process alarm alert output enable/disable setting	1: Disable	0: Enable	1: Disable	1: Disable		
Process alarm lower lower limit value	-200.0°C	200.0°C	-200.0°C	-200°C		
Process alarm lower upper limit value	-200.0°C	205.0°C	-200.0°C	-200°C		

Item	Description					
Item	CH1	CH2	CH3	CH4		
Process alarm upper lower limit value	1300.0°C	295°C	1300.0°C	1300°C		
Process alarm upper upper limit value	1300.0°C	300°C	1300.0°C	1300°C		
Rate alarm alert output enable/disable setting	1: Disable	1: Disable	0: Enable	1: Disable		
Rate alarm alert detection cycle	1 Times	1 Times	4 Times	1 Times		
Rate alarm upper limit value	0.0°C	0.0°C	5.0°C	0°C		
Rate alarm lower limit value	0.0°C	0.0°C	-5.0°C	0°C		

#### (6) When using the parameter of an intelligent function module


#### (a) Devices used by a user

Device	Device Description		
X10	Module READY flag	L60TCTT4 (X10 to X1F)	
X12	Error occurrence flag		
X22	Error code reset instruction		
X23	Operation mode setting instruction	LX42C4 (X20 to X5F)	
X25	Temperature process value read instruction		
Y11	Setting/operation mode instruction		
Y12	Error reset instruction	L60TCTT4 (Y10 to Y1F)	
Y1B	Setting change instruction		
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)	
D11	CH1 Temperature process value (PV)		
D12	CH2 Temperature process value (PV)		
D13	CH3 Temperature process value (PV)		
D50	Error code		
D51	CH1 Temperature process value (PV)		
D52	CH2 Temperature process value (PV)		
D53	CH3 Temperature process value (PV)	Devices where data is written by auto refresh	
D55	CH2 Alert definition	by auto remesh	
D56	CH3 Alert definition		
D60	Temperature conversion completion flag		

#### (b) Parameter setting

Set the contents of initial settings in the parameter.

- 1. Open the "Parameter" window.
  - Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Switch Setting]
- 2. Click Clear Value for Gray Cells to set items unnecessary for the mode set on Switch Setting to 0.
- 3. Set the parameter.




Item	Description		Settin	ıg value	
iteiii	Description	CH1	CH2	СНЗ	CH4
Input range	Set the temperature sensor used for the L60TC4 and the measurement range.	49: Thermocouple K Measured Temperature Range (-200.0 to 1300.0°C)	49: Thermocouple K Measured Temperature Range (-200.0 to 1300.0°C)	49: Thermocouple K Measured Temperature Range (-200.0 to 1300.0°C)	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)
Conversion enable/disable setting	Set whether to enable or disable temperature conversion for each channel.	0: Enable	0: Enable	0: Enable	1: Disable
Primary delay digital filter setting	Set the primary delay digital filter that smoothes the temperature process value (PV).	0 s	0 s	1 s	0 s
Process alarm alert output enable/disable setting	Set whether to enable or disable the process alarm alert output for each channel.	1: Disable	0: Enable	1: Disable	1: Disable
Process alarm lower lower limit value	Set the process alarm lower lower limit value.	0.0°C	200.0°C	0.0°C	0°C
Process alarm lower upper limit value	Set the process alarm lower upper limit value.	0.0°C	205.0°C	0.0°C	0°C

Item	Description	Setting value				
item	Description	CH1	CH2	СНЗ	CH4	
Process alarm upper lower limit value	Set the process alarm upper lower limit value.	1300.0°C	295.0°C	1300.0°C	1300°C	
Process alarm upper upper limit value	Set the process alarm upper upper limit value.	1300.0°C	300.0°C	1300.0°C	1300°C	
Rate alarm alert output enable/disable setting	Set whether to enable or disable the rate alarm alert output for each channel.	1: Disable	1: Disable	0: Enable	1: Disable	
Rate alarm alert detection cycle	Set the cycle for checking the temperature process value (PV) for the rate alarm.	1 Times	1 Times	4 Times	1 Times	
Rate alarm upper limit value	Set the rate alarm upper limit value.	0.0°C	0.0°C	5.0°C	0°C	
Rate alarm lower limit value	Set the rate alarm lower limit value.	0.0°C	0.0°C	-5.0°C	0°C	

#### (c) Auto refresh setting

Set the device to be automatically refreshed.

Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  [L60TCTT4]  $\Rightarrow$  [Auto\_Refresh]



Item	Description	Setting value				
item		CH1	CH2	CH3	CH4	
Error code	An error code or alarm code is stored.	D50				
Temperature process value (PV)	The detected temperature value where sensor correction was performed is stored.	D51	D52	D53	_	
Alert definition	Bits corresponding to alerts detected in each channel become 1.	_	D55	D56	_	
Temperature conversion completion flag	This flag checks whether the temperature conversion has started properly for each channel.	D60				

# 10.2 When Using the Module in a Standard System Configuration 10.2.1 When using the L60TC4 as a temperature input module

#### (d) Writing parameter of an intelligent function module

Write the set parameter to the CPU module. Then reset the CPU module or turn off and on the power supply of the programmable controller.

[Online] ⇒ [Write to PLC...]




#### (e) Program example


• Program that changes the setting/operation mode



 Program that reads the temperature process value (PV) and takes action when a process alarm or a rate alarm occurs



· Program that reads an error code



# (7) Program example of when not using the parameter of an intelligent function module


#### (a) Devices used by a user

Device	Description			
X10	Module READY flag			
X12	Error occurrence flag	L60TCTT4 (X10 to X1F)		
X13	Hardware error flag			
X1B	Setting change completion flag			
X20	Set value write instruction			
X22	Error code reset instruction	LX42C4 (X20 to X5F)		
X23	Operation mode setting instruction	EX42C4 (X20 to X31 )		
X25	Temperature process value read instruction			
Y11	Setting/operation mode status			
Y12	Error reset instruction	L60TCTT4 (Y10 to Y1F)		
Y1B	Setting change instruction			
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)		
D11	CH1 Temperature process value (PV)			
D12	CH2 Temperature process value (PV)			
D13	CH3 Temperature process value (PV)			
D50	Error code			
D55	CH2 Alert definition			
D56	CH3 Alert definition			
D60	Temperature conversion completion flag			
M0	For writing set value 0			
M1	For writing set value 1			
M2	For writing set value 2			


#### (b) Program example

- Program that changes the setting/operation mode
   The program is the same as that of when the parameter of the intelligent function module is used.

   (Fig. Page 259, Section 10.2.1 (6) (e))
- · Initial setting program



• Program that reads the temperature process value (PV) and takes action when a process alarm or a rate alarm occurs



· Program that reads an error code

# 10.2.2 Standard control (such as auto tuning, self-tuning, and error code read)


This section describes the program example for operations such as the auto tuning, self-tuning, and error code read.

#### (1) System configuration

The following figure shows the system configuration for operations such as the auto tuning, self-tuning, and error code read.

Power supply module (L61P)
CPU module (L02CPU)
Temperature control module (L60TCTT4)
Input module (LX42C4)
Output module (LY42NT1P)
END cover (L6EC)

X/Y00 X/Y10 X20 Y60
to to to to



#### Point P

- When using the L26CPU-BT, set the I/O assignment of the built-in CC-Link of the L26CPU-BT to X/YFFD to X/YFFF so that the I/O assignment be the same as that of the system configuration above.
- When the L60TCTT4BW or the L60TCRT4BW is used, the I/O assignment is the same as that of the system configuration shown above.
  - · Slot 0: 16 intelligent points
  - · Slot 1: 64 input points
  - Slot 2: 64 output points

#### (2) Programming condition


This program is designed to read the temperatures measured by the thermocouple (K type, 0°C to 1300°C) connected to CH1 for the control.

An error code can be read and reset.

The self-tuning function automatically sets the PID constants optimal to CH1.

#### (3) Wiring example


The following figure shows a wiring example.



#### (4) Switch Setting

Configure settings such as the input mode selection and the auto-setting at the input range change as follows.

Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Switch Setting]



ltem -		Set value				
		CH1	CH2	СНЗ	CH4	
Input Mode Selection		Temperature Contro	ol Mode			
	Output Setting at CPU Stop Error	0: CLEAR	0: CLEAR	0: CLEAR	0: CLEAR	
Temperature Control	Control Mode Selection	0: Standard Control				
Mode Setting	Setting Change Rate Limiter Setting	0: Temperature Rise/Temperature Drop Batch Setting				
	Control Output Cycle Unit Selection Setting	0: 1s Cycle				
Auto-setting at Input Range Change		0: Disable				
Sampling Cycle Selec	tion	0: 500ms				

#### (5) Contents of the initial setting

Item	Description					
item	CH1	CH2	CH3	CH4		
Input range	2: Thermocouple K Measured Temperature Range (0 to 1300°C)					
Set value (SV) setting	200°C	0°C	0°C	0°C		
Unused channel setting	0: Used	1: Unused	1: Unused	1: Unused		
Control output cycle setting	30 s	30 s	30 s	30 s		
Upper limit setting limiter	400°C	1300°C	1300°C	1300°C		
Lower limit setting limiter	0°C	0°C	0°C	0°C		
Self-tuning setting*1	1: Starting ST (PID Constant Only)	0: Do Not Run the ST	0: Do Not Run the ST	0: Do Not Run the ST		
Alert 1 mode setting	1: Upper Limit Input Alert	0: Not Warning	0: Not Warning	0: Not Warning		
Alert set value 1	500°C	0°C	0°C	0°C		

<sup>\*1</sup> This setting is necessary only when the self-tuning function is used.

#### (6) When using the parameter of an intelligent function module


#### (a) Devices used by a user

Device	Description	Description		
X10	Module READY flag	L60TCTT4 (X10 to X1F)		
X12	Error occurrence flag	L001C114 (X10 to X1F)		
X22	Error code reset instruction			
X23	Operation mode setting instruction	LX42C4 (X20 to X5F)		
X24	Memory of PID constants read instruction	LX42C4 (X20 to X3F)		
X30	CH1 Set value (SV) change instruction			
Y11	Setting/operation mode instruction			
Y12	Error reset instruction	L60TCTT4 (Y10 to Y1F)		
Y18	Set value backup instruction	L001C114 (110 to 11F)		
Y1B	Setting change instruction			
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)		
D50	Error code	Devices where data is written		
D51	CH1 Temperature process value (PV)	by auto refresh		
M20 to M23	CH□ Read completion flag	CH□ Read completion flag		
M24 to M27	CH□ Write completion flag	CH□ Write completion flag		

#### (b) Parameter setting

Set the contents of initial settings in the parameter.

- 1. Open the "Parameter" window.
  - Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Parameter]
- 2. Click Clear Value for Gray Cells to set items unnecessary for the mode set on Switch Setting to 0.
- 3. Set the parameter.



Item	Description	Setting value			
Item	Description	CH1	CH2	CH3	CH4
Input range	Set the temperature sensor used for the L60TC4 and the	2: ThermocoupleK Measured Temperature Range	2: ThermocoupleK Measured Temperature Range	2: ThermocoupleK Measured Temperature Range	2: ThermocoupleK Measured Temperature Range
Set value (SV) setting	measurement range.  Set the target temperature value of PID control.	(0 to 1300°C) 200°C	(0 to 1300°C)	(0 to 1300°C)	(0 to 1300°C)
Unused channel setting	Configure this setting when the channels where the temperature control is not performed and the temperature sensor is not connected are set to be unused.	0: Used	1: Unused	1: Unused	1: Unused
Control output cycle setting/Heating control output cycle setting	Set the pulse cycle (ON/OFF cycle) of the transistor output.	30 s	30 s	30 s	30 s
Upper limit setting limiter	Set the upper limit of the set value (SV).	400°C	1300°C	1300°C	1300°C


Item	Description	Setting value			
iteiii	Description	CH1	CH2	CH3	CH4
Lower limit setting limiter	Set the lower limit of the set value (SV).	0°C	0°C	0°C	0°C
Self-tuning setting*1	Set the operation of the self-tuning.	1: Starting ST (PID Constant Only)	0: Do Not Run the ST	0: Do Not Run the ST	0: Do Not Run the ST
Alert 1 mode setting	Set the alert mode.	1: Upper Limit Input Alert	0: Not Warning	0: Not Warning	0: Not Warning
Alert set value 1	Set the temperature where CH□ Alert 1 (b8 of Un\G5 to Un\G8) turns on depending on the selected alert mode.	500°C	_	_	_

<sup>\*1</sup> This setting is necessary only when the self-tuning function is used.

#### (c) Auto refresh setting

Set the device to be automatically refreshed.

Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4]▷ [Auto\_Refresh]



Item	Description	Set value			
iteiii	Description	CH1	CH2	СНЗ	CH4
Error code	An error code or alarm code is stored.	D50			
Temperature process value (PV)	The detected temperature value where sensor correction was performed is stored.	D51	_	_	_

#### (d) Writing parameter of an intelligent function module

Write the set parameter to the CPU module. Then reset the CPU module or turn off and on the power supply of the programmable controller.


© [Online] ▷ [Write to PLC...]



#### (e) Performing auto tuning

Set the "Automatic backup setting after auto tuning of PID constants" to "ON" and perform the auto tuning.

[Tool] □ [Intelligent Function Module Tool] □ [Temperature Control Module]



#### (f) Program example


- Program that changes the setting/operation mode
   This program is the same as that of when it is used as a temperature input module. (FFP Page 259, Section 10.2.1 (6) (e))
- · Program that reads the PID constants from the non-volatile memory



CH1 Memory's PID constant read instruction: With instruction
Read bit data from b7 to b0 of the memory's PID constant read/write completion flag to M20 to M27.

CH1 Memory's PID constant read instruction: Without instruction

· Program that reads an error code




Output an error code to Y60 to Y6F.

Error reset instruction: ON

Error reset instruction: OFF

• Program that changes the set value (SV)



Change CH1 Set value (SV) setting to 250°C.

Return CH1 Set value (SV) setting to 200°C.


# (7) Program example of when not using the parameter of an intelligent function module

#### (a) Devices used by a user

Device	Description	1
X10	Module READY flag	
X11	Setting/operation mode status	
X12	Error occurrence flag	
X13	Hardware error flag	L60TCTT4 (X10 to X1F)
X14	CH1 Auto tuning status	
X18	Back-up of the set value completion flag	
X1B	Setting change completion flag	
X20	Set value write instruction	
X21	Auto tuning execute instruction	
X22	Error code reset instruction	L V4204 (V20 to V55)
X23	Operation mode setting instruction	LX42C4 (X20 to X5F)
X24	Memory of PID constants read instruction	
X30	CH1 Set value (SV) change instruction	
Y11	Setting/operation mode instruction	
Y12	Error reset instruction	
Y14	CH1 Auto tuning instruction	L60TCTT4 (Y10 to Y1F)
Y18	Set value backup instruction	
Y1B	Setting change instruction	
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)
D50	Error code	•
D51	CH1 Temperature process value (PV)	
MO	For writing set value 0	
M1	For writing set value 1	
M2	For writing set value 2	
M10	CH1 Auto tuning completion flag	
M20 to M23	CH□ Read completion flag	
M24 to M27	CH□ Write completion flag	

#### (b) Program example

- Program that changes the setting/operation mode
   This program is the same as that of when it is used as a temperature input module. (FFP Page 259, Section 10.2.1 (6) (e))
- · Initial setting program



<sup>\*1</sup> Configure this setting only when the self-tuning function is used.


· Program that executes the auto tuning and backs up the PID constants in the non-volatile memory



- Program that reads the PID constants from the non-volatile memory

  This program is the same as that of when the parameter of the intelligent function module is used.

  (Fig. Page 270, Section 10.2.2 (6) (f))
- Program that reads an error code and the temperature process value (PV)



• Program that changes the set value (SV)

This program is the same as that of when the parameter of the intelligent function module is used.


(Fig. Page 270, Section 10.2.2 (6) (f))

# 10.2.3 Standard control (peak current suppression function, simultaneous temperature rise function)

This section describes the program example where the peak current suppression function and the simultaneous temperature rise function are used for the control.

#### (1) System configuration

The following figure shows the system configuration example of when the peak current suppression function and the simultaneous temperature rise function are used for the control.




#### Point P


- When using the L26CPU-BT, set the I/O assignment of the built-in CC-Link of the L26CPU-BT to X/YFF0 to X/YFFF so
  that the I/O assignment be the same as that of the system configuration above.
- When the L60TCTT4BW or the L60TCRT4BW is used, the I/O assignment is the same as that of the system configuration shown above.
  - Slot 0: 16 intelligent points
  - Slot 1: 64 input points
  - Slot 2: 64 output points

#### (2) Programming condition

Program example where the peak current suppression function is used
 This program is designed to suppress the peak current by automatically changing the values of the upper limit output limiter of CH1 to CH4 and dividing the timing of the transistor output into four timing.




Program example where the simultaneous temperature rise function is used
 This program is designed to classify the CH1 and CH2 into group 1 and CH3 and CH4 into group 2 so that
 the channels in each group reach the set values (SV) simultaneously.



#### (3) Wiring example


The following figure shows a wiring example.



#### (4) Switch Setting

Configure settings such as the input mode selection and the auto-setting at the input range change as follows.

Project window ⇒ [Intelligent Function Module] ⇒ [L60TCTT4] ⇒ [Switch Setting]



ltem -		Set value				
		CH1	CH2	СНЗ	CH4	
Input Mode Selection		Temperature Control Mode				
	Output Setting at CPU Stop Error	0: CLEAR	0: CLEAR	0: CLEAR	0: CLEAR	
Temperature Control			0: Standard Control			
Mode Setting	Setting Change Rate Limiter Setting	0: Temperature Rise/Temperature Drop Batch Setting				
	Control Output Cycle Unit Selection Setting	0: 1s Cycle				
Auto-setting at Input Range Change		0: Disable				
Sampling Cycle Selec	tion	0: 500ms				

#### (5) Contents of the initial setting

Item		Description					
item	CH1	CH2	СНЗ	CH4			
Input range	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)						
Set value (SV) setting	200°C	250°C	300°C	350°C			
Unused channel setting	0: Used	0: Used	0: Used	0: Used			
Control output cycle setting	20 s	20 s	20 s	20 s			
Simultaneous temperature rise group setting*1	1: Group 1	1: Group 1	2: Group 2	2: Group 2			
Peak current suppression control group setting*2	1: Group 1	2: Group 2	3: Group 3	4: Group 4			
Simultaneous temperature rise AT mode selection*1	1: AT for Simultaneous Temperature Rise						

<sup>\*1</sup> Configure this setting only when the simultaneous temperature rise function is used.

#### (6) When using the parameter of an intelligent function module

#### (a) Devices used by a user

Device	Description	Description		
X10	Module READY flag	L COTOTTA (V40 to V45)		
X12	Error occurrence flag	L60TCTT4 (X10 to X1F)		
X22	Error code reset instruction			
X23	Operation mode setting instruction	LX42C4 (X20 to X5F)		
X24	Memory of PID constants read instruction			
Y11	Setting/operation mode instruction			
Y12	Error reset instruction	L60TCTT4 (Y10 to Y1F)		
Y18	Set value backup instruction	L001C114 (110 to 11F)		
Y1B	Setting change instruction			
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)		
D50	Error code	Devices where data is written		
D51 to D54	CH□ Temperature process value (PV) by auto refresh			
M20 to M23	CH□ Read completion flag	CH□ Read completion flag		
M24 to M27	CH□ Write completion flag	CH□ Write completion flag		


<sup>\*2</sup> Configure this setting only when the peak current suppression function is used.

# 10.2 When Using the Module in a Standard System Configuration 10.2.3 Standard control (peak current suppression function, simultaneous temperature rise function)

#### (b) Parameter setting

Set the contents of initial settings in the parameter.

- 1. Open the "Parameter" window.
  - Project window  $\Rightarrow$  [Intelligent Function Module]  $\Rightarrow$  [L60TCTT4]  $\Rightarrow$  [Parameter]
- 2. Click Clear Value for Gray Cells to set items unnecessary for the mode set on Switch Setting to 0.
- 3. Set the parameter.



Item	Description	Setting value			
iteiii	Description	CH1	CH2	CH3	CH4
Input range	Set the temperature sensor used for the L60TC4 and the measurement range.	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)			
Set value (SV) setting	Set the target temperature value of PID control.	200°C	250°C	300°C	350°C
Unused channel setting	Configure this setting when the channels where the temperature control is not performed and the temperature sensor is not connected are set to be unused.	0: Used	0: Used	0: Used	0: Used
Control output cycle setting/Heating control output cycle setting	Set the pulse cycle (ON/OFF cycle) of the transistor output.	20 s	20 s	20 s	20 s
Simultaneous temperature rise group setting*1	Set the group to perform the simultaneous temperature rise function for each channel.	1: Group 1	1: Group 1	2: Group 2	2: Group 2

ltem	Description	Setting value				
item	Description	CH1	CH2	CH3	CH4	
Peak current suppression control group setting*2	Set the target channels for the peak current suppression function and the gap of the control output cycles between channels.	1: Group 1	2: Group 2	3: Group 3	4: Group 4	
Simultaneous temperature rise AT mode selection*1	Set the mode of the auto tuning.	1: AT for Simultaneous Temperature Rise				


<sup>\*1</sup> Configure this setting only when the simultaneous temperature rise function is used.

<sup>\*2</sup> Configure this setting only when the peak current suppression function is used.

#### (c) Auto refresh setting

Set the device to be automatically refreshed.

Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Auto\_Refresh]



Item	Description	Setting value			
item	Description	CH1	CH2	СНЗ	CH4
Error code	An error code or alarm code is stored.	D50			
Temperature process value (PV)	The detected temperature value where sensor correction was performed is stored.	D51	D52	D53	D54

#### (d) Writing parameter of an intelligent function module


Write the set parameter to the CPU module. Then reset the CPU module or turn off and on the power supply of the programmable controller.

Conline □ Image: The properties of the prope




#### (e) Performing auto tuning

Set the "Automatic backup setting after auto tuning of PID constants" to "ON" and perform the auto tuning.



### (f) Program example where the peak current suppression function or the simultaneous temperature rise function is used

- Program that changes the setting/operation mode
   This program is the same as that of when it is used as a temperature input module. (Page 259, Section 10.2.1 (6) (e))
- Program that reads the PID constants from the non-volatile memory



Program that reads an error code
 This program is the same as that of when it is used as a temperature input module. (FFP Page 259, Section 10.2.1 (6) (e))


# (7) Program example of when not using the parameter of an intelligent function module

#### (a) Devices used by a user


Device	Descriptio	n
X10	Module READY flag	
X11	Setting/operation mode status	
X12	Error occurrence flag	
X13	Hardware error flag	L60TCTT4 (X10 to X1F)
X14 to X17	CH□ Auto tuning status	
X18	Back-up of the set value completion flag	
X1B	Setting change completion flag	
X20	Set value write instruction	
X21	Auto tuning execute instruction	
X22	Error code reset instruction	LX42C4 (X20 to X5F)
X23	Operation mode setting instruction	
X24	Memory of PID constants read instruction	
Y11	Setting/operation mode instruction	
Y12	Error reset instruction	
Y14 to Y17	CH□ Auto tuning instruction	L60TCTT4 (Y10 to Y1F)
Y18	Set value backup instruction	
Y1B	Setting change instruction	
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)
D50	Error code	•
D51 to D54	CH□ Temperature process value (PV)	
M0	For writing set value 0	
M1	For writing set value 1	
M2	For writing set value 2	
M10 to M13	CH□ Auto tuning completion flag	
M20 to M23	CH□ Read completion flag	
M24 to M27	CH□ Write completion flag	

#### (b) Program example where the peak current suppression function is used

- Program that changes the setting/operation mode
   This is the same as that of when it is used as a temperature input module. (Fig. Page 259, Section 10.2.1 (6) (e))
- · Initial setting program



· Program that executes the auto tuning and backs up the PID constants in the non-volatile memory




- Program that reads the PID constants from the non-volatile memory
   This program is the same as that of when the parameter of the intelligent function module is used.

   (Page 282, Section 10.2.3 (6) (f))
- Program that reads an error code and the temperature process value (PV)

```
FROM U1
                                                                   Read an error code to D50.
                                                                   Output data read from an error code
                                              D50
                                                        K4Y60
                                                                   to Y60 to Y6F.
                                                                   Error reset instruction: ON
                                              -FSET
                                                        Y12
                                                                   Error reset instruction: OFF
                                              -[RST
                                                        Y12
                                                                   Read CH Temperature process value (PV) to D51 to D54.
          FROM U1
                                              D51
                                                        K4
                                                       -TEND
```

#### (c) Program example where the simultaneous temperature rise function is used

- Program that changes the setting/operation mode
   This program is the same as that of when it is used as a temperature input module. (Page 259, Section 10.2.1 (6) (e))
- · Initial setting program



- Program that executes the auto tuning and backs up the PID constants in the non-volatile memory

  This program is the same as that of when the peak current suppression function is used. (FP Page 284, Section 10.2.3 (7) (b))
- Program that reads the PID constants from the non-volatile memory

  This program is the same as that of when the parameter of the intelligent function module is used.


  (FP Page 282, Section 10.2.3 (6) (f))
- Program that reads an error code
   This program is the same as that of when the peak current suppression function is used. (FF Page 284, Section 10.2.3 (7) (b))

## 10.2.4 When performing the heating-cooling control

This section describes the program example to perform the heating-cooling control.

## (1) System configuration

The following figure shows the system configuration example to perform the heating-cooling control.



## Point P


- When using the L26CPU-BT, set the I/O assignment of the built-in CC-Link of the L26CPU-BT to X/YFF0 to X/YFFF so that the I/O assignment be the same as that of the system configuration above.
- When the L60TCTT4BW or the L60TCRT4BW is used, the I/O assignment is the same as that of the system configuration shown above.
  - Slot 0: 16 intelligent points
  - Slot 1: 64 input points
  - Slot 2: 64 output points

## (2) Program conditions

This program is designed to perform the heating-cooling control by using the temperature input of CH1.

## (3) Wiring example


The following figure shows a wiring example.



## (4) Switch Setting

Configure settings such as the input mode selection and the auto-setting at input range change as follows.

Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Switch Setting]



ltem		Setting value				
		CH1	CH2	СНЗ	CH4	
Input Mode Selection		Temperature Contro	ol Mode			
Temperature Control Mode Setting	Output Setting at CPU Stop Error	0: CLEAR	0: CLEAR	0: CLEAR	0: CLEAR	
	Control Mode Selection	3: Mix Control (Normal Mode)				
	Setting Change Rate Limiter Setting	0: Temperature Rise/Temperature Drop Batch Setting				
	Control Output Cycle Unit Selection Setting	0: 1s Cycle				
Auto-setting at Input Range Change		0: Disable				
Sampling Cycle Selection		0: 500ms				

## (5) Contents of the initial setting

Item	Description					
item	CH1	CH2	CH3	CH4		
Input range	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)					
Set value (SV) setting	200°C	0°C	0°C	0°C		
Unused channel setting	0: Used	0: Used	1: Unused	1: Unused		
Heating control output cycle setting	30 s	0 s	30 s	30 s		
Cooling method setting	0: Air Cooled	0: Air Cooled	0: Air Cooled	0: Air Cooled		
Cooling control output cycle setting	30 s	0 s	30 s	30 s		
Overlap/Dead band setting	-0.3 %	0.0 %	0.0 %	0.0 %		

## (6) When using the parameter of an intelligent function module


## (a) Devices used by a user

Device	Descriptio	n
X10	Module READY flag	L 60TCTT4 (V10 to V1E)
X12	Error occurrence flag	L60TCTT4 (X10 to X1F)
X22	Error code reset instruction	
X23 Operation mode setting instruction		LX42C4 (X20 to X5F)
X24	Memory of PID constants read instruction	
Y11	Setting/operation mode instruction	
Y12 Error reset instruction		L COTOTTA (VAO to VAE)
Y18	Set value backup instruction	L60TCTT4 (Y10 to Y1F)
Y1B	Setting change instruction	
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)
D50	Error code	Devices where data is written
D51	CH1 Temperature process value (PV)	by auto refresh
M20 to M23	CH□ Read completion flag	
M24 to M27	CH□ Write completion flag	

#### (b) Parameter setting

Set the contents of initial settings in the parameter.

- 1. Open the "Parameter" window.
  - Project window 🜣 [Intelligent Function Module] 🜣 [L60TCTT4] 💠 [Parameter]
- 2. Click Clear Value for Gray Cells to set items unnecessary for the mode set on Switch Setting to 0.
- 3. Set the parameter.



Item	Description	Setting value			
Item	Description	CH1	CH2 CH3		CH4
Input range	Set the temperature sensor used for the L60TC4 and the measurement range.	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)			
Set value (SV) setting	Set the target temperature value of PID control.	200°C	0°C	0°C	0°C
Unused channel setting	Configure this setting when the channels where the temperature control is not performed and the temperature sensor is not connected are set to be unused.	0: Used	0: Used	1: Unused	1: Unused
Control output cycle setting/Heating control output cycle setting	Set the pulse cycle (ON/OFF cycle) of the transistor output.	30 s	0 s	30 s	30 s
Cooling method setting	Set the method for the cooling control in the heating-cooling control.	0: Air Cooled	0: Air Cooled	0: Air Cooled	0: Air Cooled


9	10.2.4 When performing the heating-cooling control	10.2 When Using the Module in a Standard System Configuration

Item	Description	Setting value			
iteiii	Description	CH1	CH2	СНЗ	CH4
Cooling control output cycle setting	Set the pulse cycle (ON/OFF cycle) of the transistor output.	30 s	0 s	30 s	30 s
Overlap/dead band setting	Configure the overlap/dead band setting.	-0.3 %	0.0 %	0.0 %	0.0 %

## (c) Auto refresh setting

Set the device to be automatically refreshed.

Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Auto\_Refresh]



Item	Description	Setting value						
nem	Description	CH1	CH2	CH2 CH3 CH4				
Error code	An error code or alarm code is stored.	D50						
Temperature process value (PV)	The detected temperature value where sensor correction is performed is stored.	D51	_	_	_			

## (d) Writing parameter of an intelligent function module

Write the set parameter to the CPU module. Then reset the CPU module or turn off and on the power supply of the programmable controller.


(Online) ⇒ [Write to PLC...]



#### (e) Performing auto tuning

Set the "Automatic backup setting after auto tuning of PID constants" to "ON" and perform the auto tuning.

[Tool] ⇒ [Intelligent Function Module Tool] ⇒ [Temperature Control Module]
⇒ [Auto Tuning...] ⇒ "L60TCTT4" ⇒ □ ○ □ □



## (f) Program example

- Program that changes the setting/operation mode
   This program is the same as that of when it is used as a temperature input module. (FFP Page 259, Section 10.2.1 (6) (e))
- Program that reads the PID constants from the non-volatile memory

  This program is used when the module is in the standard control (such as auto tuning, self-tuning, and error code read). (PP Page 270, Section 10.2.2 (6) (f))
- Program that reads an error code
   This program is the same as that of when it is used as a temperature input module. (Fig. Page 259, Section 10.2.1 (6) (e))


# (7) Program example of when not using the parameter of an intelligent function module

## (a) Devices used by a user

Device	Description			
X10	Module READY flag			
X11	Setting/operation mode status			
X12	Error occurrence flag			
X13	Hardware error flag	L60TCTT4 (X10 to X1F)		
X14	CH1 Auto tuning status			
X18	Back-up of the set value completion flag			
X1B	Setting change completion flag			
X20	Set value write instruction			
X21	Auto tuning execute instruction			
X22	K22 Error code reset instruction			
X23	Operation mode setting instruction			
X24	Memory of PID constants read instruction			
Y11	Setting/operation mode instruction			
Y12	Error reset instruction			
Y14	CH1 Auto tuning instruction	L60TCTT4 (Y10 to Y1F)		
Y18	Set value backup instruction			
Y1B	Setting change instruction			
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)		
D50	Error code			
D51	CH1 Temperature process value (PV)			
M0	For writing set value 0			
M1	For writing set value 1			
M2	For writing set value 2			
M10	CH1 Auto tuning completion flag			
M20 to M23	CH□ Read completion flag			
M24 to M27	CH□ Write completion flag			


## (b) Program example

- Program that changes the setting/operation mode
   This program is the same as that of when it is used as a temperature input module. (Fig. Page 259, Section 10.2.1 (6) (e))
- Initial setting program



- Program that executes the auto tuning and backs up the PID constants in the non-volatile memory This program is used when the module is in the standard control (such as auto tuning, self-tuning, and error code read). (Page 272, Section 10.2.2 (7) (b))
- Program that reads the PID constants from the non-volatile memory

  This program is used when the module is in the standard control (such as auto tuning, self-tuning, and error code read). (FF Page 270, Section 10.2.2 (6) (f))
- · Program that reads an error code



## 10.3 When the Module is Connected to the Head Module


This section describes the program example of when the module is connected to the head module.

## (1) System configuration

The following figure shows the system configuration example of when the module is connected to the head module.

Power supply module (Q62P)
CPU module (Q10UDHCPU)
Master/local module (QJ71GF11-T2)
Input module (QX42)
Output module (QY42P)

Power supply module (L61P)
Head module (LJ72GF15-T2)
Temperature control module (L60TCTT4)
END cover (L6EC)





When the L60TCTT4BW or the L60TCRT4BW is used, the I/O assignment is the same as that of the system configuration shown above.

- Slot 0: 16 intelligent points
- Slot 1: 64 input points
- Slot 2: 64 output points

## (2) Programming condition

This program is designed to read the temperatures measured by the thermocouple (K type, 0 to 1300°C) connected to CH1.

An error code can be read and reset.

## (3) Wiring example

The wiring is the same as the that of when the module is in the standard control (such as auto tuning, self-tuning, and error code read). ( Page 264, Section 10.2.2 (3))

## (4) Switch Setting

Configure settings on the intelligent device station. (FP Page 302, Section 10.3 (7))

## (5) Contents of the initial setting


Item	Description					
item	CH1	CH2	CH3	CH4		
Input range	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)					
Set value (SV) setting	200°C	0°C	0°C	0°C		
Unused channel setting	0: Used	1: Unused	1: Unused	1: Unused		
Upper limit setting limiter	400°C	1300°C	1300°C	1300°C		
Lower limit setting limiter	0°C	0°C	0°C	0°C		
Alert 1 mode setting	1: Upper Limit Input Alert	0: Not Warning	0: Not Warning	0: Not Warning		
Alert set value 1	500°C	0°C	0°C	0°C		

## (6) Setting on the master station

## 1. Create a project on GX Works2.


Select "QCPU (Q mode)" for "PLC Series:" and select the CPU module to be used for "PLC Type:".

[Project] ▷ [New...]





2. Display the network parameter setting window and configure the setting as follows.

Project window 🜣 [Parameter] 💠 [Network Parameter]



3. Display the network range assignment setting window and configure the setting as follows.






10.3 When the Module is Connected to the Head Module

4. Display the refresh parameter setting window and configure the setting as follows.





5. Write the set parameter to the CPU module on the master station. Then reset the CPU module or turn off and on the power supply of the programmable controller.

(Online) □ [Write to PLC...]




## (7) Setting on the intelligent device station


1. Create a project on GX Works2.

Select "LCPU" for "PLC Series:" and select "LJ72GF15-T2" for "PLC Type:".

[Project] ▷ [New...]




- 2. Display the PLC parameter setting window and configure the setting as follows.
  - Project window ▷ [Parameter] ▷ [PLC Parameter] ▷ "Communication Head Setting"




3. Add the L60TCTT4 to the project on GX Works2.

Project window ❖ [Intelligent Function Module] ❖ Right-click ❖ [New Module...]




## 4. Display the L60TCTT4 Switch Setting window and configure the setting as follows.


Project window ▷ [Intelligent Function Module] ▷ [L60TCTT4] ▷ [Switch Setting]



	Item	Setting value				
iteiii		CH1	CH2	CH3	CH4	
Input Mode Selection		Temperature Contro	ol Mode	•		
Temperature Control Mode Setting	Output Setting at CPU Stop Error	0: CLEAR	0: CLEAR	0: CLEAR	0: CLEAR	
	Control Mode Selection	0: Standard Control				
	Setting Change Rate Limiter Setting	0: Temperature Rise/Temperature Drop Batch Setting				
	Control Output Cycle Unit Selection Setting	0: 1s Cycle				
Auto-setting at Input Range Change		0: Disable				
Sampling Cycle Selec	tion	0: 500ms				


5. Display the L60TCTT4 initial setting window, click Clear Value for Gray Cells, and configure the setting as follows.





Item	Description		Setting	g value		
item	Description	CH1	CH2	СНЗ	CH4	
Input range	Set the temperature sensor used for the L60TC4 and the measurement range.	2: ThermocoupleK Measured Temperature Range (0 to 1300°C)				
Set value (SV) setting	Set the target temperature value of PID control.	200°C	0°C	0°C	0°C	
Unused channel setting	Configure this setting when the channels where the temperature control is not performed and the temperature sensor is not connected are set to be unused.	0: Used	1: Unused	1: Unused	1: Unused	
Upper limit setting limiter	Set the upper limit of the set value (SV).	400°C	1300°C	1300°C	1300°C	
Lower limit setting limiter	Set the lower limit of the set value (SV).	0°C	0°C	0°C	0°C	
Alert 1 mode setting	Set the alert mode.	1: Upper Limit Input Alert	0: Not Warning	0: Not Warning	0: Not Warning	
Alert set value 1	Set the temperature where CH□ Alert 1 (b8 of Un\G5 to Un\G8) turns on depending on the selected alert mode.	500°C	_	_	_	


- 6. Display the L60TCTT4 auto refresh setting window and configure the setting as follows.
  - Project window  $\Leftrightarrow$  [Intelligent Function Module]  $\Leftrightarrow$  [L60TCTT4]  $\Leftrightarrow$  Right-click  $\Leftrightarrow$  [Auto\_Refresh]



Item	Description	Setting value				
	Description	CH1	CH2 CH3 CH4			
Error code	An error code or alarm code is stored.	W1050				
Temperature process value (PV)	The detected temperature value where sensor correction is performed is stored.	W1051	_	_	_	

7. Write the set parameter to the head module. Then reset the head module or turn off and on the power supply.

(Online) ⇒ [Write to PLC...]




## 8. Perform auto tuning.

Set the "Automatic backup setting after auto tuning of PID constants" to "ON" and perform the auto tuning.

(Tool) □ [Intelligent Function Module Tool] □ [Temperature Control Module]

 ⇔ [Auto Tuning...]
 ⇔ "L60TCTT4"
 ⇔ Image: Section of the content of the content



## (a) Devices used by a user

Device	Description	
X22	Error code reset instruction	
X23	Operation mode setting instruction	LX42C4 (X20 to X5F)
X24	Memory of PID constants read instruction	
X1000	Module READY flag	L60TCTT4 (X1000 to X100F)
X1002	Error occurrence flag	
Y60 to Y6F	Error code output	LY42NT1P (Y60 to Y9F)
Y1001	Setting/operation mode instruction	
Y1002	Error reset instruction	
Y1008	Set value backup instruction	L60TCTT4 (Y1000 to Y100F)
Y100B	Setting change instruction	
D9	Write data storage device using Z(P).REMTO instruction (for non-volatile memory read of PID constants)	
D10	Read data storage device using Z(P).REMFR instruction (for non-volatile memory read of PID constants)	
D11	Write data storage device using Z(P).REMTO instruction (for non-volatile memory read of PID constants)	
MO	Master module status check device (for MC and MCR instructions)	
M300 to M305	CH1 Memory of PID constants read flag	
M310, M311	Z(P).REMTO instruction completion/result device	
M312, M313	Z(P).REMFR instruction completion/result device	
M314, M315	Z(P).REMTO instruction completion/result device	
W1050	Error code	Devices where data is written
W1051	CH1 Temperature process value (PV)	by auto refresh
SB49	Data link status (own station)	
SWB0.0	Data link status (each station) (station number 1)	

## (b) Program example

Write the program to the CPU module on the master station.

· Program that checks the data link status of the head module

```
Check the data link status
                                                                             -Гмс
                                                                                               M0
                                                                                     N0
                                                                                                          of the head module*1.
NO T MO
                Add the following MCR instruction to the end of the program.
```

```
-Гмск
         NO
```

· Program that changes the setting/operation mode

```
Change to the setting mode or
-(Y1001
           the operation mode.
```

· Program that reads the PID constants from the non-volatile memory

```
CH1 Memory's PID constant read instruction: With instruction
                                                                                                       -[MOVP
                                                                                                                                D9
                                                                                                                   SET
                                                                                                                                M300
M300
                    ZP.REMTO
                                                                                           Н3Е
                                                                                                                   K1
                                                                                                                                M310
                                                                                                                   -[SET
                                                                                                                                M301
                                                                                                                   -FSET
                                                                                                                                M302
                                                                                                                                              Read Memory's PID constant read/write completion flag to D10.
                                - Z.REMFR "J1
                                                                    K1
                                                                               H0
                                                                                           H1F
                                                                                                       D10
                                                                                                                   K1
                                                                                                                                M312
                                                                                                                                M303
                                                                                                                   -[RST
                                                                                                                                M302
                                                                                                                                              CH1 Memory's PID constant read instruction: Without instruction
                                                                                                                   -FRS1
                                                                                                                                M303
                                                                                                                   {SET
                                                                                                                                M304
                                                                                                                   K0
                                                                                                                                D11
                                                                                                                   -FSFT
                                                                                                                                M305
                    -{ZP.REMTO
                                                                                           Н3Е
                                                                                                       D11
                                                                                                                   K1
                                                                                                                                M314
```

· Program that reads an error code

```
X1000
                                                                                                             Output an error code to Y60 to Y6F.
                                                                               -Гмо∨
                                                                                        W1050
                                                                                                  K4Y60
X22
                                                                                                             Error reset instruction: ON
                                                                                        -FSET
                                                                                                  Y1002
                                                                                                  Y1002
                                                                                                             Error reset instruction: OFF
                                                                                        -[MCR
                                                                                                  N0
                                                                                                 FND
```

# **CHAPTER 11** TROUBLESHOOTING

This chapter describes the causes and corrective actions to take when a problem occurs in the L60TC4.

# 11.1 Before Troubleshooting

Check whether any of the following LEDs are on.

- The POWER LED on the power supply module
- · The MODE LED on the CPU module or head module

If both are off, proceed with CPU module or head module troubleshooting.


- MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
- MELSEC-L CC-Link IE Field Network Head Module User's Manual

# 11.2 Troubleshooting Procedure

This section describes how to find problem causes and take corrective action.

Use GX Works2 to find problem causes and take corrective action.

## (1) Procedure



- Connect GX Works2 to the CPU module to display the "System Monitor" window.
  - [Diagnostics] ⇒ [System Monitor...]


Section Resident Productions Connection Conn

(To the next page)

 After confirming that an error is displayed on the L60TC4, select the L60TC4 and click Detailed Information

If an error LED is ON on a module other than the L60TC4, refer to the user's manual for the module and take corrective action.

# (From the previous page) $\downarrow$



- 3. Click Detailed Information to open the "Module's Detailed Information" window.

  Check the error description and the corrective
  - Check the error description and the corrective action to take under "Error and Solution".
- 4. When the error description cannot be confirmed after doing the operation above, proceed with the following troubleshooting.
  - Checks using LEDs (Page 310, Section 11.3)
  - Checks using input signals (Page 312, Section 11.4)

# 11.3 Checks Using LEDs

This section describes troubleshooting using LEDs.

# 11.3.1 When the RUN LED flashes or turns off

Check Item	Action
Is the power supplied?	Check that the supply voltage of the power supply module is within the rated range.
Is the capacity of power supply module enough?	Calculate the current consumption of the installed CPU module, I/O module, and intelligent function module to check whether power supply capacity is sufficient.
Has a watchdog timer error occurred?	Reset the CPU module or turn on the power supply again.     Replace the L60TC4.
Is the intelligent function module switch setting value outside the setting range?	Set the switch setting value of the intelligent function module to the value within the setting range.

# 11.3.2 When the ERR. LED turns on or flashes

## (1) When turning on

Check Item	Action
Is the intelligent function module switch setting outside the setting range?	Set the switch setting value of the intelligent function module to the value within the setting range.
Is the cold junction temperature compensation resistor disconnected or loose? (The L60TCTT4 and L60TCTT4BW only)	Properly connect the cold junction temperature compensation resistor.
	A hardware failure occurred in the L60TC4.
Others	Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.

## (2) When flashing

Check Item	Action
Has an error occurred?	Check the error code list (P Page 315, Section 11.6) and take actions described.

# 11.3 Checks Using LEDs 11.3.3 When the ALM LED turns on or flashes

# 11.3.3 When the ALM LED turns on or flashes

## (1) When turning on

Check Item	Action
Is CH□ Alert occurrence flag (XnC to XnF) on?	Check CH□ Alert definition (Un\G5 to Un\G8) and take the appropriate
	corrective action. (Fig. Page 336, Appendix 2 (3))

## (2) When flashing

Check Item	Action
Has the temperature process value (PV) exceeded the temperature measurement range set as the input range?	Change the setting of CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128) to a setting in the temperature measurement range to be used. (□ Page 345, Appendix 2 (12))
Is there a channel where no temperature sensor is connected?	Set the channel where no temperature sensor is connected to unused in CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157).  (□ → Page 376, Appendix 2 (35))
Has a loop disconnection been detected?	Check for a load disconnection, externally-operable device failure, and sensor disconnection.

# 11.4 Checks Using Input Signals

This section describes troubleshooting using input signals.

## 11.4.1 When Module READY flag (Xn0) does not turn on

Check Item	Action
Has a watchdog timer error occurred?	Reset the CPU module or turn on the power supply again.     Replace the L60TC4.
Has an error occurred in the programmable controller?	Refer to the user's manual of the used CPU module and take corrective action.

# 11.4.2 When Error occurrence flag (Xn2) is on

Check Item	Action
has an endroccurred?	Check the error code list (Page 315, Section 11.6) and take actions described.

# 11.4.3 When Hardware error flag (Xn3) is on

Check Item	Action
Is the cold junction temperature compensation resistor disconnected or loose? (The L60TCTT4 and L60TCTT4BW only)	Properly connect the cold junction temperature compensation resistor.
Others	A hardware failure occurred in the L60TC4.  Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.

# **11.4.4** When the auto tuning does not start (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)

Check Item	Action
Have the auto tuning start conditions been met?	Refer to the "Auto tuning function" section ( Page 141, Section 8.2.7) and confirm that all conditions have been met.
Has auto tuning ended abnormally?	Check the conditions that signify an abnormal end for auto tuning (FF Page 150, Section 8.2.7 (7)) to see whether it has ended abnormally. If it has ended abnormally, remove the cause. Then execute auto tuning again.

# 11.4.5 When the auto tuning does not complete (CH□ Auto tuning status (Xn4 to Xn7) stays on and does not turn off)

Check Item	Action
Are b4 to b7 of Memory of PID constants read/write completion flag (Un\G31) set to 1 (ON)?	Set CH□ Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159) to Disable (0). (☐ Page 378, Appendix 2 (37))
Is CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) set to Requested (1)?	To back up the setting, turn off and on Set value backup instruction (Yn8).  Set CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) to Not requested (0). (☐ Page 377, Appendix 2 (36))
Has the set value (SV) been set correctly? (Is the manipulated value (MV) still 0% because the set value (SV) is small?)	Set the set value (SV) to the desired value.

# 11.4.6 When the self-tuning does not start (CH□ Auto tuning status (Xn4 to Xn7) does not turn on)

Check Item	Action
Have the self-tuning start conditions been met?	Refer to the "Self-tuning function" section (Fig. Page 175, Section 8.2.15) and confirm that all conditions have been met.
Has self-tuning ended abnormally?	Check the conditions that signify an abnormal end for self-tuning  (Page 183, Section 8.2.15 (8)) to see whether it has ended abnormally. If it has ended abnormally, remove the cause. If the buffer memory setting was changed during self-tuning, restore the value to the one prior to change.

# 11.4.7 When Back-up of the set value fail flag (XnA) is on

Check Item	Action
Has a backup to non-volatile memory failed?	Turn off and on Set value backup instruction (Yn8) and write the setting to the non-volatile memory.  When writing fails again, a hardware is in failure. Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.

## 11.4.8 When CH□ Alert occurrence flag (XnC to XnF) is on

Check Item	Action
	Check CH□ Alert definition (Un\G5 to Un\G8) and take the appropriate
Has the temperature process value (PV) exceeded the alert set value range?	corrective action. (FF Page 336, Appendix 2 (3))
	Correct the alert set value. (Fig. Page 358, Appendix 2 (18))
Has a disconnection been detected?	Check CH□ Alert definition (Un\G5 to Un\G8) and take the appropriate
has a disconnection been detected?	corrective action. (FF Page 336, Appendix 2 (3))

# 11.5 Troubleshooting by Symptom

This section describes troubleshooting using the wiring resistance values of thermocouples.

# 11.5.1 When the temperature process value (PV) is abnormal

Check Item	Action
Is the thermocouple wiring resistance value too high?	<ul> <li>Check the thermocouple wiring resistance value and check whether a difference in the temperatures was caused by the wiring resistance.</li> <li>(Page 36, Section 3.2.2 (1))</li> <li>Use the sensor compensation function to correct the difference in the temperatures caused by the wiring resistance.</li> <li>Page 223, Section 8.3.2 (2))</li> </ul>

# 11.6 Error Code List

When the L60TC4 error occurs during data write to the CPU module or during data read from the CPU module, one of the following error codes is stored in Error code (Un\G0).


In addition, the error occurred is notified to the CPU module.

Error code (hexadecimal)	Cause	Operation at error occurrence	Action
0001 <sub>H</sub>	Hardware error	The operation varies depending on the symptom.	Check that the terminal block or the cold junction temperature compensation resistor is not disconnected or loose. Replace the L60TC4. Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.
□□□2 <sub>H</sub> *1	Data (other than 0) is being written to the system area*2.	<ul> <li>The data written is retained.</li> <li>When data is written to multiple system areas, the address with the smallest number of the buffer memory area where an error was detected is stored.*5</li> </ul>	<ul> <li>Return the value to 0 and turn off, on, and off Error reset instruction (Yn2).</li> <li>Delete the program that is writing data to the system area.</li> </ul>
□□□3 <sub>H</sub> *1	Data is being written in the operation mode*4 to the area where data can be written only in the setting mode*3.	The data written is retained. When data is written to multiple system areas, the address with the smallest number of the buffer memory area where an error was detected is stored.*5	Pollow the instructions below for error reset.  Change the mode to the setting mode.  Set the correct value and turn off, on, and off Setting change instruction (YnB).  Turn off, on, and off Error reset instruction (Yn2).  If switching from the operation mode to the setting mode, check that PID continuation flag (Un\G169) is set to Stop (0), and turn on and off Setting/operation mode instruction (Yn1).
□□□4 <sub>H</sub> *1	Data outside the settable range is being written.	<ul> <li>The data written is retained.</li> <li>If temperature, time, or percentage settings exceed upper limit value/lower limit value, change the data within those values.</li> <li>When data is written to multiple system areas, the address with the smallest number of the buffer memory area where an error was detected is stored.*5</li> </ul>	Set data within the range.
□□□5 <sub>H</sub> *1	The setting of the upper/lower limit value output limiter or the upper/lower limit setting limiter is invalid.	<ul> <li>The data written is retained.</li> <li>Change the setting to an allowable value for the upper/lower limit value.</li> <li>When data is written to multiple system areas, the address with the smallest number of the buffer memory area where an error was detected is stored.*5</li> </ul>	Set the value where the upper limit value is greater than the lower limit value.

Error code (hexadecimal)	Cause	Operation at error occurrence	Action
□□□6 <sub>H</sub> *1	The setting value is being changed while Default setting registration instruction (Yn9) was on.	<ul> <li>The data written is ignored.</li> <li>The setting cannot be changed until an error reset is performed.</li> <li>The content of Error code (Un\G0) does not change even if another write error occurs.</li> </ul>	After turning off, on, and off Error reset instruction (Yn2), change the setting value.
□□□7 <sub>Н</sub> *1	The sensor two-point correction setting is invalid.	<ul> <li>The data written is retained.</li> <li>Use the data of before the setting.</li> <li>When data is written to multiple system areas, the address with the smallest number of the buffer memory area where an error was detected is stored.*5</li> <li>When both the offset value and gain value are within the input range and the offset value is greater than or equal to the gain value, the gain value address is stored as the address where the error occurred.</li> </ul>	Enter the temperature within the input range.     Set the values so that the sensor two-point correction offset value (measured value) is smaller than the sensor two-point correction gain value (measured value) and the sensor two-point correction offset value (corrected value) is smaller than the sensor two-point correction gain value (corrected value).
□□□8 <sub>H</sub> *1	The setting is described by one of the following.  • The process alarm upper upper limit value is smaller than the upper lower limit value.  • The process alarm upper lower limit value is smaller than the lower upper limit value.  • The process alarm lower upper limit value.  • The process alarm lower upper limit value is smaller than the lower lower limit value.	<ul> <li>The data written is retained.</li> <li>the address with the smallest number of the buffer memory area where an error was detected is used as the address where the error occurred.</li> <li>Use the data of before the setting.</li> <li>When data is written to multiple system areas, the address with the smallest number of the buffer memory area where an error was detected is stored.*5</li> </ul>	Set the values that meet the following conditions.  • Process alarm upper upper limit value  ≥ Upper lower limit value  • Process alarm upper lower limit value  ≥ Lower upper limit value  • Process alarm lower upper limit value  ≥ Lower lower limit value
	An alarm has occurred.  Refer to the alarm code list (FF Page 318, Section 11.7).		
0□□E <sub>H</sub> *6	A set value discrepancy error occurred. The current set value is different from the set value backed up in non-volatile memory because one of the following settings on Switch Setting has been changed.  • Control Mode Selection  • Control Output Cycle Unit Selection Setting  • Sampling Cycle Selection	The set value cannot be changed until the control mode is determined.  When the setting under "Control Mode Selection" was changed: All parameters are overwritten with defaults.  When the setting under "Control Output Cycle Unit Selection Setting" was changed: Settings are overwritten with defaults for "Control Output Cycle Setting", "Heating Control Output Cycle Setting", and "Cooling Control Output Cycle Setting"; other settings are overwritten with backed up values.  When the setting under "Sampling Cycle Selection" was changed: All parameters are overwritten with defaults.	Turn off, on, and off Set value backup instruction (Yn8).
000F <sub>H</sub>	Values set in the intelligent function module switch setting are those outside the setting range.	The RUN LED turns off, the ERR. LED turns on, and the module does not operate.	Set the correct values on the intelligent function module switch setting.

Error Code List

- \*1 The address where the error occurred is stored in  $\Box\Box\Box_H$ .
  - Buffer memory addresses are written in decimal (Intelligent function module device (Un\G□)) in this manual. Read the stored value in decimal and refer to the buffer memory list (FF Page 44, Section 3.5).
- \*2 The buffer memory areas checked are Un\G0 to Un\G287. No error occurs for writes in the system area in or after Un\G288.
- \*3 For the writable area in setting mode, refer to the buffer memory list (Page 44, Section 3.5).
- \*4 "In the operation mode" refers to one of the following states.
  - When Setting/operation mode instruction (Yn1) or Setting/operation mode status (Xn1) is on.
  - When Setting/operation mode instruction (Yn1) turns on and off and PID continuation flag (Un\G169) is set to Continue (1).
- \*5 Ex. When an error occurs in CH1 Alert 1 mode setting (Un\G192) and CH1 Alert 2 mode setting (Un\G193), 0C0<sub>H</sub> (hex) in the buffer memory address with the smallest number "Un\G192" is stored in Error code (Un\G0).
- \*6 The error code for a set value discrepancy error indicates the match/no match status with the set value on Switch Setting backed up to non-volatile memory as follows.





When a value outside the setting range is written in the following buffer memory areas while in setting mode, the error
code 4<sub>H</sub> is stored. Switching to operation mode without error reset changes the error code to 3<sub>H</sub>. If this happens, take the
corrective action for error code 3<sub>H</sub>.

Buffer memory area		Buffer memory address			Reference
name	CH1	CH2	СНЗ	CH4	Reference
Input range	Un\G32	Un\G64	Un\G96	Un\G128	Page 345, Appendix 2 (12)
Alert 1 mode setting	Un\G192	Un\G208	Un\G224	Un\G240	
Alert 2 mode setting	Un\G193	Un\G209	Un\G225	Un\G241	- - Page 386, Appendix 2 (52)
Alert 3 mode setting	Un\G194	Un\G210	Un\G226	Un\G242	- Page 300, Appendix 2 (32)
Alert 4 mode setting	Un\G195	Un\G211	Un\G227	Un\G243	

• Error code priorities are as described below.

Priority


When a high-priority error occurs during a low-priority error, the error code of the high-priority error is written over the error occurrence address.

Only one error code, as dictated by error priority, is stored in Error code (Un\G0). For that reason, when multiple errors
occur at the same time, the next error code is stored, even when the error of the stored error code is corrected. Check for
errors other than the stored error code in the parameters of other channels.

## 11.7 Alarm Code List

The following table lists alarm codes.

The alarm code is stored in all bits of Error code (Un\G0).



If the lower four bits are "0001" ( $1_H$ ) to "1001" ( $9_H$ ) or "1011" ( $B_H$ ) to "1111" ( $F_H$ ), an error occurs. When an error occurs, refer to the error code list ([ $\bigcirc$  $\Longrightarrow$  Page 315, Section 11.6).

Alarm code (hexadecimal) *1	Cause	Operation at alarm occurrence	Action
01□A <sub>H</sub>	The temperature process value (PV) has exceeded the temperature measurement range that was set as the input range.	The ALM LED flashes.  CH□ Alert occurrence flag (XnC to XnF) turns on.  CH□ Input range upper limit (b0 of Un\G5 to Un\G8) turns on.	When Error reset instruction (Yn2) is turned OFF $\rightarrow$ ON $\rightarrow$ OFF after the temperature process value (PV) has returned to the value within the temperature measurement range, Error code (Un\G0) is cleared to 0.
02□A <sub>H</sub>	The temperature process value (PV) is below the temperature measurement range that was set as the input range.	The ALM LED flashes. CH□ Alert occurrence flag (XnC to XnF) turns on. CH□ Input range lower limit (b1 of Un\G5 to Un\G8) turns on.	The following flags and buffer memory bits that turn on when an alarm occurs turn off automatically when the temperature process value (PV) has returned to the value within the temperature measurement range.  • CH□ Alert occurrence flag (XnC to XnF)  • The applicable bit (FFP Page 336, Appendix 2 (3)) of CH□ Alert definition (Un\G5 to Un\G8)
03□A <sub>H</sub>	A loop disconnection has been detected.	The ALM LED flashes.  CH□ Alert occurrence flag (XnC to XnF) turns on.  CH□ Loop disconnection detection (b13 of Un\G5 to Un\G8) turns on.	When Error reset instruction (Yn2) is turned OFF $\rightarrow$ ON $\rightarrow$ OFF after a current error due to a disconnection or output-off is restored, Error code (Un\G0) is cleared to 0.
04□A <sub>H</sub>	A heater disconnection has been detected.	The HBA LED turns on.  CH□ Alert occurrence flag (XnC to XnF) turns on.  CH□ Heater disconnection detection (b12 of Un\G5 to Un\G8) turns on.	The following flags and buffer memory bits that turn on when an alarm occurs turn off automatically when the current error due to disconnection or output-off is restored.  • CH□ Alert occurrence flag (XnC to XnF)  • The applicable bit (☐ Page 336, Appendix 2 (3)) of CH□ Alert definition (Un\G5 to Un\G8)
05□A <sub>H</sub>	A current error at an output off-time has been detected.	The HBA LED turns on. CH□ Alert occurrence flag (XnC to XnF) turns on. CH□ Output off-time current error (b14 of Un\G5 to Un\G8) turns on.	

Alarm code (hexadecimal) *1	Cause	Operation at alarm occurrence	Action
06□A <sub>H</sub>	Alert 1 has occurred.	The ALM LED turns on. CH□ Alert occurrence flag (XnC to XnF) turns on. CH□ Alert 1 (b8 of Un\G5 to Un\G8) turns on.	When Error reset instruction (Yn2) is turned
07□A <sub>H</sub>	Alert 2 has occurred.	The ALM LED turns on. CH□ Alert occurrence flag (XnC to XnF) turns on. CH□ Alert 2 (b9 of Un\G5 to Un\G8) turns on.	OFF → ON → OFF after the temperature process value (PV) is restored from alert status, Error code (Un\G0) is cleared to 0.  The following flags and buffer memory bits that turn on when an alarm occurs turn off
08□A <sub>H</sub>	Alert 3 has occurred.	The ALM LED turns on. CH□ Alert occurrence flag (XnC to XnF) turns on. CH□ Alert 3 (b10 of Un\G5 to Un\G8) turns on.	automatically when the temperature process value (PV) is restored from alert status.  • CH□ Alert occurrence flag (XnC to XnF)  • The applicable bit (☐ Page 336, Appendix 2 (3)) of CH□ Alert definition (Un\G5 to
09□A <sub>H</sub>	Alert 4 has occurred.	The ALM LED turns on. CH□ Alert occurrence flag (XnC to XnF) turns on. CH□ Alert 4 (b11 of Un\G5 to Un\G8) turns on.	Un\G8)
0A□A <sub>H</sub>	A process alarm upper limit alert has occurred.	The ALM LED turns on.  CH□ Alert occurrence flag (XnC to XnF) turns on.  CH□ Process alarm upper limit alert (b2 of Un\G5 to Un\G8) turns on.	When Error recet instruction (Vp2) is turned
0B□A <sub>H</sub>	A process alarm lower limit alert has occurred.	The ALM LED turns on.     CH□ Alert occurrence flag (XnC to XnF) turns on.     CH□ Process alarm upper limit alert (b3 of Un\G5 to Un\G8) turns on.	When Error reset instruction (Yn2) is turned OFF → ON → OFF after the temperature process value (PV) is restored from alert status, Error code (Un\G0) is cleared to 0.  The following flags and buffer memory bits that turn on when an alarm occurs turn off automatically when the temperature process value (PV) is restored from alert status.  • CH□ Alert occurrence flag (XnC to XnF)  • The applicable bit (□ Page 336, Appendix 2 (3)) of CH□ Alert definition (Un\G5 to Un\G8)
0C□A <sub>H</sub>	A rate alarm upper limit alert has occurred.	The ALM LED turns on.  CH□ Alert occurrence flag (XnC to XnF) turns on.  CH□ Rate alarm upper limit alert (b4 of Un\G5 to Un\G8) turns on.	
0D□A <sub>H</sub>	A rate alarm lower limit alert has been occurred.	The ALM LED turns on.  CH□ Alert occurrence flag (XnC to XnF) turns on.  CH□ Process alarm upper limit alert (b5 of Un\G5 to Un\G8) turns on.  channel (1μ to 4μ) where the alarm of the channel (1μ to 4μ) where the channel (1	,

<sup>\*1</sup>  $\ \square$  represents the number of the channel (1<sub>H</sub> to 4<sub>H</sub>) where the alarm occurred.



- The error code is always given priority over the alarm code for being stored in Error code (Un\G0).
   For that reason, when an alarm occurs during an error, the alarm code is not stored in Error code (Un\G0).
   Further, when an error occurs during an alarm, the error code is written over the alarm code in Error code (Un\G0).
- · Alarm priorities are as follows.

When an alarm occurs, if its priority is the same as or higher than that of alarms already occurred, the new alarm code is written over Error code (Un\G0).

Check the L60TC4 Status

# 11.8 Check the L60TC4 Status

The error code and hardware status can be checked by selecting "Module's Detailed Information" of the L60TC4 in the system monitor of the programming tool.

## (1) Operating the programming tool

From [Diagnostics] 

□ System Monitor...] 
□ "Main Block", select L60TC4
□ Detailed Information ...

## (2) Module's Detailed Information


#### (a) Checking the function version and product information

The Product Information field shows the L60TC4 function version and product information.

### (b) Checking the error code

The Latest Error Code field shows the error code stored in Error code (Un\G0) in the L60TC4.

(Press Update Error History to display the content shown under Latest Error Code as No.1.)



## (3) Hardware information

On the "Module's Detailed Information" window, click H/W Information .

### (a) H/W LED information


The following information is displayed.

Item	Value	Condition for 0001 <sub>H</sub>
RUN		Operating normally (same as the RUN LED)
DATA ERR		A write data error has occurred
CH□ RUN		PID control is being run
CH□ ALM1		Alert 1 is on
CH□ ALM2	• 0000 <sub>H</sub> : off • 0001 <sub>H</sub> : on	Alert 2 is on
CH□ ALM3		Alert 3 is on
CH□ ALM4	, see 1 <sub>H</sub> , s	Alert 4 is on
CH□ LBA		A loop disconnection has been detected
СН□ НВА		A heater disconnection has been detected (the L60TCTT4BW and L60TCRT4BW only)
H/W ERR		A hardware error has occurred

## (b) H/W switch information

The setting status of the intelligent function module switch setting is displayed.

Item	Intelligent function module switch setting	Value
HOLD/CLR	Switch 1: Output Setting at CPU Stop Error	
CTRL MODE	Switch 2: Control Mode Selection	
SW3	Switch 3:     Setting Change Rate Limiter Setting     Control Output Cycle Unit Selection Setting     Output Setting at CPU Stop Error     Auto-setting at Input Range Change     Sampling Cycle Selection	Refer to Page 108, Section 7.2



# **APPENDICES**

# Appendix 1 Details of I/O Signals

The following section describes the details of the L60TC4 I/O signals toward the CPU module. The I/O numbers (X/Y) described in Appendix 1 is for the case when the start I/O number of the L60TC4 is set to 0.

# Appendix 1.1 Input signal

#### (1) Module READY flag (Xn0)


This flag turns on to indicate that the preparation for the L60TC4 is completed when the module is turned on from off or when the CPU module's reset is released.

Make sure that this flag is on when reading/writing data from/in the buffer memory of the L60TC4 from the CPU module. The following shows an example of a program. (In the following example, the start I/O number of the L60TC4 is set to 10.)

If the watchdog timer error is detected, this flag turns off. The L60TC4 stops controlling the temperature and the transistor output turns off. (The RUN LED turns off and ERR. LED turns on.)

#### (2) Setting/operation mode status (Xn1)

This signal turns on at the operation mode, off at the setting mode.



----- Executed by the L60TC4

#### (a) Precautions during the mode shifting

The mode shifting means the following timings.

- From Setting/operation mode instruction (Yn1) OFF → ON to Setting/operation mode status (Xn1) ON (above figure 1)
- From Setting/operation mode instruction (Yn1) ON → OFF to Setting/operation mode status (Xn1) OFF
  (above figure ②)

During the mode shifting, do not change the set values. If the set values are changed during the mode shifting, the module operation cannot be guaranteed. Use Setting/operation mode status (Xn1) as an interlock condition for Setting/operation mode instruction (Yn1) when changing the setting.



The conditions whether to perform the temperature judgment, PID control, and alert judgment by the L60TC4 differ among the following timings.

- · Setting mode at power-ON
- · Operation mode (in operation)
- · Setting mode (after operation)

For each detail on the temperature judgment, PID control, and alert judgment, refer to the following.

- Temperature judgment: Page 336, Appendix 2 (3)
- PID control: Page 134, Section 8.2.3 (6)
- Alert judgment: Page 166, Section 8.2.11 (5)

#### (3) Error occurrence flag (Xn2)


This flag turns on when errors other than a hardware error occur.

After an error occurs and the error code is stored in Error code (Un\G0), this flag turns on.

Errors occur under the following conditions.

- · When data is set in the buffer memory of the system area
- When the setting of the area which can be written only during the setting mode (Setting/operation mode status (Xn1): OFF) is changed during the operation mode (Setting/operation mode status (Xn1): ON)

  (Fig. Page 324, Appendix 1.1 (2))
- · When the data which cannot be set is set
- When the setting of the buffer memory is changed during the default setting registration (Page 332, Appendix 1.2 (5))
- When the current set value and the set value backed up in the non-volatile memory are different due to the change on Switch Setting.



----- Executed by the L60TC4

## (4) Hardware error flag (Xn3)

This flag turns on when hardware error occurs in the L60TC4.

#### (5) CH□ Auto tuning status (Xn4 to Xn7)

This signal turns on when auto tuning of each channel is set by the user or when the L60TC4 performs self-tuning.


	A	uto tuning statu					
Channel	Standard control	Heating- cooling control	Mix control	ON/OFF status			
CH1	Xn4	Xn4	Xn4	ON: The auto tuning/self-tuning is being			
CH2	Xn5	Xn5	Xn5 <sup>*2</sup>	performed.			
CH3	Xn6	Xn6 <sup>*1</sup>	Xn6	OFF: The auto tuning/self-tuning is not being			
CH4	Xn7	Xn7 <sup>*1</sup>	Xn7	performed or is completed.			

<sup>\*1</sup> Available only under the heating-cooling control (expanded mode). For details on the expanded mode, refer to Page 127, Section 8.2.1 (3).

#### (a) Performing auto tuning

To perform auto tuning, turn CH□ Auto turning instruction (Yn4 to Yn7) on from off.

While auto tuning is in process, this signal is on, and turns off at the completion of the auto tuning.



For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

#### (b) Self-tuning

This signal turns on when self-tuning starts. This signal automatically turns off at the completion of the self-tuning.

Set a self-tuning option in CH $\square$  Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670). (FFPage 399, Appendix 2 (72)) Self-tuning can be executed only in the standard control.


For details on the self-tuning function, refer to the following.

Page 175, Section 8.2.15

<sup>\*2</sup> Available only under the mix control (expanded mode). For details on the expanded mode, refer to Page 127, Section 8.2.1 (3).

#### (6) Back-up of the set value completion flag (Xn8)

Turning Set value backup instruction (Yn8) on from off starts the writing of the buffer memory data to the non-volatile memory. After the data writing is completed, this flag turns on. Turning Set value backup instruction (Yn8) off from on also turns off this flag.




For details on the data writing to the non-volatile memory, refer to the following.

Page 235, Section 8.3.4

#### (7) Default value write completion flag (Xn9)

Turning Default setting registration instruction (Yn9) on from off starts the writing of the default value of the L60TC4 to the buffer memory. After the data writing is completed, this flag turns on. Turning Default setting registration instruction (Yn9) off from on also turns off this flag.



#### (a) Unused channel

For unused channels (which temperature sensors are not connected to), CH Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) must be set to Unused (1) after the completion of the writing of the default value.


If not, ALM LED blinks.

For details on the unused channel setting, refer to the following.

Page 106, Section 6.6

#### (8) Back-up of the set value fail flag (XnA)

Turning Set value backup instruction (Yn8) on from off starts the writing of the buffer memory data to the non-volatile memory. This flag turns on when the writing failed.



After the data writing is completed properly, this flag turns off.

For details on the data writing to the non-volatile memory, refer to the following.


Page 235, Section 8.3.4



After Set value backup instruction (Yn8) is turned on from off, make sure that this flag is off. Then turn Set value backup instruction (Yn8) off from on . If Set value backup instruction (Yn8) is turned off from on while this flag is on, the L60TC4 operates with the default value since the data in the buffer memory is undefined. Likewise, if the power supply is turned on from off or the CPU module is released from the reset status while this flag is on, the L60TC4 operates with the default value since the data in the buffer memory is undefined.

#### (9) Setting change completion flag (XnB)

Turning Setting change instruction (YnB) on from off during the setting mode (Setting/operation mode status (Xn1): OFF) reflects the set contents of each buffer memory to the control. After the data is reflected, this flag turns on. Turning Setting change instruction (YnB) off from on also turns off this flag.



This flag can be used as an interlock condition for Setting/operation mode instruction (Yn1).

## (10)CH□ Alert occurrence flag (XnC to XnF)


When an alert occurs, the alert definition is stored in CH $\square$  Alert definition (Un\G5 to Un\G8), and this flag turns on.


For conditions where this flag turns off, refer to the following.

Page 166, Section 8.2.11 (6)

The following table lists the partucular flag and buffer memory addresses of alert definitions for each channel.

Channel	Alert occurrence flag	ON/OFF status	CH□ Alert definition (buffer memory address)([☐ Page 336, Appendix 2 (3))
CH1	XnC		Un\G5
CH2	XnD	OFF: Alert does not	Un\G6
CH3	XnE	occur. ON: Alert occurs.	Un\G7
CH4	XnF		Un\G8





----- Executed by the L60TC4

# Appendix 1.2 Output signal

#### (1) Setting/operation mode instruction (Yn1)

Use this signal to select the setting mode or the operation mode.

OFF: Setting mode ON: Operation mode

Some buffer memory areas can be set only in the setting mode.

#### (a) Buffer memory areas that can be set only in the setting mode

The following settings can be changed only when Setting/operation mode instruction (Yn1) is off. If the settings are changed in the operation mode, a write data error (error code:  $\Box\Box\Box\Box$  3<sub>H</sub>) occurs.

Duffer memory area no		Buffer me	Deference				
Buffer memory area name	CH1	CH2	CH3	CH4	Reference		
CH□ Input range	Un\G32	Un\G64	Un\G96	Un\G128	Page 345, Appendix 2 (12)		
Resolution of the manipulated value for output with another analog module	Un\G181		<b>-</b>	<b>-</b>	Page 384, Appendix 2 (48)		
CH□ Alert 1 mode setting	Un\G192	Un\G208	Un\G224	Un\G240			
CH□ Alert 2 mode setting	Un\G193	Un\G209	Un\G225	Un\G241	Dans 200 Amendia 2 (F2)		
CH□ Alert 3 mode setting	Un\G194	Un\G210	Un\G226	Un\G242	Page 386, Appendix 2 (52)		
CH□ Alert 4 mode setting	Un\G195	Un\G211	Un\G227	Un\G243			
CH□ Process alarm alert output enable/disable setting	Un\G196	Un\G212	Un\G228	Un\G244	Page 387, Appendix 2 (53)		
CH□ Process alarm lower lower limit value	Un\G197	Un\G213	Un\G229	Un\G245			
CH□ Process alarm lower upper limit value	Un\G198	Un\G214	Un\G230	Un\G246	Dans 200 Annondiv 2 (54)		
CH□ Process alarm upper lower limit value	Un\G199	Un\G215	Un\G231	Un\G247	Page 388, Appendix 2 (54)		
CH□ Process alarm upper upper limit value	Un\G200	Un\G216	Un\G232	Un\G248			
CH□ Rate alarm alert output enable/disable setting	Un\G201	Un\G217	Un\G233	Un\G249	Page 389, Appendix 2 (55)		
CH□ Rate alarm alert detection cycle	Un\G202	Un\G218	Un\G234	Un\G250	Page 389, Appendix 2 (56)		
CH□ Rate alarm upper limit value	Un\G203	Un\G219	Un\G235	Un\G251	Danis 000 Annandis 0 (57)		
CH□ Rate alarm lower limit value	Un\G204 Un\G220 Un\G236		Un\G236	Un\G252	Page 390, Appendix 2 (57)		
CT□ CT selection	Un\G272 to L	In\G279 (set for	Page 392, Appendix 2 (60)				
CH□ 2-point sensor compensation offset value (measured value)	Un\G544	Un\G576	Un\G608	Un\G640	Page 394, Appendix 2 (63)		
CH□ 2-point sensor compensation offset value (compensation value)	Un\G545	Un\G577	Un\G609	Un\G641	Page 394, Appendix 2 (64)		
CH□ 2-point sensor compensation gain value (measured value)	Un\G546	Un\G578	Un\G610	Un\G642	Page 395, Appendix 2 (65)		
CH□ 2-point sensor compensation gain value (compensation value)	Un\G547	Un\G579	Un\G611	Un\G643	Page 395, Appendix 2 (66)		
CH□ 2-point sensor compensation offset latch request	Un\G548	Un\G580	Un\G612	Un\G644	Page 396, Appendix 2 (67)		
CH□ 2-point sensor compensation gain latch request	Un\G550	Un\G582	Un\G614	Un\G646	Page 397, Appendix 2 (69)		
Conversion enable/disable setting	Un\G693	•	Page 402, Appendix 2 (75)				
Cooling method setting	Un\G719				Page 404, Appendix 2 (77)		
CH□ Process value (PV) scaling function enable/disable setting	Un\G725	Un\G741	Un\G757	Un\G773	Page 405, Appendix 2 (80)		

Buffer memory area name		Buffer mer	Reference		
buller memory area name	CH1	CH2	CH3	CH4	Reference
CH□ Process value (PV) scaling lower limit value	Un\G726	Un\G742	Un\G758	Un\G774	- Page 406, Appendix 2 (81)
CH□ Process value (PV) scaling upper limit value	Un\G727	Un\G743	Un\G759	Un\G775	1 age 400, Appendix 2 (01)
CH□ Derivative action selection	Un\G729	Un\G745	Un\G761	Un\G777	Page 407, Appendix 2 (83)
CH□ Simultaneous temperature rise group setting	Un\G730	Un\G746	Un\G762	Un\G778	Page 407, Appendix 2 (84)
CH□ Setting change rate limiter unit time setting	Un\G735	Un\G751	Un\G767	Un\G783	Page 411, Appendix 2 (89)
Peak current suppression control group setting	Un\G784				Page 412, Appendix 2 (90)
Sensor compensation function selection	Un\G785		Page 413, Appendix 2 (91)		

#### (2) Error reset instruction (Yn2)

Use this signal to turn off Error occurrence flag (Xn2) and to reset Error code (Un\G0). For the method to reset an error, refer to Error occurrence flag (Xn2). (Fig. Page 325, Appendix 1.1 (3))

#### (3) CH□ Auto tuning instruction (Yn4 to Yn7)

Use this signal to start auto tuning. Turning this signal on from off starts auto tuning and turns on CH $\square$  Auto tuning status (Xn4 to Xn7). After auto tuning is completed, CH $\square$  Auto tuning status (Xn4 to Xn7) turns off. Keep this instruction ON during auto tuning and turn it off from on at the completion of the auto tuning. If this instruction is turned off from on during auto tuning, the auto tuning stops. If the auto tuning stops, PID constants in the buffer memory do not change.

# Point P

- If proportional band (P)/heating proportional band (Ph) is set to 0, auto tuning cannot be performed. (F) Page 355, Appendix 2 (15))
- If Setting/operation mode instruction (Yn1) is turned off from on and the operation status shifts to the setting mode during auto tuning, the auto tuning stops. After that, even if Setting/operation mode instruction (Yn1) is turned on from off and the the operation status shifts back to the operation mode, the auto tuning does not resume. To resume the auto tuning, turn Auto tuning instruction (Yn4 to Yn7) off from on, and turn it on from off again.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

#### (4) Set value backup instruction (Yn8)

Use this signal to write the buffer memory data to the non-volatile memory. Turning this instruction on from off starts the data writing to the non-volatile memory.

For the buffer memory areas whose data is to be backed up, refer to the following.

Page 44, Section 3.5

#### (a) When data writing to the non-volatile memory has completed normally

Back-up of the set value completion flag (Xn8) turns on.

#### (b) When data writing to the non-volatile memory has not completed normally

Back-up of the set value fail flag (XnA) turns on. When Back-up of the set value fail flag (XnA) turns on, turn Set value backup instruction (Yn8) on from off to write the data to the non-volatile memory again.

#### (c) Timings when this instruction cannot be received

In the following timings, this instruction cannot be received.

- · 1: While PID constants are written after auto tuning
- 2: While PID constants are read from the non-volatile memory
- · 3: While a setting error is occurring
- 4: While a setting is being changed by Setting change instruction (YnB)

For 1 to 3 above, turn this instruction on from off after each condition is resolved. For 4, the data writing to the non-volatile memory automatically starts after the condition is resolved.

For details on the data writing to the non-volatile memory, refer to the following.

Page 235, Section 8.3.4

#### (5) Default setting registration instruction (Yn9)

Use this signal to set data in the buffer memory or the non-volatile memory back to the default value. Turning this instruction on from off starts the writing of the default value of the L60TC4 to the buffer memory. After the data writing is completed, Default value write completion flag (Xn9) turns on.

#### (a) When Setting/operation mode status (Xn1) is on (in operation mode)

Turning this instruction on from off does not set data back to the default value. Turn on this instruction when Setting/operation mode status (Xn1) is off (in the setting mode).

#### (6) Setting change instruction (YnB)

Use this instruction to confirm the set value of the buffer memory (the buffer memory areas that can be set only in the setting mode (Setting/operation mode status (Xn1): OFF). (Fig. Page 330, Appendix 1.2 (1))

#### (a) Reflection of set value

Even though the set values are written into the buffer memory, they cannot be reflected to the L60TC4's operation immediately. To confirm the set values, turn this instruction OFF  $\rightarrow$  ON  $\rightarrow$  OFF after the set values are written into the buffer memory. Doing so lets the L60TC4 operate according to the setting in each buffer memory area.

#### (7) CH□ PID control forced stop instruction (YnC to YnF)

Use this signal to temporarily stop PID control forcibly.

#### (a) Mode when PID control stops

The mode depends on the setting of CH $\square$  Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129). For details on CH $\square$  Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129), refer to the following. Page 353, Appendix 2 (13)

# Appendix 2 Details of the Buffer Memory

This chapter describes details on the buffer memory of the L60TC4.



For buffer memory areas indicated with the icons standard and Heating-cooling, or with common, the following terms are used, unless otherwise specified.

- · Proportional band (P): includes heating proportional band (Ph) and cooling proportional band (Pc)
- Manipulated value (MV): includes manipulated value for heating (MVh) and manipulated value for cooling (MVc).
- · Transistor output: includes heating transistor output and cooling transistor output
- · Control output cycle: includes heating control output cycle and cooling control output cycle

## (1) Error code (Un\G0) Common

An error code or alarm code is stored in this buffer memory area.

For error codes and alarm codes, refer to the following.

Page 315, Section 11.6, Page 318, Section 11.7

# (2) CH□ Decimal point position (Un\G1 to Un\G4) Common

According to the setting of CH Input range (Un\G32, Un\G64, Un\G96, Un\G128), the decimal point position applicable in the following buffer memory areas is stored in this buffer memory area.

Duffer memory area name		Buffer mei	Reference			
Buffer memory area name	CH1	CH2	CH3	CH4	Reference	
CH□ Temperature process value (PV)	Un\G9	Un\G10	Un\G11	Un\G12	Page 338, Appendix 2 (4)	
CH□ Set value (SV) setting	Un\G34	Un\G66	Un\G98	Un\G130	Page 354, Appendix 2 (14)	
CH□ Alert set value 1	Un\G38	Un\G70	Un\G102	Un\G134		
CH□ Alert set value 2	Un\G39	Un\G71	Un\G103	Un\G135	Page 358, Appendix 2	
CH□ Alert set value 3	Un\G40	Un\G72	Un\G104	Un\G136	(18)	
CH□ Alert set value 4	Un\G41	Un\G73	Un\G105	Un\G137		
CH□ AT bias setting	Un\G53	Un\G85	Un\G117	Un\G149	Page 370, Appendix 2 (29)	
CH□ Upper limit setting limiter	Un\G55	Un\G87	Un\G119	Un\G151	Page 372, Appendix 2	
CH□ Lower limit setting limiter	Un\G56	Un\G88	Un\G120	Un\G152	(31)	
CH□ Loop disconnection detection dead band	Un\G60	Un\G92	Un\G124	Un\G156	Page 375, Appendix 2 (34)	
CH□ Process alarm lower lower limit value	Un\G197	Un\G213	Un\G229	Un\G245		
CH□ Process alarm lower upper limit value	Un\G198	Un\G214	Un\G230	Un\G246	Page 388, Appendix 2	
CH□ Process alarm upper lower limit value	Un\G199	Un\G215	Un\G231	Un\G247	(54)	
CH□ Process alarm upper upper limit value	Un\G200	Un\G216	Un\G232	Un\G248		
CH□ Rate alarm upper limit value	Un\G203	Un\G219	Un\G235	Un\G251	Page 390, Appendix 2	
CH□ Rate alarm lower limit value	Un\G204	Un\G220	Un\G236	Un\G252	(57)	
CH□ 2-point sensor compensation offset value (measured value)	Un\G544	Un\G576	Un\G608	Un\G640	Page 394, Appendix 2 (63)	
CH□ 2-point sensor compensation offset value (compensation value)	Un\G545	Un\G577	Un\G609	Un\G641	Page 394, Appendix 2 (64)	

Buffer memory area name		Buffer mem	Reference		
Bullet memory area name	CH1	CH2	CH3	CH4	Kelelelice
CH□ 2-point sensor compensation gain value (measured value)	Un\G546	Un\G578	Un\G610	Un\G642	Page 395, Appendix 2 (65)
CH□ 2-point sensor compensation gain value (compensation value)	Un\G547	Un\G579	Un\G611	Un\G643	Page 395, Appendix 2 (66)
CH□ Simultaneous temperature rise gradient data	Un\G731	Un\G747	Un\G763	Un\G779	Page 408, Appendix 2 (85)

Stored values differ depending on the setting in CH Input range (Un\G32, Un\G64, Un\G96, Un\G128).

Setting of CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)  (□ Page 345, Appendix 2 (12))	Stored value	Setting contents	
Resolution is 1.	0	Nothing after decimal point	
Resolution is 0.1.	1	First decimal place	

# (3) CH□ Alert definition (Un\G5 to Un\G8) common

Bits corresponding to alerts detected in each channel become 1.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0								0	0						
Bit da	t data b15 are Bit data from b7 to														
fixed to 0. b2 are fixed to 0.															

Target bit number	Flag name	Alert definition		
b0	CH□ Input range upper limit	Temperature process value (PV) has exceeded the temperature		
DO	Crib inputrange upper infint	measurement range <sup>*1</sup> of the set input range.		
b1	CH□ Input range lower limit	Temperature process value (PV) has fallen below the temperature		
	OTIL Input range lower limit	measurement range <sup>*1</sup> of the set input range.		
b2	CH□ Process alarm upper limit	Temperature process value (PV) has reached the process alarm upper		
-		upper limit value or more.		
b3	CH□ Process alarm lower limit	Temperature process value (PV) has reached the process alarm lower		
		lower limit value or lower.		
b4	CH□ Rate alarm upper limit	The variation of temperature process value (PV) has reached the rate alarm upper limit value or more.		
		The variation of temperature process value (PV) has reached the rate		
b5	CH□ Rate alarm lower limit	alarm lower limit value or lower.		
b6 to b7	— (fixed to 0)	— (Unused)		
b8	CH□ Alert 1	Alert 1 has occurred. (FF Page 157, Section 8.2.11)		
b9	CH□ Alert 2	Alert 2 has occurred. (FP Page 157, Section 8.2.11)		
b10	CH□ Alert 3	Alert 3 has occurred. ( Page 157, Section 8.2.11)		
b11	CH□ Alert 4	Alert 4 has occurred. (FP Page 157, Section 8.2.11)		
b12	CH□ Heater disconnection detection	Heater disconnection has been detected. (FP Page 215, Section 8.2.24)		
b13	CH□ Loop disconnection detection	Loop disconnection has been detected. (FP Page 204, Section 8.2.19)		
b14	CH□ Output off-time current error	Output off-time current error has been detected. ( Page 220, Section		
		8.2.25)		
b15	— (fixed to 0)	— (Unused)		

<sup>\*1</sup> For the temperature measurement range, refer to Page 337, Appendix 2 (3) (a).

#### (a) Temperature measurement range

The temperature measurement range is as follows.

- Input range lower limit 5% of full scale to Input range upper limit + 5% of full scale
- Ex. A calculation example when CH Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (temperature measurement range: -200.0 to 400.0°C)
- Input range lower limit 5% of full scale = -200 ((400.0 (-200.0)) × 0.05) = -230.0
- Input range upper limit + 5% of full scale = 400 + ((400.0 (-200.0)) × 0.05) = 430.0

Therefore, the temperature measurement range is -230.0 to 430.0°C.

The L60TC4 checks whether the input temperature is in temperature measurement range of the input range. When the input temperature is out of the temperature measurement range, CH $\square$  Input range upper limit (b0 of Un\G5 to Un\G8), or CH $\square$  Input range lower limit (b1 of Un\G5 to Un\G8) becomes 1 (ON). The conditions which the L60TC4 uses to judge whether the measured temperature is within the temperature measurement range differ depending on the following settings.

- Setting/operation mode instruction (Yn1) (FP Page 330, Appendix 1.2 (1))
- PID continuation flag (Un\G169) (Page 381, Appendix 2 (43))
- CH PID control forced stop instruction (YnC to YnF) (Page 333, Appendix 1.2 (7))
- CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) ([☐ Page 353, Appendix 2 (13))



The following table lists the conditions whether to perform the temperature judgment.

○: Executed ×: Not executed

Setting/operation mode instruction (Yn1)*1	PID continuation flag (Un\G169)	CH□ PID control forced stop instruction (YnC to YnF)	CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129)	Temperature judgment
			Stop (0)	×
Setting mode at power-ON	Stop (0)/Continue (1)	OFF/ON	Monitor (1)	0
power orv	(1)		Alert (2)	0
		OFF	Stop (0)/Monitor (1)/Alert (2)	0
Operation mode	Stop (0)/Continue		Stop (0)	×
(in operation)	(1)	ON	Monitor (1)	0
			Alert (2)	0
			Stop (0)	×
	Stop (0)	OFF/ON	Monitor (1)	0
			Alert (2)	0
Setting mode (after operation)		OFF	Stop (0)/Monitor (1)/Alert (2)	0
(alter operation)	Continue (1)		Stop (0)	×
	Continue (1)	ON	Monitor (1)	0
			Alert (2)	0

<sup>\*1</sup> Refer to Page 324, Appendix 1.1 (2) for each timing.

If CH Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Disable (1), temperature judgment is not executed even though the condition above is satisfied. (Fig. Page 376, Appendix 2 (35))

# (4) CH□ Temperature process value (PV) (Un\G9 to Un\G12) Common

The detected temperature value where sensor correction is performed is stored in this buffer memory area. The value to be stored differs depending on the stored value in CH $\square$  Decimal point position (Un\G1 to Un\G4).

(F) Page 334, Appendix 2 (2))

- No decimal place (0): Stored as it is.
- One decimal place (1): Stored after a multiplication by 10.



When value measured by a temperature sensor exceeds the temperature measurement range, the following value is stored.

- When measured value exceeds temperature measurement range: Input range upper limit + 5% of full scale
- When measured value falls below temperature measurement range: Input range lower limit 5% of full scale

# Appendix 2 Details of the Buffer Memory

# (5) CH□ Manipulated value (MV) (Un\G13 to Un\G16) Standard

## CH□ Manipulated value for heating (MVh) (Un\G13 to Un\G16) Heating-cooling

#### CH□ Manipulated value for cooling (MVc) (Un\G704 to Un\G707) Healing-cooling



The result of PID operation based on temperature process value (PV) is stored in these buffer memory areas. The area Un\G13 to Un\G16 are used for heating in the case of the heating-cooling control. The following table lists the range of values to be stored.

Store description	Store range in control	Stored value when control stops		
Manipulated value (MV)	-50 to 1050 (-5% to 105.0%)	-50 (-5.0%)		
Manipulated value for heating (MVh)	0 to 1050 (0.0% to 105.0%)	-50 (-5.0%)		
Manipulated value for cooling (MVc)	0 to 1050 (0.0% to 105.0%)	-50 (-5.0%)		

However, values are output in the range of 0% to 100%. For 0% or less and 100% or more, refer to the following.


- For 0% or less: 0%
- For 100% or more: 100%

#### (a) Manipulated value (MV) and control output cycle

- Manipulated value (MV) indicates ON time of CH□ Control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143) in percentage. (FP Page 364, Appendix 2 (23))
- Manipulated value for heating (MVh) indicates ON time of CH□ Heating control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143) in percentage. (FP Page 364, Appendix 2 (23))
- Manipulated value for cooling (MVc) indicates ON time of CH□ Cooling control output cycle setting (Un\G722, Un\G738, Un\G754, Un\G770) in percentage. (FP Page 364, Appendix 2 (23)) Ex. When 600 (60.0%) is stored in CH Manipulated value (MV) (Un\G13 to Un\G16) and the value of the buffer memory is set as shown in the following.
- CH□ Control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143): 30s ON time of transistor output = Control output cycle setting (s) × Manipulated value (MV) (%) = 30 × 0.6 = 18 (s)

ON time of transistor output is 18s.

Transistor output is pulse of ON for 18s, OFF for 12s.




## (6) CH□ Temperature rise judgment flag (Un\G17 to Un\G20) Standard Healing-cooling

This flag is for checking whether the temperature process value (PV) is in the temperature rise completion range or not.

The following values are stored in this buffer memory area.

- 0: Out of temperature rise completion range
- 1: Within temperature rise completion range

When the temperature process value (PV) stays in the temperature rise completion range during the set temperature rise completion soak time, 1 is stored in this buffer memory area, which is within temperature rise completion range (1).



Set the temperature rise completion range and temperature rise completion soak time in the following buffer memory areas.

- Temperature rise completion range setting (Un\G167) (Page 380, Appendix 2 (41))
- Temperature rise completion soak time setting (Un\G168) (FPage 381, Appendix 2 (42))


# (7) CH□ Transistor output flag (Un\G21 to Un\G24) Standard

# CH□ Heating transistor output flag (Un\G21 to Un\G24) Heating-cooling

# CH□ Cooling transistor output flag (Un\G712 to Un\G715) [tealing-cooling


ON/OFF status of transistor output and ON delay output are stored in these flags. In the heating-cooling control, ON/OFF status of transistor output/ON delay output for heating are stored in Un\G21 to Un\G24.

- OFF: 0
- ON: 1



#### (a) Relationship with ON delay output flag

Relationship between Transistor output flag and ON delay output flag is shown in the following.



Transistor output monitor ON delay time setting (Un\G175) enables setting considering delay time (response/scan time delay) of actual transistor output. (Page 382, Appendix 2 (45)) By monitoring the ON delay output flag and external output on the program, disconnection of external output can be judged. For details on the ON delay output function, refer to the following.

Page 174, Section 8.2.14

# (8) CH□ Set value (SV) monitor (Un\G25 to Un\G28) Standard Heating-cooling

Set value (SV) of each time unit set in CH $\square$  Setting change rate limiter time unit setting (Un\G735, Un\G751, Un\G767, Un\G783) is stored in this buffer memory area. (Fig. Page 411, Appendix 2 (89)) The set value (SV) can be monitored in real time.

# (9) Cold junction temperature process value (Un\G29) Common

The measured temperature of cold junction temperature compensation resistor is stored in this buffer memory area.

Values to be stored are within 0 to 55°C.

#### (a) Usable modules


- · L60TCTT4
- L60TCTT4BW

# (10)MAN mode shift completion flag (Un\G30) Standard Heating-cooling

This flag is for checking completion of the mode shift when shifting AUTO (auto) mode to MAN (manual) mode. The following values are stored in this buffer memory area.

- · 0: MAN mode shift uncompleted
- 1: MAN mode shift completed

The following figure shows bits of the buffer memory area that correspond to each channel.



Bit data from b15 to b4 are fixed to 0.

When shift to MAN mode is completed, bits corresponding to appropriate channel become MAN mode shift completed (1).

#### (a) How to shift the mode

Shift the mode in the following buffer memory area.

• CH□ AUTO/MAN mode shift (Un\G50, Un\G82, Un\G114, Un\G146) ([ ] Page 367, Appendix 2 (26))

#### (b) Setting manipulated value (MV) in MAN mode

Set the manipulated value (MV) in the following buffer memory area.

• CH $\square$  MAN output setting (Un\G51, Un\G83, Un\G115, Un\G147) (FPage 368, Appendix 2 (27)) Set the manipulated value (MV) after confirming MAN mode shift completion flag (Un\G30) has become MAN mode shift completed (1).

## (11) Memory of PID constants read/write completion flag (Un\G31) Standard Heating-cool

This flag is for showing whether the settings of the following buffer memory areas are completed or not.

- CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158)([☐FPage 377, Appendix 2 (36))
- CH□ Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159)(□ Page 378, Appendix 2 (37))

#### (a) Correspondence between each bit and flag

The following table lists flags correspond to bits of this buffer memory area.

Bit number	Flag description	Bit number	Flag description
b0	CH1 Read completion flag	b8	CH1 Read failure flag
b1	CH2 Read completion flag	b9	CH2 Read failure flag
b2	CH3 Read completion flag	b10	CH3 Read failure flag
b3	CH4 Read completion flag	b11	CH4 Read failure flag
b4	CH1 Write completion flag	b12	CH1 Write failure flag
b5	CH2 Write completion flag	b13	CH2 Write failure flag
b6	CH3 Write completion flag	b14	CH3 Write failure flag
b7	CH4 Write completion flag	b15	CH4 Write failure flag


# (b) ON/OFF timing for CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) ([☐ Page 377, Appendix 2 (36))

The following figure shows the ON/OFF timing of this flag for CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158). (For CH1)

CH1 Memory's PID constant read instruction (Un\G62)

CH1 Read completion flag (b0 of Un\G31)

CH1 Read failure flag (b8 of Un\G31)



When the data reading from the non-volatile memory is completed normally, CH $\square$  Read completion flag (b0 to b3 of Un\G31) of the corresponding channel turns on.

CH□ Read completion flag (b0 to b3 of Un\G31) turns off when CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G158) is turned off from on.

When the data reading from the non-volatile memory fails, CH $\square$  Read failure flag (b8 to b11 of Un\G31) of the corresponding channel turns on and the L60TC4 operates with PID constants before the data reading. (The LED status remains.)

CHI Read failure flag (b8 to b11 of Un\G31) turns off when the data reading of the corresponding channel is completed normally.

When the data reading fails, try again by turning CH $\square$  Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126, Un\G158) ON  $\rightarrow$  OFF  $\rightarrow$  ON.

# (c) ON/OFF timing for CH□ Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159) (□ Page 378, Appendix 2 (37))


The following figure shows ON/OFF timing of this flag for CH□ Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159). (For CH1)

CH1 Auto tuning status (Xn4)

CH1 Automatic backup setting after auto tuning of PID constants (Un\G63)

CH1 Write completion flag (b4 of Un\G31)

CH1 Write failure flag (b12 of Un\G31)



When the data writing to the non-volatile memory is completed normally, CH Write completion flag (b4 to b7 of Un\G31) turns on.

CH□ Write completion flag (b4 to b7 of Un\G31) turns off when CH□ Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159) is set to Disable (0) from Enable (1).

When the data writing to the non-volatile memory fails, CH $\square$  Write failure flag (b12 to b15 of Un\G31) of the corresponding channel turns on and the L60TC4 operates with PID constants calculated in the previous auto tuning. (The LED status remains.)

CH Write failure flag (b12 to b15 of Un\G31) turns off when the data writing of the corresponding channel is completed normally.

When the data writing fails, perform auto tuning again by turning CH $\square$  Auto tuning instruction (Yn4 to Yn7) ON  $\rightarrow$  OFF  $\rightarrow$  ON. If the data writing fails even after executing auto tuning again, a hardware error can be the reason. Consult a local representative or branch about the problem.

# Point P

- By referring to this flag at the completion of auto tuning, whether the automatic data backup is completed normally or not can be checked.
- After confirming that the following flags are on, set CH□ Automatic backup setting after auto tuning of PID constants (Un\G63, Un\G95, Un\G127, Un\G159) to Disable (0).
  - CH□ Write completion flag (b4 to b7 of Un\G31) (when automatic data backup is completed normally)
  - CH Write failure flag (b12 to b15 of Un\G31) (when automatic data backup fails)

If auto tuning is executed under Enable (1), although PID constants are stored after auto tuning is complete, CH□ Auto tuning status (Xn4 to Xn7) does not turn off.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

# (12)CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128) Common

Select the set value according to temperature sensor, temperature measurement range \*1, output temperature unit (Celsius (°C)/Fahrenheit (°F)/digit) and resolution (1/0.1) which are used with the L60TC4.

- \*1 In the case of input from other analog modules (such as an A/D converter module) also, set these values.
  - Ex. When the L60TCTT4 or L60TCTT4BW is used and the following thermocouple is selected
  - Thermocouple type: R
  - Temperature measurement range: 0 to 1700°C
  - Resolution: 1

Set 1 in CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128).

When using the L60TCTT4 or L60TCTT4BW, refer to Page 346, Appendix 2 (12) (a). When using the L60TCRT4 or L60TCRT4BW, refer to Page 350, Appendix 2 (12) (b).

### (a) Setting range of the L60TCTT4, L60TCTT4BW

The following table lists setting values of CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128) and the corresponding thermocouple types.

The relationship between temperature unit and setting values is as follows.

Setting of CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)	Item				
1 to 99	Thermocouple is used. (No input from	Output temperature unit is Celsius (°C).			
100 to 199	other analog modules (such as an A/D converter module)) (1 to 199)	Output temperature unit is Fahrenheit ( °F ).			
200 to 299	Other analog modules (such as an A/D converter module) are used. (200 to 299)	Unit is digit.			

Thermocouple type	Temperature measurement range	Celsius (°C)/ Fahrenheit (°F)/digit	Resolution	CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)		g when changing t range*1  CH□ Lower limit setting limiter, CH□ Process alarm lower lower limit value, CH□ Process
					alarm upper upper limit value	alarm lower upper limit value
	0 to 1700	°C	1	1	1700	0
R	0 to 3000	°F	1	105	3000	0
	-200.0 to 400.0	°C	0.1	38	4000	-2000
	0.0 to 400.0	°C	0.1	36	4000	0
	0 to 1300	°C	1	2 (Default value)	1300	0
	0 to 500	°C	1	11	500	0
	0.0 to 500.0	°C	0.1	40	5000	0
K	0 to 800	°C	1	12	800	0
	0.0 to 800.0	°C	0.1	41	8000	0
	-200.0 to 1300.0	°C	0.1	49	13000	-2000
	0 to 1000	°F	1	100	1000	0
	0.0 to 1000.0	°F	0.1	130	10000	0
	0 to 2400	°F	1	101	2400	0

					Automatic setting	g when changing
					the inpu	
Thermocouple type	Temperature measurement range	ement   (°C)/ Fahrenheit   Resc		CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)	CH□ Upper limit setting limiter, CH□ Process alarm upper lower limit value, CH□ Process alarm upper upper limit value	CH□ Lower limit setting limiter, CH□ Process alarm lower lower limit value, CH□ Process alarm lower upper limit value
	0.0 to 400.0	°C	0.1	37	4000	0
	0 to 500	°C	1	13	500	0
	0.0 to 500.0	°C	0.1	42	5000	0
	0 to 800	°C	1	14	800	0
	0.0 to 800.0	°C	0.1	43	8000	0
J	-200.0 to 1000.0	°C	0.1	50	10000	-2000
-	0 to 1200	°C	1	3	1200	0
	0 to 1000	°F	1	102	1000	0
	0.0 to 1000.0	°F	0.1	131	10000	0
	0 to 1600	°F	1	103	1600	0
	0 to 2100	°F	1	104	2100	0
	-200 to 400	°C	1	4	400	-200
	-200 to 200	°C	1	21	200	-200
	-200.0 to 400.0	°C	0.1	39	4000	-2000
	0 to 200	°C	1	19	200	0
Т	0 to 400	°C	1	20	400	0
	0.0 to 400.0	°C	0.1	45	4000	0
	-300 to 400	°F	1	110	400	-300
	0 to 700	°F	1	109	700	0
	0.0 to 700.0	°F	0.1	132	7000	0
S	0 to 1700	°C	1	15	1700	0
3	0 to 3000	°F	1	106	3000	0
	0 to 1800	°C	1	16	1800	0
В	0 to 3000	°F	1	107	3000	0
	0 to 400	°C	1	17	400	0
	0.0 to 700.0	°C	0.1	44	7000	0
E	0 to 1000	°C	1	18	1000	0
	-200.0 to 1000.0	°C	0.1	51	10000	-2000
	0 to 1800	°F	1	108	1800	0
	0 to 1300	°C	1	22	1300	0
N	0.0 to 1000.0	°C	0.1	52	10000	0
	0 to 2300	°F	1	111	2300	0

Thermocouple type	Temperature measurement range	Celsius (°C)/ Fahrenheit (°F)/digit	Resolution	CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)	Automatic setting the inputon the input the	when changing t range*1  CH□ Lower limit setting limiter, CH□ Process alarm lower lower limit value, CH□ Process alarm lower upper limit value
	0 to 400	°C	1	25	400	0
U	0.0 to 600.0	°C	0.1	46	6000	0
J	-300 to 400	°F	1	115	400	-300
	0 to 700	°F	1	114	700	0
	0 to 400	°C	1	27	400	0
	0.0 to 400.0	°C	0.1	47	4000	0
	0 to 900	°C	1	28	900	0
L	0.0 to 900.0	°C	0.1	48	9000	0
	0 to 800	°F	1	116	800	0
	0 to 1600	°F	1	117	1600	0
PLII	0 to 1200	°C	1	23	1200	0
FLII	0 to 2300	°F	1	112	2300	0
MED - MACCO -	0 to 2300	°C	1	24	2300	0
W5Re/W26Re	0 to 3000	°F	1	113	3000	0
Input from other analog modules (0 to 4000)*2	0 to 4000	digit	1	201	4000	0
Input from other analog modules (0 to 12000)*2	0 to 12000	digit	1	202	12000	0
Input from other analog modules (0 to 16000)*2	0 to 16000	digit	1	203	16000	0
Input from other analog modules (0 to 20000)*2	0 to 20000	digit	1	204	20000	0
Input from other analog modules (0 to 32000)*2	0 to 32000	digit	1	205	32000	0

When the input range is changed, the set values in some buffer memory areas are initialized automatically and return to the default value (0).

<sup>(</sup>Fig. Page 351, Appendix 2 (12) (d))
Same as the L60TCRT4, L60TCRT4BW



For the following mode and channel, CH $\square$  Input range (Un\G32, Un\G64, Un\G96, Un\G128) cannot be set to 201 to 205. If these values are set, a write data error (error code:  $\square\square\square4_H$ ) occurs.

	Mode	Corresponding channel		
Temperature input mode		CH1 to CH4		
Tomporature control made	Heating-cooling control (normal mode)	CH3, CH4		
Temperature control mode	Mix control (normal mode)	CH2		

#### (b) Setting range of the L60TCRT4, L60TCRT4BW

The following table lists setting values of CH $\square$  Input range (Un\G32, Un\G64, Un\G96, Un\G128) and the corresponding platinum resistance thermometer types.

					the inpu	ng when changing ut range <sup>*1</sup>	
Platinum resistance thermometer type	Temperature measurement range	Celsius (°C)/ Fahrenheit (°F)/digit	Resolution	CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)	CH□ Upper limit setting limiter, CH□ Process alarm upper lower limit value, CH□ Process alarm upper upper limit value	CH□ Lower limit setting limiter, CH□ Process alarm lower lower limit value, CH□ Process alarm lower upper limit value	
	-200.0 to 600.0	°C	0.1	7 (Default value)	6000	-2000	
	-200.0 to 200.0	°C	0.1	8	2000	-2000	
Pt100	-200.0 to 850.0	°C	0.1	54	8500	-2000	
	-300 to 1100	°F	1	141	1100	-300	
	-300.0 to 300.0	°F	0.1	143	3000	-3000	
	-200.0 to 500.0	°C	0.1	5	5000	-2000	
	-200.0 to 200.0	°C	0.1	6	2000	-2000	
JPt100	-200.0 to 640.0	°C	0.1	53	6400	-2000	
	-300 to 900	°F	1	140	900	-300	
	-300.0 to 300.0	°F	0.1	142	3000	-3000	
Input from other analog modules (0 to 4000)*2	0 to 4000	digit	1	201	4000	0	
Input from other analog modules (0 to 12000)*2	0 to 12000	digit	1	202	12000	0	
Input from other analog modules (0 to 16000)*2	0 to 16000	digit	1	203	16000	0	
Input from other analog modules (0 to 20000)*2	0 to 20000	digit	1	204	20000	0	
Input from other analog modules (0 to 32000)*2	0 to 32000	digit	1	205	32000	0	

<sup>\*1</sup> When the input range is changed, the set values in some buffer memory areas are initialized automatically and return to the default value (0).

<sup>(</sup> Page 351, Appendix 2 (12) (d))

<sup>\*2</sup> Same as the L60TCTT4, L60TCTT4BW



For the following mode and channel, CH $\square$  Input range (Un\G32, Un\G64, Un\G96, Un\G128) cannot be set to 201 to 205. If these values are set, a write data error (error code:  $\square\square\square4_H$ ) occurs.

	Mode	Corresponding channel		
Temperature input mode		CH1 to CH4		
Temperature control mode	Heating-cooling control (normal mode)	CH3, CH4		
remperature control mode	Mix control (normal mode)	CH2		

#### (c) Resolution

The resolution is applied to the stored values and the set values of particular buffer memory areas as described in the following table.

Resolution	Stored value	Set value
1	Value in 1°C ( °F or digit) unit is stored.	Set a value in 1°C ( °F or digit) unit.
0.1	Value in 0.1°C ( °F) unit (tenfold value) is stored.	Set a value in 0.1°C ( °F) unit (tenfold value).

For applicable buffer memory areas, refer to the following.

Page 334, Appendix 2 (2)

# (d) When "Auto-setting at Input Range Change" is set to "1: Enable" on Switch Setting (Page 108, Section 7.2)

When the input range is changed, the following buffer memory areas are set automatically according to selected temperature sensor. Set the buffer memory areas again if necessary.

Buffer memory area name		Buffer mem	Reference			
Bullet memory area name	CH1	CH2	СНЗ	CH4	Kelelelice	
CH□ Upper limit setting limiter	Un\G55	Un\G87	Un\G119	Un\G151	Page 372, Appendix 2 (31)	
CH□ Lower limit setting limiter	Un\G56	Un\G88	Un\G120	Un\G152	rage 372, Appendix 2 (31)	
CH□ Process alarm lower lower limit value	Un\G197	Un\G213	Un\G229	Un\G245		
CH□ Process alarm lower upper limit value	Un\G198	Un\G214	Un\G230	Un\G246	Dago 200 Appondix 2 (54)	
CH□ Process alarm upper lower limit value	Un\G199	Un\G215	Un\G231	Un\G247	Page 388, Appendix 2 (54)	
CH□ Process alarm upper upper limit value	Un\G200	Un\G216	Un\G232	Un\G248		

At the same time, the following buffer memory areas related to the input range is initialized to the default value (0) automatically. Set the buffer memory areas again if necessary.

Duffer memory even neme		Buffer mem	Reference		
Buffer memory area name	CH1	CH2	CH3	CH4	Reference
CH□ Set value (SV) setting	Un\G34	Un\G66	Un\G98	Un\G130	Page 354, Appendix 2 (14)
CH□ Alert set value 1	Un\G38	Un\G70	Un\G102	Un\G134	
CH□ Alert set value 2	Un\G39	Un\G71	Un\G103	Un\G135	Page 358, Appendix 2 (18)
CH□ Alert set value 3	Un\G40	Un\G72	Un\G104	Un\G136	Page 336, Appendix 2 (16)
CH□ Alert set value 4	Un\G41	Un\G73	Un\G105	Un\G137	
CH□ AT bias setting	Un\G53	Un\G85	Un\G117	Un\G149	Page 370, Appendix 2 (29)
CH□ Loop disconnection detection dead band	Un\G60	Un\G92	Un\G124	Un\G156	Page 375, Appendix 2 (34)
CH□ 2-point sensor compensation offset value (measured value)	Un\G544	Un\G576	Un\G608	Un\G640	Page 394, Appendix 2 (63)

Buffer memory area name		Buffer mem	Reference		
buller memory area name	CH1	CH2	CH3	CH4	Reference
CH□ 2-point sensor compensation offset value (compensation value)	Un\G545	Un\G577	Un\G609	Un\G641	Page 394, Appendix 2 (64)
CH□ 2-point sensor compensation gain value (measured value)	Un\G546	Un\G578	Un\G610	Un\G642	Page 395, Appendix 2 (65)
CH□ 2-point sensor compensation gain value (compensation value)	Un\G547	Un\G579	Un\G611	Un\G643	Page 395, Appendix 2 (66)
CH□ Simultaneous temperature rise gradient data	Un\G731	Un\G747	Un\G763	Un\G779	Page 408, Appendix 2 (85)
CH□ Simultaneous temperature rise dead time	Un\G732	Un\G748	Un\G764	Un\G780	Page 408, Appendix 2 (86)

These 19 buffer memory areas are set automatically when the input range is changed and Setting change instruction (YnB) is turned OFF  $\rightarrow$  ON  $\rightarrow$  OFF during setting mode (Setting/operation mode status (Xn1): OFF).

# (e) When "Auto-setting at Input Range Change" is set to "0: Disable" on Switch Setting (Page 108, Section 7.2)

Set values in the buffer memory ( $\Box$  Page 351, Appendix 2 (12) (d)) can be out of the setting range. (When the setting range changes according to the change of the input range, the set value before the change can turn out of the range.) In this case, a write data error (error code:  $\Box\Box\Box\Box 4_H$ ) occurs in the buffer memory area where the value turns out of the setting range. Change the input range after setting each buffer memory area with values within the setting range after the input range change.

#### (f) Enablement of set contents

Enable the set contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (g) Precautions

Soon after the input range is changed, input temperature may be unstable. Do not start the control until Temperature conversion completion flag (Un\G786) becomes First temperature conversion completed (1<sub>H</sub>).

# Appendix 2 Details of the Buffer Memory

#### (13)CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129) Standard Heating-cooling

Set the mode activated at PID control stop.

#### (a) Setting range and action of L60TC4

The following table lists the relationship.

O: Executed ×: Not executed

Mada which can be	Cat walks of CUID Stars made actions	Action				
Mode which can be set	Set value of CH□ Stop mode setting (Un\G33, Un\G65, Un\G97, Un\G129)	PID control	Temperature judgment*1	Alert judgment		
Stop	0	×	×	×		
Monitor	1	×	0	×		
Alert	2	×	0	0		

<sup>\*1</sup> Means that the L60TC4 checks whether the input temperature is in the temperature measurement range set in the input range.

However, action of the L60TC4 differs depending on the following settings.

- CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) ([] Page 376, Appendix 2 (35))
- Setting/operation mode instruction (Yn1) ( Page 330, Appendix 1.2 (1))
- PID continuation flag (Un\G169) (Page 381, Appendix 2 (43))
- CH□ PID control forced stop instruction (YnC to YnF) ( Page 333, Appendix 1.2 (7))
- "Output Setting at CPU Stop Error" (Switch Setting) (Page 108, Section 7.2)

For details, refer to the following.

- PID control: Page 150, Section 8.2.7 (7)
- Temperature judgment: Page 336, Appendix 2 (3)
- Alert judgment: Page 166, Section 8.2.11 (5)

#### (b) Default value

The default values are set to Monitor (1) in all channels.



Default values are set to Monitor (1).

Therefore, channels which temperature sensors are not connected to detect sensor input disconnection and the ALM LED blinks.

When CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1), control of the corresponding channel is not performed. For channels which temperature sensors are not connected to, CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) must be set to Unused (1).

#### (14)CH□ Set value (SV) setting (Un\G34, Un\G66, Un\G98, Un\G130) Standard Healing-cooling





Set the target temperature value of PID control.

#### (a) Setting range

The setting range is identical to the temperature measurement range of the set input range. (FP Page 345, Appendix 2 (12))

When a value which is out of the setting range is set, a write data error (error code:  $\Box\Box\Box\Box\Box\Box$ <sub>H</sub>) and the following situations occur.

- Error occurrence flag (Xn2) turns on.
- The error code is stored in Error code (Un\G0).

#### (b) Setting unit

The value to be set differs depending on the stored value in CH Decimal point position (Un\G1 to Un\G4). (Frage 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C (°F or digit) unit.
- One decimal place (1): Set a value in 0.1°C (°F) unit (tenfold value).

#### (c) Default value

The default values are set to 0 in all channels.

(15)CH□ Proportional band (P) setting (Un\G35, Un\G67, Un\G99, Un\G131) Standard CH□ Heating proportional band (Ph) setting (Un\G35, Un\G67, Un\G99,



Un\G131) Heating-cooling

CH□ Cooling proportional band (Pc) setting (Un\G720, Un\G736, Un\G752,

Un\G768) Heating-cooling

Set proportional band (P)/heating proportional band (Ph)/cooling proportional band (Pc) to perform PID control. (In the heating-cooling control, set heating proportional band (Ph) to Un\G35, Un\G67, Un\G99, Un\G131.)

#### (a) Setting range

Set the value within the following ranges for the full scale of the set input range. (FF Page 345, Appendix 2 (12))

- Proportional band (P) setting: 0 to 10000 (0.0% to 1000.0%)
- Heating proportional band (Ph) setting: 0 to 10000 (0.0% to 1000.0%)
- Cooling proportional band (Pc) setting: 1 to 10000 (0.1% to 1000.0%)
- Ex. When the value of the buffer memory is set as follows
  - CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (temperature measurement range: -200.0 to 400.0°C)
  - CH□ Proportional band (P) setting (Un\G35, Un\G67, Un\G99, Un\G131): 100 (10.0%)

(Full scale) × (Proportional band (P) setting) = (400.0°C - (-200.0)) × 0.1 = 60°C Set the proportional band (P) to 60°C.

#### (b) Two-position control

Set the proportional band (P)/heating proportional band (Ph) to 0. (The auto tuning cannot be performed.) For details on Two-position control, refer to the following.

Page 129, Section 8.2.3

#### (c) Default value

The default values are set to 30 (3.0%) in all channels.



If the proportional band (P)/heating proportional band (Ph) is set to 0 (0.0%), the auto tuning cannot be performed. To perform the auto tuning, set proportional band (P)/heating proportional band (Ph) to other than 0. For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7




The proportional band (P) is the variation width of deviation (E) necessary for manipulated value (MV) to vary 0% to 100%. The following formula shows the relationship between deviation (E) and manipulated value (MV) in proportional action.

Kp is proportional gain. The following formula shows proportional band (P) in this case.

$$P = \frac{1}{Kp} \cdot 100$$

When the value of the proportional band (P) is increased, the proportional gain (Kp) decreases. Therefore, the manipulated value (MV) for variation of the deviation (E) becomes small.

When the value of proportional band (P) is decreased, the proportional gain (Kp) increases. Therefore, the manipulated value (MV) for variation of the deviation (E) becomes large. The following figure shows the proportional band (P) in reverse action.



#### (16)CH□ Integral time (I) setting (Un\G36, Un\G68, Un\G100, Un\G132) Common

Set integral time (I) to perform PID control.

#### (a) Setting range

The setting range is 0 to 3600 (0 to 3600s).

#### (b) In the P control or PD control

Set this setting to 0.

For details on control methods, refer to the following.

Page 129, Section 8.2.3

#### (c) Default value

The default values are set to 240 (240s) in all channels.

## (17)CH□ Derivative time (D) setting (Un\G37, Un\G69, Un\G101, Un\G133) common



Set derivative time (D) to perform PID control.

#### (a) Setting range

The setting range is 0 to 3600 (0 to 3600s).

#### (b) In the P control or PI control

Set this setting to 0.

For details on control methods, refer to the following.

Page 129, Section 8.2.3

#### (c) Default value

The default values are set to 60 (60s) in all channels.

(18)CH□ Alert set value 1 (Un\G38, Un\G70, Un\G102, Un\G134) Standard Hesting-cooling

CH□ Alert set value 2 (Un\G39, Un\G71, Un\G103, Un\G135) Standard Healing-cooling

CH□ Alert set value 3 (Un\G40, Un\G72, Un\G104, Un\G136) Standard Heating-cooling

CH□ Alert set value 4 (Un\G41, Un\G73, Un\G105, Un\G137) Standard Heating-cooling

Set temperature values where CH $\square$  Alert 1 (Un\G5 to Un\G8 of b8) to CH $\square$  Alert 4 (Un\G5 to Un\G8 of b11) turn on according to selected alert mode of alert 1 to 4.

For CH□ Alert definition (Un\G5 to Un\G8), refer to the following.

Page 336, Appendix 2 (3)

For details on the alert function, refer to the following.

Page 157, Section 8.2.11

#### (a) Alert mode

Set the alert mode of alert 1 to 4 in the following buffer memory areas. Alert mode of alert 1 to 4 respectively correspond to alert set value 1 to 4.

#### (b) Setting range

Buffer memory area	Buffer memory address				Reference
name	CH1	CH2	СНЗ	CH4	Reference
CH□ Alert 1 mode setting	Un\G192	Un\G208	Un\G224	Un\G240	Page 386, Appendix 2 (52)
CH□ Alert 2 mode setting	Un\G193	Un\G209	Un\G225	Un\G241	
CH□ Alert 3 mode setting	Un\G194	Un\G210	Un\G226	Un\G242	
CH□ Alert 4 mode setting	Un\G195	Un\G211	Un\G227	Un\G243	

The setting range differs depending on the setting of the following buffer memory area. (each full scale differs)

• CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128) ( Page 345, Appendix 2 (12))

Also, the setting range differs depending on alert mode to be set. (FP Page 358, Appendix 2 (18) (a))

Alert mode	Setting range of alert set value	Remarks
No alert	_	_
Upper limit input alert, lower limit input alert	Temperature measurement range of the input range	Same as with standby
Upper limit deviation alert, lower limit deviation alert, upper limit deviation alert (using the set value (SV)), lower limit deviation alert (using the set value (SV))	-(full scale) to +(full scale)	Same as with standby and standby (second time)
Upper lower limit deviation alert, within-range alert, upper lower limit deviation alert (using the set value (SV)), within-range alert (using the set value (SV))	0 to +(full scale)	Same as with standby and standby (second time)

When a value which is out of the setting range is set, a write data error (error code:  $\Box\Box\Box 4_H$ ) and the following situations occur.

- Error occurrence flag (Xn2) turns on.
- The error code is stored in Error code (Un\G0).

### (c) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (□ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C (°F or digit) unit.
- One decimal place (1): Set a value in 0.1°C ( °F) unit (tenfold value).

### (d) Write data error

In the following case, a write data error (error code:  $\Box\Box\Box\Box A_H$ ) occurs as well as when the setting is out of the setting value. Error occurrence flag (Xn2) turns on and the error code is stored in Error code (Un\G0).

• When the set value is other than 0 when No alert (0) is set in the alert mode

### (e) Default value

The default values are set to 0 in all channels.

(19)CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138) standard
CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139) Standard CH□ Heating upper limit output limiter (Un\G42, Un\G74, Un\G106,
Un\G138) Hasting-cooling CH□ Cooling upper limit output limiter (Un\G721, Un\G737, Un\G753, Un\G769



In the standard control, set upper limit value/lower limit value for actual output of manipulated value (MV) calculated by the PID operation to an external device. In the heating-cooling control, set upper limit value of heating/cooling for actual output of manipulated value for heating (MVh)/manipulated value for cooling (MVc) calculated by the PID operation to an external device. Additionally, Un\G42, Un\G74, Un\G106, Un\G138 are used for heating in the heating-cooling control. During the auto tuning, setting of Heating upper limit output limiter and Cooling upper limit output limiter are disabled.

### (a) Setting range

The following table lists setting range of each buffer memory.

Buffer memory	Setting range	Remarks
CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)		Set the values to lower limit output limiter value < upper limit output limiter value.
CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139)	-50 to 1050 (-5.0% to 105.0%)	When lower limit output limiter value ≥ upper limit output limiter value, write data error (error code:  □□□5 <sub>H</sub> ) occurs. In addition, if the setting is out of the setting value, a write data error (error code:  □□□4 <sub>H</sub> ) occurs. When the error occurs, the following situations occur.  • Error occurrence flag (Xn2) turns on.  • The error code is stored in Error code (Un\G0).
CH□ Heating upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)		If the setting is out of the setting value, a write data error (error code: □□□4 <sub>H</sub> ) occurs. When the error
CH□ Cooling upper limit output limiter (Un\G721, Un\G737, Un\G753, Un\G769)	0 to 1050 (0.0% to 105.0%)	occurs, the following situations occur.  • Error occurrence flag (Xn2) turns on.  • The error code is stored in Error code (Un\G0).



- In the standard control, CH□ Cooling upper limit output limiter (Un\G721, Un\G737, Un\G753, Un\G769) is invalid even it is set.
- In the heating-cooling control, lower limit value is not used. When CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139) is set to other than 0, a write data error (error code: □□□2<sub>H</sub>) occurs.

# (b) Two-position control (Page 129, Section 8.2.3 (1))

The following table lists Enable/Disable of the setting.

Buffer memory	Enable/Disable of the setting in the two- position control		
CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)	Disable		
CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139)	Disable		
CH□ Heating upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)	Enable		
CH□ Cooling upper limit output limiter (Un\G721, Un\G737, Un\G753, Un\G769)	Ellable		

### (c) Manual control (FP Page 139, Section 8.2.5)

The following table lists Enable/Disable of the setting.

Buffer memory	Enable/Disable of the setting in the manual control	Remarks			
CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)	Enable	When an output exceeds the upper limit output limiter value, the manipulated value (MV) of the manual control is fixed (clipped) to the upper limit output limiter value that is set. When an output			
CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139)	LITABLE	falls below the lower limit output limiter value, the manipulated value (MV) of the manual control is fixed (clipped) to the lower limit output limiter value that is set.			
CH□ Heating upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)	Disable				
CH□ Cooling upper limit output limiter (Un\G721, Un\G737, Un\G753, Un\G769)	Disable				

### (d) Default value

The following table lists the default value of each buffer memory area.

Buffer memory	Default value
CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)	1000 (100.0%)
CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139)	0 (0.0%)
CH□ Heating upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)	1000 (100.0%)
CH□ Cooling upper limit output limiter (Un\G721, Un\G737, Un\G753, Un\G769)	1000 (100.0%)

### (20)CH□ Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140)



Set the limit of an output variation per 1s to regulate a rapid change of the manipulated value (MV).


### (a) Setting range

The setting range is 0 or 1 to 1000 (0.1%/s to 100.0%/s). When 0 is set, an output variation is not regulated.

Ex. When the value of the buffer memory is set as follows

• CH□ Output variation limiter setting (Un\G44, Un\G76, Un\G108, Un\G140): 10(1.0%/s)

If the manipulated value (MV) rapidly changes by 50%, the variation is regulated to 1%/s. Therefore, it takes 50s until the output actually changes by 50%.



(b) Two-position control (Page 129, Section 8.2.3 (1))

The setting is invalid.

(c) Manual control (Page 139, Section 8.2.5)

The setting is enabled.

### (d) Default value

The default values are set to 0 in all channels.

### (21)CH□ Sensor correction value setting (Un\G45, Un\G77, Un\G109, Un\G141)



Set the correction value when measured temperature and actual temperature are different.

For details on the sensor compensation function, refer to the following.

Page 223, Section 8.3.2

### (a) Setting range

Set the value within the range -5000 to 5000 (-50.00% to 50.00%) of the full scale of the set input range. (Fig. Page 345, Appendix 2 (12))

### (b) Enablement of setting contents

When 1-point sensor compensation (standard) ( $0_H$ ) is set in Sensor compensation function selection (Un\G785), the setting contents is enabled. ( $\Box$  Page 413, Appendix 2 (91))


### (c) Default value

The default values are set to 0 (0.00%) in all channels.

### (22)CH□ Adjustment sensitivity (dead band) setting (Un\G46, Un\G78, Un\G110,



To prevent a chattering in the two-position control, set the adjustment sensitivity (dead band) for the set value (SV).



For details on the two-position control, refer to the following.

Page 129, Section 8.2.3

### (a) Setting range

Set the value within the range 1 to 100 (0.1% to 10.0%) of the full scale of the set input range. ( $\Box$ Page 345, Appendix 2 (12))

### Ex. When the value of the buffer memory is set as follows

- CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (temperature measurement range: -200.0 to 400.0°C)
- CH
   Adjustment sensitivity (dead band) setting (Un\G46, Un\G78, Un\G110, Un\G142): 10 (1.0%)
   (Full scale) × (Adjustment sensitivity (dead band) setting) = (400.0°C (-200.0)) × 0.01 = 6.0°C
   The dead band is the set value (SV) ±6.0°C.

### (b) Default value

The default values are set to 5 (0.5%) in all channels.


# (23)CH□ Control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143) Standard CH□ Heating control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143)



CH□ Cooling control output cycle setting (Un\G722, Un\G738, Un\G754,

# Un\G770) Heating-cooling

Set the pulse cycle (ON/OFF cycle) of the transistor output. In the heating-cooling control, the output cycle of the heating control and cooling control can be set individually. Additionally, Un\G47, Un\G79, Un\G111, Un\G143 are used for heating in the heating-cooling control.




The ON time of the control output cycle is determined by multiplying the control output cycle by the manipulated value (MV)<sup>\*1</sup> (%) calculated by PID operation. If the manipulated value (MV)<sup>\*1</sup> is constant, a pulse of the same cycle is output repeatedly.

- \*1 For the heating control output cycle, the manipulated value for heating (MVh) is used. For the cooling control output cycle, manipulated value for cooling (MVc) is used.
  - Ex. When 700 (70%) is stored in CH□ Manipulated value (MV) (Un\G13 to Un\G16) and the value of the buffer memory is set as follows
    - CH□ Control output cycle setting (Un\G47, Un\G79, Un\G111, Un\G143): 100 (100s) 100s × 0.7 (70%) = 70s

The ON time is 70s.

The transistor output turns on for 70s and off for 30s per 100s.



### (a) Setting range

- When the control output cycle unit selection setting on Switch Setting is set to the cycle of 1s: 1 to 100 (1s to 100s)
- When the control output cycle unit selection setting on Switch Setting is set to the cycle of 0.1s: 5 to 1000 (0.5s to 100.0s)

For details on the control output cycle unit selection setting function, refer to the following.

Page 140, Section 8.2.6


### (b) Default value

- When the control output cycle unit selection setting on Switch Setting is set to the cycle of 1s: 30 (30s)
- When the control output cycle unit selection setting on Switch Setting is set to the cycle of 0.1s: 300 (30.0s)


# (24)CH□ Primary delay digital filter setting (Un\G48, Un\G80, Un\G112, Un\G144)



The temperature process values (PV) are smoothed and sudden changes are absorbed by using the primary delay digital filter.



The time for the temperature process value (PV) to change by 63.3% can be set by the primary delay digital filter setting (filter setting time).



### (a) Setting range

The setting range is 0 or 1 to 100 (1s to 100s). When 0 is set, the primary delay digital filter processing is not performed.

### (b) Default value

The default values are set to 0 in all channels.

# (25)CH□ Control response parameter (Un\G49, Un\G81, Un\G113, Un\G145)




In the simple two-degree-of-freedom PID control, select the response speed to the change of the set value (SV) from the following three levels: Slow, Normal, and Fast.

For details on the simple two-degree-of-freedom, refer to the following.

Page 153, Section 8.2.8

### (a) Setting range

Set value	Setting contents	Description
0	Slow	Set Slow when reducing an overshoot and undershoot to the change of the set value (SV). However, the settling time is the longest of the three settlings.
1	Normal	Normal has features between Slow and Fast.
2	Fast	Set Fast when speeding up the response to the change of the set value (SV). However, an overshoot and undershoot is the largest of the three settings.



### (b) Default value

The default values are set to Slow (0) in all channels.

# (26)CH□ AUTO/MAN mode shift (Un\G50, Un\G82, Un\G114, Un\G146) Standard



Select whether to calculate the manipulated value (MV) by PID operation or to set it manually by the user.


### (a) Setting range

Set value	Setting contents	Description
0	AUTO	Activates the AUTO mode. The manipulated value (MV) calculated by PID operation is used to calculate the ON time of the control cycle.
1	MAN	Activates the MAN mode. The manipulated value (MV) written in CH MAN output setting (Un\G51, Un\G83, Un\G115, Un\G147) is used to calculate the ON time of the control output cycle.

### (b) When AUTO mode is shifted to MAN mode

The following operation is performed.

- The manipulated value (MV) calculated by PID operation is transferred to CH□ MAN output setting (Un\G51, Un\G83, Un\G115, Un\G147). (For preventing a rapid change of the manipulated value (MV))
- When the shift to the MAN mode is completed, bits of the corresponding channel of MAN mode shift completion flag (Un\G30) are set to MAN mode shift completed (1).



----> Executed by the L60TC4



Set the manipulated value (MV) in MAN mode after confirming completion of the mode shift.

### (c) When performing auto tuning

Set to AUTO (0). If MAN (1) is set, the auto tuning is not performed.

### (d) Default value

The default values are set to AUTO (0) in all channels.

# (27)CH MAN output setting (Un\G51, Un\G83, Un\G115, Un\G147) Standard Heating-cooling

This buffer memory area is used for setting the manipulated value (MV) in the MAN mode.

### (a) How to shift the mode

Shift the mode by the following buffer memory area.

• CH□ AUTO/MAN mode shift (Un\G50, Un\G82, Un\G114, Un\G146) ([☐ Page 367, Appendix 2 (26))

### (b) Setting range

The setting range is different between the standard control and the heating-cooling control. (FFP Page 126, Section 8.2.1)

- In standard control: -50 to 1050 (-5.0 to 105.0%)
- In heating-cooling control: -1050 to 1050 (-105.0 to 105.0%)

### (c) Enablement of setting contents

Make sure the corresponding bits of MAN mode shift completion flag (Un\G30) has been set to 1 (ON) and write a value in the MAN output setting.

A value that is written when MAN mode shift completion flag is OFF will be replaced with the manipulated value (MV) calculated by PID operation by the system.

### (d) Default value

The default values are set to 0 (0.0%) in all channels.

### (28)CH□ Setting change rate limiter (Un\G52, Un\G84, Un\G116, Un\G148)




CH□ Setting change rate limiter (temperature rise) (Un\G52, Un\G84, Un\G116,

Un\G148) Standard Heating-cooling

CH□ Setting change rate limiter (temperature drop) (Un\G564, Un\G596,

Un\G628, Un\G660) Standard Heating-cooling

Set the change rate of the set value (SV) per a set time unit when the set value (SV) is changed. This setting can regulate a rapid change of the manipulated value (MV). Set a time unit in CH $\square$  Setting change rate limiter time unit setting (Un\G735, Un\G751, Un\G767, Un\G763). (FFPage 411, Appendix 2 (89))



### (a) Batch/individual setting of temperature rise and temperature drop

Setting change rate limiter for the temperature rise and the temperature drop can be set in a batch or individually. Select it on Switch Setting.

For details on the setting method, refer to the following.

Page 108, Section 7.2

When setting change rate limiter is set individually, Un\G52, Un\G84, Un\G116, Un\G148 is for the temperature rise. The following table lists the buffer memory areas to be referred to.

Batch/Individual	Buffor momory area name	Buffer memory address			
Batch/Individual Buffer memory area name		CH1	CH2	СНЗ	CH4
Batch	CH□ Setting change rate limiter	Un\G52	Un\G84	Un\G116	Un\G148
	CH□ Setting change rate limiter (temperature rise)	Un\G52	Un\G84	Un\G116	Un\G148
Individual	CH□ Setting change rate limiter (temperature drop)	Un\G564	Un\G596	Un\G628	Un\G660

For details on the function, refer to the following.

Page 155, Section 8.2.10

### (b) Setting range

Set 0 or the value within the range of 1 to 1000 (0.1% to 100.0%) toward the full scale of the set input range. When 0 is set, the setting is disabled.

### (c) Default value

The default values are set to 0 in all channels.

# (29)CH AT bias setting (Un\G53, Un\G85, Un\G117, Un\G149) Standard Resting cooling

The point set as the set value (SV) in the auto tuning can be rearranged by using this buffer memory area.

The auto tuning function determines each PID constant by performing the two-position control toward the set value (SV) and making a temperature process value (PV) hunting.


Set CH□ AT bias setting (Un\G53, Un\G85, Un\G117, Un\G149) when an overshoot caused by the hunting is improper.

The auto tuning is performed with having the AT point (the point rearranged by the setting) as its center. When the auto tuning is completed, the L60TC4 performs a control toward the set value (SV) to which the value set in the AT bias is added, not the set value (SV) itself.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

Ex. When AT bias is set to minus value (reverse action)



### (a) Setting range

The setting range is from -(full scale) to +(full scale). The setting range depends on the input range setting. (Fig. 245, Appendix 2 (12))

- Ex. When the value of the buffer memory is set as follows
  - CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (temperature measurement range -200.0 to 400.0°C, resolution: 0.1)

The setting range is -6000 to 6000.

### (b) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (☐ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C ( °F or digit) unit.
- One decimal place (1): Set a value in 0.1°C (°F) unit (tenfold value).

### (c) Default value

The default values are set to 0 in all channels.

### (d) Precautions

For CH $\square$  AT bias setting (Un\G53, Un\G85, Un\G117, Un\G149), set the range where PID operation fluctuates slightly and the control result get no effect.

Depending on the controlled object, accurate PID constants may not be obtained.

# (30)CH□ Forward/reverse action setting (Un\G54, Un\G86, Un\G118, Un\G150)



Select whether to use channels in the forward action or reverse action.

Select the forward action for the cooling control. Select the reverse action for the heating control.

For details on the forward action/reverse action selection function, refer to the following.

Page 203, Section 8.2.18

### (a) Setting range

- 0: Forward action
- 1: Reverse action

### (b) Default value

The default values are set to Reverse action (1) in all channels.

### (31)CH□ Upper limit setting limiter (Un\G55, Un\G87, Un\G119, Un\G151)

Standard Heating-cooling

### CH□ Lower limit setting limiter (Un\G56, Un\G88, Un\G120, Un\G152)

Standard Heating-cooling

Upper/lower limit value of the set value (SV) can be set.


### (a) Setting range

The setting range is identical to the temperature measurement range of the set input range. (Fig. Page 345, Appendix 2 (12))

The setting should meet the following conditions.

- CH□ Lower limit setting limiter (Un\G56, Un\G88, Un\G120, Un\G152)
  - < CH□ Upper limit setting limiter (Un\G55, Un\G87, Un\G119, Un\G151)

If the above conditions are not met, a write data error (error code:  $\Box\Box\Box\Box$ <sub>H</sub>) occurs.



### (b) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (□ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C (°F or digit) unit.
- One decimal place (1): Set a value in 0.1°C ( °F) unit (tenfold value).

### (c) Default value

A default value differs depending on modules to be used.

Buffer memory	Default value			
Buller memory	L60TCTT4/L60TCTT4BW	L60TCRT4/L60TCRT4BW		
CH□ Upper limit setting limiter (Un\G55, Un\G87, Un\G119, Un\G151)	1300	6000		
CH□ Lower limit setting limiter (Un\G56, Un\G88, Un\G120, Un\G152)	0	-2000		

# (32)CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154)



Set the set value in heater disconnection detection and off-time current error detection in percentage of the reference heater current value.

For details on the heater disconnection detection function, refer to the following.

Page 215, Section 8.2.24

For details on the output off-time current error detection function, refer to the following.

Page 220, Section 8.2.25

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

The setting range is 0 to 100 (%).

- Ex. To generate Heater disconnection alert with the following conditions
  - CT□ Reference heater current value (Un\G280 to Un\G287): 100 (10.0A)
  - When CT□ Heater current process value (Un\G256 to Un\G263) is 80 (8.0A) or less, set CH□ Heater disconnection alert setting (Un\G58, Un\G90, Un\G122, Un\G154) to 80 (%).

When 0 is set, heater disconnection detection and off-time current error detection are not performed.

### (c) Default value

The default values are set to 0 (%) in all channels.

### (33)CH□ Loop disconnection detection judgment time (Un\G59, Un\G91, Un\G123,

# Un\G155) Standard

Errors such as disconnection of resistors, malfunction of an external controller, and errors of the control system due to troubles such as disconnection of the sensor can be detected by the loop disconnection detection function.

If temperature does not change by 2°C (°F) or more in the Loop disconnection detection judgment time, a loop disconnection is detected.

For details on the loop disconnection detection function, refer to the following.

Page 204, Section 8.2.19

### (a) Setting range

The setting range is 0 to 7200 (s).

Set a value that exceeds the time in which temperature changes by 2°C (°F).

### (b) When performing auto tuning

For this setting, the twice value of that of CH $\square$  Integral time (I) setting (Un\G36, Un\G68, Un\G100, Un\G132) is automatically set. (FFPage 357, Appendix 2 (16)) However, when this setting is set to 0 (s) at the start of the auto tuning, Loop disconnection detection judgment time is not stored.


### (c) Default value

The default values are set to 480 (s) in all channels.

### (34)CH□ Loop disconnection detection dead band (Un\G60, Un\G92, Un\G124,

# Un\G156) Standard

To prevent an error alarm of Loop disconnection detection, set a non-alert band (temperature band in which the loop disconnection is not detected) where the set value (SV) is at the center.



For details on the loop disconnection detection function, refer to the following.

Page 204, Section 8.2.19

### (a) Setting range

The setting range is identical to the temperature measurement range of the set input range. (Fig. Page 345, Appendix 2 (12))

- Ex. When the value of the buffer memory is set as follows
  - CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 38 (resolution: 0.1)
  - CH□ Loop disconnection detection dead band (Un\G60, Un\G92, Un\G124, Un\G156): 50 (Loop disconnection detection dead band set value) × (resolution) = 50 × 0.1 = 5.0°C

Within the range of the set value (SV) ±5.0°C, Loop disconnection is not detected.

### (b) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (□ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C (°F or digit) unit.
- One decimal place (1): Set a value in 0.1°C ( °F) unit (tenfold value).

### (c) Default value

The default values are set to 0 in all channels.

### (35)CH Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) Standard Healing-cooling



Set this buffer memory area when treating channels that do not control temperature or are not connected with temperature sensors as "Unused". Setting them as unused channels stops detection of an alert. For details on the unused channel setting, refer to the following.

Page 106, Section 6.6

### (a) Setting range

- 0: Use
- 1: Unused

### (b) Default value

The default values are set to Use (0) in all channels.

### (c) ON of Default setting registration instruction (Yn9) (Page 332, Appendix 1.2 (5))

When Default setting registration instruction (Yn9) is turn on from off, CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is reset to Use (0).

Channels that do not control temperature or are not connected to temperature sensors needs to be set as unused channels again after settings of other buffer memory areas and non-volatile memories return to the default values. Set CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) to Unused (1) again.

# (36)CH□ Memory of PID constants read instruction (Un\G62, Un\G94, Un\G126,

# Un\G158) Standard Heating-cooling

PID constants are read from a non-volatile memory and stored in the buffer memory by using this instruction. Setting this buffer memory area to Requested (1) stores the value backed up in the non-volatile memory in the buffer memory.

### (a) buffer memory areas to store set value of non-volatile memory

The following table lists the buffer memory areas whose set value is read.

Buffer memory area name	Buffer memory address				Reference
Bullet memory area hame	CH1	CH2	CH3	CH4	Reference
CH□ Proportional band (P) setting	Un\G35	Un\G67	Un\G99	Un\G131	
CH□ Heating proportional band (Ph) setting	Un\G35	Un\G67	Un\G99	Un\G131	Page 355, Appendix 2 (15)
CH□ Cooling proportional band (Pc) setting	Un\G720	Un\G736	Un\G752	Un\G768	
CH□ Integral time (I) setting	Un\G36	Un\G68	Un\G100	Un\G132	Page 357, Appendix 2 (16)
CH□ Derivative time (D) setting	Un\G37	Un\G69	Un\G101	Un\G133	Page 357, Appendix 2 (17)
CH□ Loop disconnection detection judgment time	Un\G59	Un\G91	Un\G123	Un\G155	Page 374, Appendix 2 (33)

### (b) Setting range

- 0: Not requested
- 1: Requested

### (c) Default value

The default values are set to Not requested (0) in all channels.

### (d) Precautions

When Requested (1) is set, do not perform the following operations. An incorrect value may be stored in the non-volatile memory.

- Change of the set value of the buffer memory read from the non-volatile memory by this instruction (F) Page 378, Appendix 2 (37) (a))
- Memory back up (Page 235, Section 8.3.4)
- Default setting registration ( Page 332, Appendix 1.2 (5))
- Auto tuning (Page 141, Section 8.2.7)

# Point P

- When the initial setting by a programming tool is already configured, PID constants should be backed up to a non-volatile memory after the auto tuning. Turning on this instruction at the next start-up can omits the auto tuning.
- This instruction is enabled in the setting mode or operation mode. (☐ Page 324, Appendix 1.1 (2))
  However, it is disabled when CH□ Auto tuning instruction (Yn4 to Yn7) is ON. (☐ Page 141, Section 8.2.7)

# (37)CH□ Automatic backup setting after auto tuning of PID constants (Un\G63,

# Un\G95, Un\G127, Un\G159) Standard Heating-cooling

The set value to be stored in the buffer memory is automatically backed up to a non-volatile memory by using this function. By reading the set value that is backed up, when the power is turned on from off or the CPU module is released from the reset status, another auto tuning can be omitted.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

### (a) buffer memory areas whose set value is backed up to a non-volatile memory

The following table lists the buffer memory areas whose setting is backed up.

Buffer memory area name	Buffer memory address				Reference
Bullet memory area name	CH1	CH2	CH3	CH4	Reference
CH□ Proportional band (P) setting	Un\G35	Un\G67	Un\G99	Un\G131	
CH□ Heating proportional band (Ph) setting	Un\G35	Un\G67	Un\G99	Un\G131	Page 355, Appendix 2 (15)
CH□ Cooling proportional band (Pc) setting	Un\G720	Un\G736	Un\G752	Un\G768	
CH□ Integral time (I) setting	Un\G36	Un\G68	Un\G100	Un\G132	Page 357, Appendix 2 (16)
CH□ Derivative time (D) setting	Un\G37	Un\G69	Un\G101	Un\G133	Page 357, Appendix 2 (17)
CH□ Loop disconnection detection judgment time	Un\G59	Un\G91	Un\G123	Un\G155	Page 374, Appendix 2 (33)

### (b) Setting range

• 0: Disable

• 1: Enable

### (c) Default value

The default values are set to Disable (0) in all channels.

### (d) Precautions

When Enable (1) is set, do not perform the following operations. An incorrect value may be stored in the non-volatile memory.

- · Changing the set value of the buffer memory
- Memory back up (FP Page 235, Section 8.3.4)
- Default setting registration (FP Page 332, Appendix 1.2 (5))
- · Change to Disable (0) during the auto tuning

# (38) Alert dead band setting (Un\G164) Standard Heating-cooling

This setting is for using the alarm function.

For details on the alert function, refer to the following.

Page 157, Section 8.2.11

### (a) Setting range

Set the value within the range 0 to 100 (0.0% to 10.0%) of the full scale of the set input range. (FFP Page 345, Appendix 2 (12))

- Ex. When the value of the buffer memory is set as follows
  - CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128): 2 (temperature measurement range 0 to 1300°C)
  - Alert dead band setting (Un\G164): 5 (0.5%)
     (Full scale) × (Alert dead band) = (1300°C 0°C) × 0.005 = 6.5°C
     The dead band is the alert set value (SV) ±6.5°C.

### (b) Default value

The default value is set to 5 (0.5%).

# (39) Number of alert delay (Un\G165) Standard Heating-cooling

Set the number of sampling for an alert judgment.

By setting number of sampling, when the temperature process value (PV) stays within the alert area until the number of sampling exceeds the number of alert delay, the alert status will be active.

For details on the alert function, refer to the following.

Page 157, Section 8.2.11

### (a) Setting range

The setting range is 0 to 255 (times).

### (b) Default value

The default value is set to 0 (times).

### (40) Heater disconnection/output off-time current error detection delay count

# (Un\G166) Standard Heating-cooling

Set the limit value for consecutive heater disconnection detections and output off-time current error detections so that the errors exceeding the limit value triggers an alert judgment.

For details on the heater disconnection detection function, refer to the following.

Page 215, Section 8.2.24

For details on the output off-time current error detection function, refer to the following.

Page 220, Section 8.2.25

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

The setting range is 3 to 255 (times).

### (c) Default value

The default value is set to 3 (times).

# (41)Temperature rise completion range setting (Un\G167) Standard Heating-cooling

Set the vertical range of the temperature rise completion range.

When the temperature process value (PV) meets the following conditions, the temperature rise is completed.

 Set value (SV) - Temperature rise completion range ≤ Temperature process value (PV) ≤ Set value (SV) + Temperature rise completion range



When CH Temperature process value (PV) (Un\G9 to Un\G12) enters the temperature rise judgment range, CH Temperature rise judgment flag (Un\G17 to Un\G20) is set to Within temperature rise completion range (1). (Set the time from the temperature rise completion to Within temperature rise completion range (1) in Temperature rise completion soak time setting (Un\G168).)

### (a) Setting range

- When the temperature unit of the input range is °C: 1 to 10 (°C)
- When the temperature unit of the Input range is  $\,^\circ\text{F}$ : 1 to 10 (  $\,^\circ\text{F}$ )
- Other than above: 1 to 10 (%) of the full scale

# (b) Default value

The default value is set to 1.

# Appendix 2 Details of the Buffer Memory

# (42) Temperature rise completion soak time setting (Un\G168) Standard Heating-cooling

Set the delay time for CH $\square$  Temperature rise judgment flag (Un\G17 to Un\G20) (FP Page 340, Appendix 2 (6)) to be set to Within temperature rise completion range (1).

### (a) Setting range

The setting range is 0 to 3600 (min).

### (b) Default value

The default value is set to 0 (min).

# (43)PID continuation flag (Un\G169) Standard Healing-cooling

Set the operation status at the time when the mode has shifted from the operation mode to the setting mode (Setting/operation mode instruction (Yn1) ON  $\rightarrow$  OFF).

For details on the relationship between this flag and the control status, refer to the following.

- PID control: Page 134, Section 8.2.3 (6)
- Temperature judgment: Page 336, Appendix 2 (3)
- Alert judgment: Page 166, Section 8.2.11 (5)

### (a) Setting range

- 0: Stop
- 1: Continue

### (b) Default value

The default value is set to Stop (0).

# (44) Heater disconnection correction function selection (Un\G170) Standard Heating-cooling

Set whether to use the heater disconnection correction function or not.

For details on the heater disconnection correction function, refer to the following.

Page 217, Section 8.2.24 (3)

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

- 0: Not use the heater disconnection correction function
- 1: Use the heater disconnection correction function

### (c) Default value

The default value is set to Not use the heater disconnection correction function (0).

# (45)Transistor output monitor ON delay time setting (Un\G175)Standard Healing-cooling

Set the delay time of the ON delay output flag.

Set this buffer memory area to perform the heater disconnection detection with an input module.

For ON delay output flag, refer to the following.

Page 341, Appendix 2 (7)

For details on the ON delay output function, refer to the following.

Page 174, Section 8.2.14

### (a) Setting range

The setting range is 0 or 1 to 50 (10 to 500ms).

When 0 is set, ON delay output flag is not set to 1 (ON).

### (b) Default value

The default value is set to 0.

# (46)CT monitor method switching (Un\G176) Standard Heating-cooling

Set the method for performing the heater current measurement.

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

- 0: ON current/OFF current
- 1: ON current

When ON current/OFF current (0) is set, the present current value of the current sensor (CT) is measured. Selecting ON current (1) fixes the current value of the heater being OFF as the current value of the heater previously being ON.

### (c) Default value

The default value is set to ON current/OFF current (0).

### (47)CH□ Manipulated value (MV) for output with another analog module (Un\G177

to Un\G180) Standard

CH□ Manipulated value of heating (MVh) for output with another analog

module (Un\G177 to Un\G180) Heating-cooling

CH□ Manipulated value of cooling (MVc) for output with another analog

module (Un\G708 to Un\G711) Heating-cooling



The values stored in the following buffer memory areas are converted for other analog modules such as a D/A converter module and stored in these buffer memory areas.

Buffer memory area name		Buffer mem	ory address		Reference
Buller memory area name	CH1	CH2	CH3	CH4	Kelefelice
CH□ Manipulated value (MV)	Un\G13	Un\G14	Un\G15	Un\G16	
CH□ Manipulated value for heating (MVh)	Un\G13	Un\G14	Un\G15	Un\G16	Page 339, Appendix 2 (5)
CH□ Manipulated value for cooling (MVc)	Un\G704	Un\G705	Un\G706	Un\G707	

Un\G177 to Un\G180 are used for heating in the heating-cooling control.

The store range differs depending on the resolution set in the following buffer memory area. (0 to 4000/0 to 12000/0 to 16000/0 to 20000)

• Resolution of the manipulated value for output with another analog module (Un\G181) (FP Page 384, Appendix 2 (48))

For details, refer to the following.

Page 173, Section 8.2.13 (2)



When the device which performs heating or cooling can receive only the analog input, use other analog modules (such as D/A converter module) to convert the digital output to the analog input.

### (48) Resolution of the manipulated value for output with another analog module

# (Un\G181) Standard Heating-cooling

Set the resolution of the following buffer memory areas. (FP Page 339, Appendix 2 (5))

- CH□ Manipulated value (MV) (Un\G13 to Un\G16)
- CH□ Manipulated value for heating (MVh) (Un\G13 to Un\G16)
- CH□ Manipulated value for cooling (MVc) (Un\G704 to Un\G707)

For details, refer to the following.

Page 173, Section 8.2.13 (2)

### (a) Setting range

- 0: 0 to 4000
- 1: 0 to 12000
- 2: 0 to 16000
- 3: 0 to 20000

The manipulated value (MV) reflecting the resolution is stored in the following buffer memory areas.

( Page 383, Appendix 2 (47))

- CH□ Manipulated value (MV) for output with another analog module (Un\G177 to Un\G180)
- CH□ Manipulated value of heating (MVh) for output with another analog module (Un\G177 to Un\G180)
- CH Manipulated value of cooling (MVc) for output with another analog module (Un\G708 to Un\G711)

### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (c) Default value

The default value is set to 0 to 4000 (0).

# (49)Cold junction temperature compensation selection (Un\G182) Common

Select whether to perform the cold junction temperature compensation using a standard terminal block or not to perform the cold junction temperature compensation.

### (a) Supported modules

- L60TCTT4
- L60TCTT4BW

### (b) Setting range

- 0:Use Standard Terminal Block
- 1: This setting cannot be used.
- 2: Not use cold junction temperature compensation

### (c) Default value

The default value is set to Use Standard Terminal Block (0).

# (50)Control switching monitor (Un\G183) Common

The setting contents of the mode selection set on Switch Setting are stored in this buffer memory area. The mode in operation can be confirmed.

The following table lists the stored value and the contents.

Stored value	Mode		
Stored value		Control mode	
0 <sub>H</sub>	Temperature control mode	Standard control	
1 <sub>H</sub>		Heating-cooling control (normal mode)	
2 <sub>H</sub>		Heating-cooling control (expanded mode)	
3 <sub>H</sub>		Mix control (normal mode)	
4 <sub>H</sub>		Mix control (expanded mode)	
100 <sub>H</sub>	Temperature input mode	•	

Select the mode on Switch Setting.

For details on the setting method, refer to the following.

Page 108, Section 7.2

For details on the modes, refer to the following.

Page 116, Section 8.1, Page 126, Section 8.2.1

# (51)CH□ Auto tuning mode selection (Un\G184 to Un\G187) Standard Healing-cooling

Select the auto tuning mode from the following two modes according to the controlled object to be used.

Auto tuning mode	Description
Standard mode	The standard mode is appropriate for most controlled objects. This mode is especially suitable for controlled objects that have an extremely slow response speed or can be affected by noise or disturbance.  However, PID constants of slow response (low gain) may be calculated from controlled objects whose ON time or OFF time in the auto tuning is only around 10s.  In this case, PID constants of fast response can be calculated by selecting the high response mode and performing the auto tuning.
High response mode	This mode is suitable for controlled objects whose ON time or OFF time in the auto tuning is only around 10s. PID constants of fast response (high gain) can be calculated. However, the temperature process value (PV) may oscillates near the set value (SV) because of the too high gain of the PID constants calculated. In this case, select the normal mode and perform the auto tuning.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

### (a) Setting range

- · 0: Standard mode
- 1: High response mode

### (b) Default value

The default values are set to Standard mode (0) in all channels.

(52)CH□ Alert 1 mode setting (Un\G192, Un\G208, Un\G224, Un\G240) Standard Realing-cooling CH□ Alert 2 mode setting (Un\G193, Un\G209, Un\G225 Un\G241) Standard Realing-cooling CH□ Alert 3 mode setting (Un\G194, Un\G210, Un\G226, Un\G242) Standard Realing-cooling CH□ Alert 4 mode setting (Un\G195, Un\G211, Un\G227, Un\G243) Standard Realing-cooling CH□ Alert 4 mode setting (Un\G195, Un\G211, Un\G227, Un\G243) Standard Realing-cooling

Set the alert mode of alert 1 to 4.

For details on the alert function, refer to the following.

Page 157, Section 8.2.11

### (a) Alert mode and alert set value

Any alert set value can be set in each alert mode of alert 1 to 4 selected in this setting. Set the alert set value 1 to 4 in the following buffer memory areas. Alert set values 1 to 4 respectively correspond to alert modes of alert 1 to 4.

Buffer memory area name	Buffer memory address				Reference	
Burier memory area name	CH1	CH2	CH3	CH4	Neierence	
CH□ Alert set value 1	Un\G38	Un\G70	Un\G102	Un\G134		
CH□ Alert set value 2	Un\G39	Un\G71	Un\G103	Un\G135	Page 358, Appendix 2 (18)	
CH□ Alert set value 3	Un\G40	Un\G72	Un\G104	Un\G136	- Fage 336, Appendix 2 (16)	
CH□ Alert set value 4	Un\G41	Un\G73	Un\G105	Un\G137		

### (b) Setting range

The following table lists set values and setting ranges which are available for alert set values set in each alert mode.

Set value	Alert mode	Setting range of alert set value	
0	- (no alert)	_	
1	Upper limit input alert	Within the temperature measurement range of the set input range	
2	Lower limit input alert	( Page 345, Appendix 2 (12))	
3	Upper limit deviation alert	-(full scale) to +(full scale)	
4	Lower limit deviation alert	-(full scale) to +(full scale)	
5	Upper lower limit deviation alert	0 to +(full scale)	
6	Within-range alert	10 to +(itili scale)	
7	Upper limit input alert with standby	Within the temperature measurement range of the set input range	
8	Lower limit input alert with standby	( Page 345, Appendix 2 (12))	
9	Upper limit deviation alert with standby	-(full scale) to +(full scale)	
10	Lower limit deviation alert with standby	-(Iuii scale) to +(Iuii scale)	
11	Upper lower limit deviation alert with standby	0 to +(full scale)	
12	Upper limit deviation alert with standby (second time)	-(full scale) to +(full scale)	
13	Lower limit deviation alert with standby (second time)	-(Iuii scale) to +(Iuii scale)	
14	Upper lower limit deviation alert with standby (second time)	0 to +(full scale)	
15	Upper limit deviation alert (using the set value (SV))	-(full scale) to +(full scale)	
16	Lower limit deviation alert (using the set value (SV))	(Tuli Scale) to +(Tuli Scale)	
17	Upper lower limit deviation alert (using the set value (SV))	0 to +(full scale)	
18	Within-range alert (using the set value (SV))	o to '(tuli scale)	

A
$\overline{c}$
Ã.
pendix
뽀
_
Ω.
Δ.
$\sim$
Details
$_{\sim}$
Œ,
ੜ
≌.
ᆕ
O,
<del>ٽ</del>
of the
ᠴ
ī
$\varpi$
Buffer
⇆
⇟
Ψ.
_
7
=
Ø
Memor
$\preceq$
$\simeq$
ب

Set value	Alert mode	Setting range of alert set value	
19	Upper limit deviation alert with standby (using the set value (SV))	(full scale) to +(full scale)	
20	Lower limit deviation alert with standby (using the set value (SV))	(full scale) to +(full scale)	
21	Upper lower limit deviation alert with standby (using the set value (SV))	0 to +(full scale)	
22	Upper limit deviation alert with standby (second time) (using the set value (SV))	(full scale) to ±(full scale)	
23	Lower limit deviation alert with standby (second time) (using the set value (SV))	(full scale) to +(full scale)	
24	Upper lower limit deviation alert with standby (second time) (using the set value (SV))	0 to +(full scale)	

### (c) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

When the set value is out of the range, a write data error (error code:  $\Box\Box\Box\Box 4_H$ ) occurs, and the L60TC4 operates with the previous set value. Turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF after the error occurrence and setting a value within the range operate the L60TC4 with the new set value.

### (d) Default value

The default values are set to 0 in all channels.

### (53)CH□ Process alarm alert output enable/disable setting (Un\G196, Un\G212,

# Un\G228, Un\G244) Temperature Input

Set whether to enable or disable alert output of process alarm. For details on the process alarm, refer to the following.

Page 120, Section 8.1.3 (1)

### (a) Setting range

- 0: Enable
- 1: Disable

### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (c) Default value

The default values are set to Disable (1) in all channels.

(54)CH□ Process alarm lower lower limit value (Un\G197, Un\G213, Un\G229,

Un\G245) Temperature Input

CH□ Process alarm lower upper limit value (Un\G198, Un\G214, Un\G230,

Un\G246) Temperature Input

CH□ Process alarm upper lower limit value (Un\G199, Un\G215, Un\G231,

Un\G247) Temperature Input

CH□ Process alarm upper upper limit value (Un\G200, Un\G216, Un\G232,

Un\G248) Temperature Input

Set the lower lower limit value, lower upper limit value, upper lower value, and upper upper limit of process alarm.

### (a) Setting range

The setting range should meet the both of the following.

- Within the temperature measurement range of set input range (Page 345, Appendix 2 (12))
- Process alarm lower lower limit value ≤ Process alarm lower upper limit value ≤ Process alarm upper lower limit value ≤ Process alarm upper upper limit value (If the setting is out of the setting value, out of range error (error code: □□□8<sub>H</sub>) occurs.)

### (b) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (☐ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C ( °F or digit) unit.
- One decimal place (1): Set a value in 0.1°C ( °F) unit (tenfold value).

### (c) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (d) Default value

Item	Default value			
item	L60TCTT4/L60TCTT4BW	L60TCRT4/L60TCRT4BW		
CH□ Process alarm lower lower limit value	0	-2000		
CH□ Process alarm lower upper limit value	0	-2000		
CH□ Process alarm upper lower limit value	1300	6000		
CH□ Process alarm upper upper limit value	1300	6000		

# (55)CH□ Rate alarm alert output enable/disable setting (Un\G201, Un\G217,

# Un\G233, Un\G249) Temperature Input

Set whether to enable or disable alert output of rate alarm. For details on the rate alarm, refer to the following. Page 122, Section 8.1.3 (2)

### (a) Setting range

- 0: Enable
- 1: Disable

### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (c) Default value

The default values are set to Enable (1) in all channels.

### (56)CH□ Rate alarm alert detection cycle (Un\G202, Un\G218, Un\G234,

# Un\G250) Temperature Input

Set the check cycle of the temperature process value (PV) for the rate alarm. Set the frequency of checks in the unit of sampling cycles.

The check cycle can be calculated from the following formula.

• Rate alarm alert detection cycle = Set value of Rate alarm alert detection cycle × Sampling cycle

### (a) Setting range

The setting range is 1 to 6000 (times).

### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (c) Default value

The default values are set to Every sampling cycle (1) in all channels.

### (57)CH□ Rate alarm upper limit value (Un\G203, Un\G219, Un\G235, Un\G251) [Temperature Input]



# CH□ Rate alarm lower limit value (Un\G204, Un\G220, Un\G236, Un\G252) [Temperature Input

Set the rate alarm upper limit value and lower limit value.

### (a) Setting range

The setting is -32768 to 32767.

### (b) Setting unit

The value to be set differs depending on the stored value in CH Decimal point position (Un\G1 to Un\G4). (F Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C ( °F or digit) unit.
- One decimal place (1): Set a value in 0.1°C (°F) unit (tenfold value).

### (c) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF → ON → OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (d) Default value

The default values are set to 0 in all channels.

# (58)CT□ Heater current process value (Un\G256 to Un\G263) Standard Heating-cooling

The heater current value which L60TCTT4BW or L60TCRT4BW detects is stored in this buffer memory area. The current values within the range of the current sensor selected in CT CT selection (Un\G272 to Un\G279) (Page 392, Appendix 2 (60)) is stored.

### (a) Supported module

- L60TCTT4BW
- L60TCRT4BW



To perform the measurement of the heater current, the following buffer memory areas need to be set.

- CT CT input channel assignment setting (Un\G264 to Un\G271) (F Page 391, Appendix 2 (59))
- CT□ Reference heater current value (Un\G280 to Un\G287) ( Page 393, Appendix 2 (61))

If the both are set to 0, the heater current cannot be measured. If either of them is not set, the heater current cannot be measured precisely.

# (59)CT□ CT input channel assignment setting (Un\G264 to Un\G271) Standard Heating-cool





Set the assignment of each current sensor (CT) input to the channels.

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Correspondence between CT input terminal and buffer memory address

CT input terminal	Buffer memory address
CT1	Un\G264
CT2	Un\G265
CT3	Un\G266
CT4	Un\G267
CT5	Un\G268
CT6	Un\G269
CT7	Un\G270
CT8	Un\G271

### (c) Setting range

- 0: Unused
- 1: CH1
- 2: CH2
- 3: CH3
- 4: CH4

### (d) Default value

The default values are set to Unused (0) for all terminals.



• If a three-phase heater is used, the same channel should be assigned to two current sensor (CT) inputs. For setting examples, refer to the following.

Page 105, Section 6.5

In the heating-cooling control, CH3 and CH4 cannot be assigned to this setting. In the mix control, CH2 cannot be assigned to this setting.

# (60)CT□ CT selection (Un\G272 to Un\G279) Standard Heating-cooling

Select the current sensor to be connected to each current sensor (CT) input.

### (a) Supported modules

- · L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

- 0: When CTL-12-S36-8 is used (0.0 to 100.0A)
- 1: When CTL-6-P(-H) is used (0.00 to 20.00A)
- 2: When CT ratio setting is used (0.0A to 100.0A)

### (c) Current sensor (CT) to be used and buffer memory setting

When using a current sensor (CT) other than CTL-12-S36-8 and CTL-6-P(-H), set the number of second-winding (turns) of the current sensor (CT) to be connected in CT CT ratio setting (Un\G288 to Un\G295). Set the buffer memory area as follows according to the specification of the current sensor (CT) to be used.

Current sensor (CT) to be used		CT□ CT Selection (Un\G272 to Un\G279)	CT□ CT ratio setting (Un\G288 to Un\G295) (『 Page 393, Appendix 2 (62))	Note	
	CTL-12-S36-8	When CTL-12-S36-8 is used (0.0A to 100.0A) (0)	Setting not necessary	The product is	
Products of U.R.D.Co.,	CTL-6-P	When CTL-6-P(-H) is used (0.00A to 20.00A) (1)	Setting not necessary	discontinued, though it can be used.	
	CTL-6-P-H	When CTL-6-P(-H) is used (0.00A to 20.00A) (1) Setting not necessar		_	
LIB.	CTL-12-S36-10	When CT ration setting is used (0.0A to 100.0A) (2)	Set 1000, which is the number of second-winding (turns).	_	
	CTL-12-S56-10	When CT ration setting is used (0.0A to 100.0A) (2)	Set 1000, which is the number of second-winding (turns).	_	
Other current sensors(CT)		When CT ration setting is used (0.0A to 100.0A) (2)	Set the number of second-winding (turns) depending on the current sensor (CT) specification.	Current sensors (CT) whose number of second- wonding (turns) is 600 to 9999 can be used.	

For the URL of U.R.D.Co., LTD., refer to the following.

Page 82, Section 5.2 (4)

### (d) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (e) Occurrence of write data error

In the following case, a write data error (error code:  $\Box\Box\Box\Box 4_H$ ) occurs as when the setting is out of the setting value. Error occurrence flag (Xn2) turns on and the error code is stored in Error code (Un\G0).

When the set value of CT□ CT ratio setting (Un\G288 to Un\G295) is out of the setting when Setting change instruction (YnB) is turned OFF → ON → OFF

### (f) Default value

The default values are set to When CTL-12-S36-8 is used (0.0 to 100.0A) (0) for all terminals.



When CT ratio setting is used (0.0 to 100.0A) (2) is selected, the setting of CT□ CT ratio setting (Un\G288 to Un\G295) is enabled. In advance, set CT□ CT ratio setting (Un\G288 to Un\G295) corresponding to the sensor to be connected. After that, select When CT ratio setting is used (0.0 to 100.0A) (2).

### (61)CT□ Reference heater current value (Un\G280 to Un\G287) Standard Heating-cooling





Set the reference value of CT Heater current process value (Un\G256 to Un\G263) of when the heater is turned on (Page 390, Appendix 2 (58)).

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

The setting range is within the heater current range of the current sensor selected in CT□ CT selection (Un\G272 to Un\G279). (FFPage 392, Appendix 2 (60))

Setting range	Setting of CT□ CT selection (Un\G272 to Un\G279)
0 to 1000 (0.0 to 100.0A)	• When CTL-12-S36-8 is used (0.0 to 100.0A) (0) • When CT ratio setting is used (0.0 to 100.0A) (2)
0 to 2000 (0.00 to 20.00A)	When CTL-6-P(-H) is used (0.00 to 20.00A) (1)

### (c) Default value

The default values are set to 0 (0.0A) for all terminals.

# (62)CT□ CT ratio setting (Un\G288 to Un\G295) Standard Heating cooling

Set the number of second-winding (turning number) of the current sensor (CT) to be connected. This buffer memory area is available only when CT□ CT selection (Un\G272 to Un\G279) is set to When CT ratio setting is used (0.0 to 100.0A) (2). (Fig. Page 392, Appendix 2 (60))

### (a) Supported modules

- L60TCTT4BW
- L60TCRT4BW

### (b) Setting range

The setting range is 600 to 9999.

### (c) Default value

The default values are set to 800 for all terminals.

### (63)CH□ 2-point sensor compensation offset value (measured value) (Un\G544,

# Un\G576, Un\G608, Un\G640) Common

The measured value of temperature corresponding to the offset value of the 2-point sensor compensation is stored in this buffer memory area.

The value to be stored differs depending on the stored value in CHD Decimal point position (Un\G1 to Un\G4).

(F Page 334, Appendix 2 (2))

- No decimal place (0): stored as it is.
- One decimal place (1): stored after a multiplication by 10.

For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

### (a) Enablement of the stored value

Turn Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF) to enable stored contents.

### (64)CH□ 2-point sensor compensation offset value (compensation value)

# (Un\G545, Un\G577, Un\G609, Un\G641) Common

Set the temperature of the offset value of the 2-point sensor compensation.

For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

### (a) Setting range

The setting range is identical to the temperature measurement range of the set input range. (Page 345, Appendix 2 (12))

### (b) Setting unit

The value to be set differs depending on the stored value in CH $\square$  Decimal point position (Un\G1 to Un\G4). (FF Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C (°F or digit) unit.
- One decimal place (1): Set a value in 0.1°C ( °F) unit (tenfold value).

### (c) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

### (d) Default value

The default values are set to 0 in all channels.

#### (65)CH□ 2-point sensor compensation gain value (measured value) (Un\G546,

#### Un\G578, Un\G610, Un\G642) Common

The measured value of temperature corresponding to the gain value of the 2-point sensor compensation is stored in this buffer memory area.

The value to be stored differs depending on the stored value in CHD Decimal point position (Un\G1 to Un\G4).

(F Page 334, Appendix 2 (2))

- No decimal place (0): stored as it is.
- One decimal place (1): stored after a multiplication by 10.

For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

#### (a) Enablement of the stored value

Turn Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF) to enable stored contents.

#### (66)CH□ 2-point sensor compensation gain value (compensation value) (Un\G547,

#### Un\G579, Un\G611, Un\G643) Common

Set temperature of gain value of the 2-point sensor compensation.

For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

#### (a) Setting range

The setting range is identical to the temperature measurement range of the set input range. (FP Page 345, Appendix 2 (12))

#### (b) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (□ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C (°F or digit) unit.
- One decimal place (1): Set a value in 0.1°C ( °F) unit (tenfold value).

#### (c) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (d) Default value

The default values are set to 0 in all channels.

#### (67)CH□ 2-point sensor compensation offset latch request (Un\G548, Un\G580,

#### Un\G612, Un\G644) Common

This request is for storing temperature process value (PV) as 2-point sensor compensation offset value to the following buffer memory area.

• CHI 2-point sensor compensation offset value (measured value) (Un\G544, Un\G576, Un\G608, Un\G640) (FF Page 394, Appendix 2 (63))

For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

#### (a) Setting range

- 0: No request
- 1: Latch request

#### (b) Default value

The default values are set to No request (0) in all channels.

#### (68)CH□ 2-point sensor compensation offset latch completion (Un\G549, Un\G581,

#### Un\G613, Un\G645) Common

When 2-point sensor compensation offset value is stored, 1 is stored in this buffer memory area, which is Latch completed (1).

When CH $\square$  2-point sensor compensation offset latch request (Un\G548, Un\G580, Un\G612, Un\G644) is set to No request (0), 0 is stored in this buffer memory area, which is No request (0). (FF Page 396, Appendix 2 (67)) For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

# Appendix 2 Details of the Buffer Memory

#### (69)CH□ 2-point sensor compensation gain latch request (Un\G550, Un\G582,

#### Un\G614, Un\G646) Common

This is a request for storing temperature process value (PV) as 2-point sensor compensation gain value to the following buffer memory area.

• CH 2-point sensor compensation gain value (measured value) (Un\G546, Un\G578, Un\G610, Un\G642) (FP Page 395, Appendix 2 (65))

For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

#### (a) Setting range

- 0: No request
- 1: Latch request

#### (b) Default value

The default values are set to No request (0) in all channels.

#### (70)CH□ 2-point sensor compensation gain latch completion (Un\G551, Un\G583,

#### Un\G615, Un\G647) Common

When 2-point sensor compensation gain value is stored, 1 is stored in this buffer memory area, which is Latch completed (1).

When CH $\square$  2-point sensor compensation gain latch request (Un\G550, Un\G582, Un\G614, Un\G646) is set to No request (0), 0 is stored in this buffer memory area, which is No request (0). (Figure Page 397, Appendix 2 (69)) For details on the 2-point sensor compensation function, refer to the following.

Page 227, Section 8.3.2 (2)

#### (71)CH□ AT simultaneous temperature rise parameter calculation flag (Un\G573,

#### Un\G605, Un\G637, Un\G669) Standard

The status when simultaneous temperature rise AT (auto tuning) calculates simultaneous temperature rise parameter is stored in this buffer memory area.

- 0: OFF
- 1: ON



Bit data from b15 to b3 are fixed to 0.

Bit	Flag name	Description
b0	AT simultaneous temperature rise parameter calculation completion	This flag is set to 1 (ON) when the simultaneous temperature rise parameter*1 is calculated by simultaneous temperature rise AT.
b1	AT simultaneous temperature rise parameter calculation error status	This flag is set to 1 (ON) when the simultaneous temperature rise parameter*1 cannot be calculated by simultaneous temperature rise AT.
b2	Simultaneous temperature rise AT disable status	This flag is set to 1 (ON) when the simultaneous temperature rise AT cannot be performed.
b3 to b15	- (fixed to 0)	- (Unused)

<sup>\*1</sup> Indicates the values of CH□ Simultaneous temperature rise gradient data (Un\G731, Un\G747, Un\G763, Un\G779) and CH□ Simultaneous temperature rise dead time (Un\G732, Un\G748, Un\G764, Un\G780).



This area is enabled only for the following channels (channels of the standard control).

- · CH1 to CH4 when the standard control is used
- CH3 and CH4 when mix control (normal mode) or mix control (expanded mode) is used

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

# Appendix 2 Details of the Buffer Memory

#### (72)CHD Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) Standard



Perform operation setting of self-tuning with this buffer memory area.

For details on the self-tuning function, refer to the following.

Page 175, Section 8.2.15

#### (a) Setting range

- · 0: Do Not Run the ST
- 1: Starting ST (PID Constants Only)
- 2: Starting ST (Simultaneous Temperature Rise Parameter Only\*1)
- 3: Starting ST (PID constants and Simultaneous Temperature Rise Parameter\*1)
- 4: Starting ST and vibration ST (PID Constants Only)
- Indicates the values of CHI Simultaneous temperature rise gradient data (Un\G731, Un\G747, Un\G763, Un\G779) and CHD Simultaneous temperature rise dead time (Un\G732, Un\G748, Un\G764, Un\G780) to be used in the simultaneous temperature rise function.

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

#### (b) Default value

The default values are set to Do Not Run the ST (0) in all channels.



This area is enabled only for the following channels (channels of the standard control).

- · CH1 to CH4 when the standard control is used
- CH3 and CH4 when mix control (normal mode) or mix control (expanded mode) is used


#### (73)CH□ Self-tuning flag (Un\G575, Un\G607, Un\G639, Un\G671) Standard



The execution status of self-tuning can be monitored in this buffer memory area.

For details on the self-tuning function, refer to the following.

Page 175, Section 8.2.15



The following contents are stored in each bit.

- 0: OFF
- 1: ON

Bit	Flag name	Condition on which value turns to 1 (ON)	Condition on which value turns to 0 (OFF)		
b0	PID auto-correction status	This flag is set to 1 (ON) when PID constants are corrected by the self-tuning.	This flag is set to 0 (OFF) when either of the following operation is performed.		
b1	Simultaneous temperature rise parameter correction status	This flag is set to 1 (ON) when simultaneous temperature rise parameter*1 is corrected by self-tuning.	<ul> <li>When the operation mode shifts to the setting mode by turning off from on Setting/operation mode instruction (Yn1)</li> <li>When CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1)</li> <li>When CH□ PID control forced stop instruction (YnC to YnF) is turned on from off</li> <li>When CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) is set to Do not run the ST (0)</li> <li>This flag is also set to 0 (OFF) in the following cases.</li> <li>When the self-tuning starts by changing the set value (SV)</li> <li>When the vibration ST starts by vibration caused by disturbance of the process value (PV)</li> </ul>		
b2 to b7	- (fixed to 0)	- (Unused)	_		
b8	Self-tuning disable status	This flag is set to 1 (ON) when the self-tuning cannot be performed.	This flag is set to 0 (OFF) when either of the following operation is performed.  • When the operation mode shifts to the setting mode by turning off from on Setting/operation mode instruction (Yn1)  • When CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1)  • When CH□ PID control forced stop instruction (YnC to YnF) is turned on from off  • When CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) is set to Do not run the ST (0)  This flag is also set to 0 (OFF) when all disable conditions are released.  For disable conditions, refer to □ Page 181, Section 8.2.15 (6).		

Bit	Flag name	Condition on which value turns to 1 (ON)	Condition on which value turns to 0 (OFF)
b9	Simultaneous temperature rise parameter error status	This flag is set to 1 (ON) when simultaneous temperature rise parameter*1 cannot be calculated by self-tuning.	
b10	Self-tuning error	This flag is set to 1 (ON) when either of the following operation is performed during the self-tuning.  • PID constants change • Setting change rate limiter change • Output limiter change • Control output cycle change • Sensor correction change • Primary delay digital filter change • AUTO to MAN mode shift • Forward/reverse action shift This flag is also set to 1 (ON) in the following cases • When the temperature process value (PV) is out of the temperature measurement range • When required measurement data is not obtained because the manipulated value (MV) does not reach the upper limit output limiter value or the lower limit output limiter value until the measurement is completed • When the temperature process value (PV) decreases by 1°C (°F) or more though it should increase after the self-tuning is started as the starting ST • When temperature process value (PV) increases by 1°C (°F) or more though it should decrease after the self-tuning is started as the starting ST	This flag is set to 0 (OFF) when either of the following operation is performed.  • When the operation mode shifts to the setting mode by turning off from on Setting/operation mode instruction (Yn1)  • When CH□ Unused channel setting (Un\G61, Un\G93, Un\G125, Un\G157) is set to Unused (1)  • When CH□ PID control forced stop instruction (YnC to YnF) is turned on from off  • When CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670) is set to ST(0)  This flag is also set to 0 (OFF) in the following cases.  • When the self-tuning starts by changing the set value (SV)  • When the vibration ST starts by vibration caused by disturbance of the process value (PV)
b11 to b15	- (fixed to 0)	- (Unused)	

Indicates the values of CH Simultaneous temperature rise gradient data (Un\G731, Un\G747, Un\G763, Un\G779) and CH Simultaneous temperature rise dead time (Un\G732, Un\G748, Un\G764, Un\G780).

For details on the simultaneous temperature rise function, refer to Page 190, Section 8.2.17.



This area is enabled only for the following channels (channels of the standard control).

- CH1 to CH4 when the standard control is used
- CH3 and CH4 when mix control (normal mode) or mix control (expanded mode) is used

#### (74)CH□ Temperature process value (PV) for input with another analog module

#### (Un\G689 to Un\G692) Standard Heating-cooling

Digital input value of the current/voltage converted in another analog module (such as A/D conversion module) on system can be used as a temperature process value (PV).

Store digital input values of current/voltage converted by another analog module (such as A/D conversion module) in this area.

For details, refer to the following.

Page 172, Section 8.2.13 (1)



If a stored value is out of the set input range, the value to be used in control is fixed to the upper limit value or the lower limit value of the input range.

#### (75)Conversion enable/disable setting (Un\G693) [Temperature Input]



Set enable or disable temperature input. For details on the temperature input function, refer to the following. Page 116, Section 8.1



#### (a) Setting range

- 0: Enable
- 1: Disable

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF → ON → OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

All channels are set to Conversion disable (000F<sub>H</sub>).

#### (76)CHD Temperature conversion setting (Un\G695 to Un\G697) Healing-cooling

In the heating-cooling control (normal mode) or the mix control (normal mode), only the temperature measurement can be performed using temperature input terminals of unused channels.

The following table lists the settable buffer memory addresses for each control mode selection.

	Control mode							
Channel	Standard control	Heating- cooling control (normal mode)	Heating- cooling control (expanded mode)	Mix control (normal mode)	Mix control (expanded mode)			
CH1	_	_	_	_	_			
CH2	_	_	_	Un\G695	_			
CH3	_	Un\G696	_	_	_			
CH4	_	Un\G697	_	_	_			

When the combination of the control mode and the buffer memory address is not the setting target in the above list, the combination is invalid even if it is set.

For details on the temperature conversion function (using unused channels), refer to the following.

Page 212, Section 8.2.23

#### (a) Setting range

- 0: Not use
- 1: Use

#### (b) Default value

The default values are set to Not use (0) in all channels.



- When this setting is set from Not use (0) to Use (1), after completion of the first temperature conversion, Temperature conversion completion flag (Un\G786) is set to First temperature conversion completed (1H). Before referring to the temperature process value (PV) of each channel, check Temperature conversion completion flag (Un\G786) has been set to First temperature conversion completed (1<sub>H</sub>).
- When the following control mode is selected, this setting is invalid.
  - · Standard control
  - · Heating-cooling control (expanded mode)
  - · Mix control (expanded mode)

#### (77)Cooling method setting (Un\G719) Heating-cooling

Set the method for the cooling control in the heating-cooling control. Select the suitable cooling method for cooling characteristics of devices.

The following figure shows the channel assignment of the buffer memory area.

b15	to	b12	b11	to	b8	b7	to	b4	b3	to	b0
	CH4			CH3			CH2			CH1	

For details on the cooling method setting function, refer to the following.

Page 207, Section 8.2.21

#### (a) Setting range

- 0<sub>H</sub>: Air cooling
- 1<sub>H</sub>: Water cooling
- 2<sub>H</sub>: Linear

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

The default value is set to Air cooling  $(0_H)$ .

#### (78)CH□ Overlap/dead band function (Un\G723, Un\G739, Un\G755,

#### Un\G771) Heating-cooling

Configure the overlap/dead band setting.

For details on the overlap/dead band function, refer to the following.

Page 209, Section 8.2.22

#### (a) Setting range

Set the value within the following ranges for the full scale of the set input range. (Fig. Page 345, Appendix 2 (12))

- -100 to -1 (-10.0% to -0.1%): Overlap
- 0(0.0%): None
- 1 to 100 (0.1% to 10.0%): Dead band

#### (b) Default value

The default values are set to 0 (0.0%) in all channels.

#### (79)CH□ Manual reset amount setting (Un\G724, Un\G740, Un\G756, Un\G772)



Set the amount of the proportional band (P) to be moved.

For details on the manual reset function, refer to the following.

Page 137, Section 8.2.4

#### (a) Setting range

Set the value within the range of -1000 to 1000 (-100.0% to 100.0%) for the full scale of the set input range. (Fig. Page 345, Appendix 2 (12))

The setting range is the same between the standard control and heating-cooling control.

#### (b) Default value

The default values are set to 0 (0.0%) in all channels. The default value is the same between the standard control and the heating-cooling control.

#### (80)CH□ Process value (PV) scaling function enable/disable setting (Un\G725,

#### Un\G741, Un\G757, Un\G773) Common

Set enable/disable of the temperature process value (PV) scaling function.

For details on the temperature process value (PV) scaling function, refer to the following.

Page 221, Section 8.3.1

#### (a) Setting range

- 0: Disable
- 1: Enable

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

The default values are set to Disable (0) in all channels.

#### (81)CH□ Process value (PV) scaling lower limit value (Un\G726, Un\G742,

Un\G758, Un\G774) Common

CH□ Process value (PV) scaling upper limit value (Un\G727, Un\G743,

Un\G759, Un\G775) Common

Set the upper limit value/lower limit value of the temperature process value (PV) scaling function.

For details on the temperature process value (PV) scaling function, refer to the following.

Page 221, Section 8.3.1

#### (a) Setting range

The setting range is -32000 to 32000.

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

The default values are set to 0 in all channels.



The setting where the lower limit value is not less than the upper limit value does not cause an error. The temperature process value (PV) is scaled according to the formula of Page 221, Section 8.3.1 (1).

#### (82)CH□ Process value (PV) scaling value (Un\G728, Un\G744, Un\G760,

#### Un\G776) Common

When the temperature process value (PV) scaling function is enabled, the scaled temperature process value (PV) is stored

For details on the temperature process value (PV) scaling function, refer to the following.

Page 221, Section 8.3.1

#### (83)CH□ Derivative action selection (Un\G729, Un\G745, Un\G761, Un\G777)



Select the type of derivative action. Dynamic performance can be improved by selecting the suitable derivative action for the fixed value action and the ramp action. For details on the derivative action selection function, refer to the following.

Page 154, Section 8.2.9

#### (a) Setting range

- 0: Measured value derivation
- · 1: Deviation derivation

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

All channels are set to Measured value derivation (0).

#### (84)CH□ Simultaneous temperature rise group setting (Un\G730, Un\G746,

#### Un\G762, Un\G778) Standard

Set a group to perform the simultaneous temperature rise function for each channel. The simultaneous temperature rise function enables channels in the same group to complete the rise of temperature simultaneously. When the control mode is the heating-cooling control, this setting is invalid.

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

#### (a) Setting range of the standard control

- 0: No simultaneous temperature rise
- 1: Group 1 selection
- · 2: Group 2 selection

#### (b) Setting range of the mix control

- 0: No simultaneous temperature rise
- 1: Simultaneous temperature rise

The setting range in the mix control does not include group selection because the mix control has only two channels for the standard control.

#### (c) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (d) Default value

The default values are set to No simultaneous temperature rise (0) in all channels.

#### (85)CH□ Simultaneous temperature rise gradient data (Un\G731, Un\G747,

#### Un\G763, Un\G779) Standard

Set Simultaneous temperature rise gradient data (temperature rising per minute).

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

#### (a) Setting range

The setting range is 0 to (the upper limit of the temperature measurement range of the set input range).

#### (b) Setting unit

The value to be set differs depending on the stored value in CH□ Decimal point position (Un\G1 to Un\G4). (☐ Page 334, Appendix 2 (2))

- No decimal place (0): Set a value in 1°C ( °F or digit) unit.
- One decimal place (1): Set a value in 0.1°C (°F) unit (tenfold value).

#### (c) Default value

The default values are set to 0 in all channels.



This setting can not only be set manually but also be calculated automatically. Automatic calculation is performed when the simultaneous temperature rise AT (auto tuning) or self-tuning (when the automatic calculation of the temperature rise parameter is set) is normally completed.

#### (86)CH□ Simultaneous temperature rise dead time (Un\G732, Un\G748, Un\G764,

#### Un\G780) Standard

Set Simultaneous temperature rise dead time (time taken for the temperature to start rising after the output is turned on).

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

#### (a) Setting range

The setting range is 0 to 3600 (s).

#### (b) Default value

The default values are set to 0 in all channels.



This setting can not only be set manually but also be calculated automatically. Automatic calculation is performed when the simultaneous temperature rise AT (auto tuning) or self-tuning (when the automatic calculation of the temperature rise parameter is set) is normally completed.

# Appendix 2 Details of the Buffer Memory

#### (87)CH□ Simultaneous temperature rise AT mode selection (Un\G733, Un\G749,

#### Un\G765, Un\G781) Standard

Select mode of the auto tuning.

For details on the auto tuning function, refer to the following.

Page 141, Section 8.2.7

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

#### (a) Setting range

- 0: Select normal auto tuning
- 1: Simultaneous temperature rise AT

#### (b) Default value

The default values are set to Select normal auto tuning (0) in all channels.



- This setting can be used with the setting of CH□ Auto tuning mode selection (Un\G184 to Un\G187). (☐ Page 385, Appendix 2 (51))
- If this setting is changed during the auto tuning, it is enabled in the next auto tuning.

#### (88)CH□ Simultaneous temperature rise status (Un\G734, Un\G750, Un\G766,


#### Un\G782) Standard

The execution state of the simultaneous temperature rise is monitored. The following values are stored in this buffer memory area.

- · 0: Simultaneous temperature rise not in process
- 1: Simultaneous temperature rise in process

During control by the simultaneous temperature rise function, Simultaneous temperature rise in process (1) is stored in this buffer memory area.

The following figure shows the timing when the value is set to Simultaneous temperature rise not in process (0). (In the following, CH1 and CH2 are set to group 1. (Fig. Page 407, Appendix 2 (84))



Completion of the temperature rise does not set CH $\square$  Simultaneous temperature rise status (Un\G734, Un\G750, Un\G766, Un\G782) to Simultaneous temperature rise not in process (0). As in the figure above, the temperature rise is performed by the simultaneous temperature rise function to a certain point, and Simultaneous temperature rise in process (1) is set during the performance. After the point, the temperature rise is performed based on the PID constants of each channel, and Simultaneous temperature rise not in process (0) is set.

For details on the simultaneous temperature rise function, refer to the following.

Page 190, Section 8.2.17

#### (89)CH□ Setting change rate limiter time unit setting (Un\G735, Un\G751, Un\G767,

#### Un\G783) Standard Heating-cooling

Set the time unit of setting change rate limiter.

For details on the setting change rate limiter time unit setting function, refer to the following.

Page 155, Section 8.2.10

#### (a) Setting range

- 0 (Not use time unit setting)
- 1 to 3600 (1 to 3600s)

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

The default values are set to 0 (Not use time unit setting) in all channels.



When 0 is set, the L60TC4 operation is the same as the case when 60, a variation per minute, is set.

#### (90)Peak current suppression control group setting (Un\G784) Standard

Set the target channels for the peak current suppression function and the gap of the control output cycle between channels.

b15	to	b12	b11	to	b8	b7	to	b4	b3	to	b0
	CH4			CH3			CH2			CH1	

For details on the peak current suppression function, refer to the following.

Page 185, Section 8.2.16

#### (a) Setting range

- 0<sub>H</sub>: Not divide
- 1<sub>H</sub>: Group 1
- 2<sub>H</sub>: Group 2
- 3<sub>H</sub>: Group 3
- 4<sub>H</sub>: Group 4

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

The default value is set to Not divide (0<sub>H</sub>).



The upper limit output limiter value is automatically set since the division number depends on this setting. The following table lists the upper limit output limiter values which are set when this setting is enabled.

Division Number	CH□ Upper limit output limiter (Un\G42, Un\G74, Un\G106, Un\G138)  ([☐ Page 360, Appendix 2 (19))
2	500 (50.0%)
3	333 (33.3%)
4	250 (25.0%)

CH□ Lower limit output limiter (Un\G43, Un\G75, Un\G107, Un\G139) is set to 0.

#### (91)Sensor compensation function selection (Un\G785) Common

Select the method of the sensor correction for each channel.

b15	to	b12	b11	to	b8	b7	to	b4	b3	to	b0
	CH4			CH3			CH2			CH1	

For details on the sensor compensation function, refer to the following.

Page 223, Section 8.3.2

#### (a) Setting range

- 0<sub>H</sub>: 1-point sensor compensation (standard)
- 1<sub>H</sub>: 2-point sensor compensation

#### (b) Enablement of setting contents

Enable the setting contents by turning Setting change instruction (YnB) OFF  $\rightarrow$  ON  $\rightarrow$  OFF during the setting mode (Setting/operation mode status (Xn1): OFF).

#### (c) Default value

The default value is set to 1-point sensor compensation (standard) (0<sub>H</sub>).

#### (92)Temperature conversion completion flag (Un\G786) Common

This flag checks whether the temperature conversion has started properly for each channel. The following values are stored in this buffer memory area.

- 0<sub>H</sub>: During conversion or unused CH
- 1<sub>H</sub>: First temperature conversion completed

This flag becomes During conversion or unused CH (0<sub>H</sub>) during temperature conversion or for unused channels.

When the first temperature conversion is completed and the temperature process value (PV) is stored in the buffer memory, First temperature conversion completed  $(1_H)$  is set.

The following figure shows the channel assignment of this area.

b15	to	b12	b11	to	b8	b7	to	b4	b3	to	b0
	CH4			CH3			CH2			CH1	

#### (93)Function extension bit monitor (Un\G787) Common


The following settings configured on Switch Setting are stored.

- "Auto-setting at Input Range Change"
- "Setting Change Rate Limiter Setting"
- "Control Output Cycle Unit Selection Setting"

For details on Switch Setting, refer to the following.

Page 108, Section 7.2

The following figure and table show how the setting is stored.



Bit	Flag name (Function extension bit monitor)	Description					
		When the input range is changed, the related buffer memory data is automatically changed to prevent errors of the buffer memory areas that					
b0	Auto-setting at Input Range Change	are out of the setting range. (FF Page 351, Appendix 2 (12) (d))  0: Disable  1: Enable					
b1	Setting Change Rate Limiter Setting	Select whether the setting change rate limiter to be set in a batch or individually. (Fig. Page 155, Section 8.2.10)  0: Temperature Rise/Temperature Drop Batch Setting  1: Temperature Rise/Temperature Drop Individual Setting					
b2	Control Output Cycle Unit Selection Setting	Select 0.1s or 1s as a unit for the cycle of turning on/off the transistor output. (Fig. Page 140, Section 8.2.6)  0: 1s Cycle  1: 0.1s Cycle					
b3 to b15	- (fixed to 0)	- (Unused)					

#### (94)Sampling cycle monitor (Un\G788) Common

Current sampling cycle is stored.

- 0: 500ms/4 channels
- 1: 250ms/4 channels

Sampling cycle is set on Switch Setting. For details on Switch Setting, refer to the following.

Page 108, Section 7.2

#### (95)Latest address of error history (Un\G1279) Common

The latest address of error history is stored.

For details on the error history function, refer to the following.

Page 237, Section 8.3.5

#### (96)Error history 1 to 16 (Un\G1280 to Un\G1407) Common

Errors and alarms occurred in the module are recorded up to 16.

Ex. For the error history 1

Buffer memory						
address	b15	to	b8	b7	to	b0
Un\G1280			Error	code*	1	
Un\G1281		First two digits of the y	/ear		Last two digits of the year	
Un\G1282		Month			Day	
Un\G1283		Hour			Minute	
Un\G1284		Second			Day of the week *2	
Un\G1285						
to			Syster	n area	ì	
Un\G1287						

\*1 For error codes and alarm codes, refer to the following.

Page 315, Section 11.6, Page 318, Section 11.7

\*2 The following table lists the stored value and corresponding each day of the week.

Stored value	Day of the week
0	Sunday
1	Monday
2	Tuesday
3	Wednesday
4	Thursday
5	Friday
6	Saturday

For details on the error history function, refer to the following.

Page 237, Section 8.3.5

## **Appendix 3** How to Check the Serial Number and Function Version

For details on how to check the serial number and function version, refer to the following.
MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
MELSEC-L CC-Link IE Field Network Head Module User's Manual

#### Appendix 4 Differences with MELSEC-Q series Modules

#### Appendix 4.1 Differences with temperature control modules

This section describes the differences in functions and programming methods between the MELSEC-Q series temperature control modules (Q64TCTTN, Q64TCTTBWN, Q64TCRTN, Q64TCRTBWN) and the L60TC4.

#### (1) Functional comparison

#### (a) Added functions

The following table lists the functions added in the L60TC4.

Item	Description	Reference
Input range	The following input ranges are available in the L60TC4.  (1) L60TCTT4, L60TCTT4BW  • K: -200.0 to 1300.0°C  • J: -200.0 to 1000.0°C  • E: -200.0 to 1000.0°C  • N: 0.0 to 1000.0°C  (2) L60TCRT4, L60TCRT4BW  • Pt100: -200.0 to 850.0°C  • JPt100: -200.0 to 640.0°C	Page 36, Section 3.2.2
Temperature input mode	The L60TC4 can be used as a temperature input module. It also enables application of the primary delay digital filter to temperature input, the alert output, and other functions.	Page 116, Section 8.1
Switching the sampling cycle	The sampling cycle can be selected from 250ms/4 channels and 500ms/4 channels. (The cycle is fixed to 500ms in MELSEC-Q series temperature control modules.)	Page 38, Section 3.2.3 (1), Page 108, Section 7.2
Switching the unit of control output cycle	The control output cycle can be selected by 0.1s (0.5s to 100.0s) with the L60TC4. The cycle can be also selected by 1s (1s to 100s) similar to MELSEC-Q series temperature control modules.	Page 38, Section 3.2.3 (2), Page 108, Section 7.2

#### (b) Function that cannot be used

Online module change is not available with the L60TC4.

#### (2) Program compatibility

Programs used in the MELSEC-Q series temperature control modules (Q64TCTTN, Q64TCTTBWN, Q64TCRTN, Q64TCRTBWN) can be used with the L60TC4.

#### (a) I/O signal

Although some I/O numbers of the L60TC4 have different names from those of the MELSEC-Q series temperature control modules, they have the same function and are compatible with each other.

#### (b) Buffer memory

Although some buffer memory areas have been added to the L60TC4, the functions are the same and the program has compatibility.

#### (c) Sampling cycle

For the L60TC4, the sampling cycle can be selected from 250ms and 500ms. For the MELSEC-Q series temperature control modules, the cycle is fixed to 500ms. When using the program used in the MELSEC-Q series temperature control modules with the L60TC4, check that the sampling cycle for the L60TC4 is set to 500ms. When changing the cycle to 250ms, thoroughly verify that the control of the target system has no problem.

#### Appendix 5 When Using GX Developer

This section describes how to configure the setting of the L60TC4 using GX Developer.

### **Appendix 5.1** I/O assignment and intelligent function module switch setting


Configure the setting on the following windows when using GX Developer.

Window name	Application
I/O assignment	Set the type of a module to be connected and the range of I/O signal.
Intelligent function module switch setting	Configure the Switch Setting of the intelligent function module.

#### (1) I/O assignment

Configure the setting on "I/O assignment" in "PLC parameter".

Parameter  $\Rightarrow$  [PLC parameter]  $\Rightarrow$  [I/O assignment]



Item	Description
Туре	Select "Intelli.".
Model name	Enter the model name of the module.
Points	Select 16point.
Start XY	Enter an arbitrary start I/O number of the L60TC4.




Select 16point in Points when using the L60TCTT4BW or L60TCRT4BW.


#### (2) Intelligent function module switch setting

Configure the setting on "Switch Setting" in "PLC parameter".

Parameter  $\Rightarrow$  [PLC parameter]  $\Rightarrow$  [I/O assignment]  $\Rightarrow$  Click Switch setting



Item	Setting item			
Switch 1	CH4 CH3 CH2 CH1	Control output HOLD/CLEAR setting		
		Setting value	Output setting	
		0	CLEAR	
		Other than 0	HOLD	
	0.445		Mode selection*1	
	Setting value*2		Control mode	Number of control loops
	0000 <sub>H</sub>		Standard control	Standard control 4 loops
Switch 2	0001 <sub>H</sub>	Temperature control mode    Mix control (normal mode)   loops	,	Heating-cooling control 2 loops
	0002 <sub>H</sub>			Heating-cooling control 4 loops
	0003 <sub>H</sub>		Mix control (normal mode)	Heating-cooling control 1 loop
				Standard control 2 loops
				Heating-cooling control 2
	0004 <sub>H</sub>		loops	
				Standard control 2 loops
	0100 <sub>H</sub>	Temperature input m	node	_



- \*1 Immediately after the setting is changed, a set value discrepancy error (error code: 0□□E<sub>H</sub>) occurs. To clear the set value discrepancy error, turn off, on, and off Set value backup instruction (Yn8).
- \*2 When the setting is out of the setting value, a switch setting error (error code: 000F<sub>H</sub>) occurs. In this case, the module does not operate properly. Set the correct value.
- \*3 Control in the expanded mode requires an external output module. For details, refer to Page 127, Section 8.2.1 (3).

#### Appendix 5.2 Initial setting and auto refresh setting

The initial setting and auto refresh setting cannot be configured when GX Developer is used. Use the program instead.

#### (1) Initial setting

Configure the initial setting using the program. (Page 250, CHAPTER 10)

#### (2) Auto refresh setting

To access the buffer memory using the program, perform one of the following methods.

#### (a) Access using FROM/TO instruction

Use FROM instruction to store the data read from the buffer memory in the L60TC4 into the specified device. Use TO instruction to write the data of the specified device to the buffer memory in the L60TC4.

For details on FROM/TO instruction, refer to the following.

MELSEC-Q/L Programming Manual (Common Instructions)

#### (b) Access using Intelligent function module device


Use Intelligent function module device (Un\G□) to access the buffer memory in the L60TC4.

Ex. When Error code (Un\G0) is transferred to D0 in the CPU module.


#### Appendix 6 External Dimensions

The following shows the external dimensions of the L60TC4.


#### (1) L60TCTT4




#### (2) L60TCTT4BW



#### (3) L60TCRT4



#### (4) L60TCRT4BW



#### Memo

#### **INDEX**

0 to 9	С
1-point sensor compensation (standard)	Checking the completion of auto tuning
A	(Un\G550, Un\G582, Un\G614, Un\G646) 397
Accuracy	CH□ 2-point sensor compensation gain value
Added functions	(compensation value) (Un\G547, Un\G579, Un\G611,
Adjustment after auto tuning	Un\G643)
Air cooled	CH□ 2-point sensor compensation gain value
Air cooling	(measured value) (Un\G546, Un\G578, Un\G610,
Alarm code list	Un\G642)
Alarm priorities	CHO 2-point sensor compensation offset latch
Alert	completion (Un\G549, Un\G581, Un\G613, Un\G645)
Alert dead band	CH□ 2-point sensor compensation offset latch request
Alert dead band setting (Un\G164)	(Un\G548, Un\G580, Un\G612, Un\G644) 396
Alert mode and settings	CH□ 2-point sensor compensation offset value
Alert output	(compensation value) (Un\G545, Un\G577, Un\G609,
Alert with standby	Un\G641)
Alert with standby (second time) 164	CH□ 2-point sensor compensation offset value
Algorithm of PID control in process-value incomplete	(measured value) (Un\G544, Un\G576, Un\G608,
derivation	Un\G640)
ALM LED	(Un\G46, Un\G78, Un\G110, Un\G142)
Applicable software version	
Applicable solderless terminal	CH□ Alert 1 mode setting (Un\G192, Un\G208,
Applicable wire size	Un\G224, Un\G240)
AT point	CH□ Alert 2 mode setting (Un\G193, Un\G209,
AT simultaneous temperature rise parameter calculation	Un\G225, Un\G241)
completion	CHI Alert 3 mode setting (Un\G194, Un\G210,
AT simultaneous temperature rise parameter calculation	Un\G226, Un\G242)
error status	Un\G227, Un\G243)
Auto configuration at input range change 234 Auto refresh	CH□ Alert definition (Un\G5 to Un\G8)
Auto tuning	CH□ Alert occurrence flag (XnC to XnF) 313,329
Automatic setting when the input range is change	CH□ Alert set value 1 (Un\G38, Un\G70, Un\G102,
	Un\G134)
Auto-setting at input range change 108,109,351,352	CH□ Alert set value 2 (Un\G39, Un\G71, Un\G103,
	Un\G135)
В	Un\G136)
	CH□ Alert set value 4 (Un\G41, Un\G73, Un\G105,
Backup of the calculated value on completion of auto	Un\G137)
tuning	CH□ AT bias setting (Un\G53, Un\G85, Un\G117,
Back-up of the set value fail flag (XnA)313,328	Un\G149)
Batch/individual setting for temperature rise and	CHO AT simultaneous temperature rise parameter
temperature drop	calculation flag (Un\G573, Un\G605, Un\G637, Un\G669)
Buffer memory	CH□ Auto tuning instruction (Yn4 to Yn7) 331
Buffer memory address by mode	CH□ Auto tuning mode selection (Un\G184 to Un\G187)
Buffer memory address for error history	
Buffer memory areas related to auto tuning 142 Buffer memory areas related to control method 135	CH□ Auto tuning status (Xn4 to Xn7) 312,313,326
Buffer memory areas which can be set only in the setting	CH□ AUTO/MAN mode shift (Un\G50, Un\G82,
mode	Un\G114, Un\G146)
Buffer memory data backup	CHI Automatic backup setting after auto tuning of PID

constants (Un\G63, Un\G95, Un\G127, Un\G159)

CHU Control output cycle setting (Un\G47, Un\G79,	CHLI PID control forced stop instruction (YnC to YnF)
Jn\G111, Un\G143)	
CHI Control response parameter (Un\G49, Un\G81,	CH□ Primary delay digital filter setting (Un\G48, Un\G80,
Jn\G113, Un\G145)	Un\G112, Un\G144)
Jn\G738, Un\G754, Un\G770)	(Un\G196, Un\G212, Un\G228, Un\G244) 387
CH□ Cooling proportional band (Pc) setting (Un\G720,	CH□ Process alarm lower lower limit value (Un\G197,
Jn\G736, Un\G752, Un\G768)	Un\G213, Un\G229, Un\G245)
CH□ Cooling transistor output flag (Un\G712 to	CH□ Process alarm lower upper limit value (Un\G198,
Jn\G715)341	Un\G214, Un\G230, Un\G246)
CH□ Cooling upper limit output limiter (Un\G721,	CH□ Process alarm upper lower limit value (Un\G199,
Jn\G737, Un\G753, Un\G769)	Un\G215, Un\G231, Un\G247)
CH□ Decimal point position (Un\G1 to Un\G4) 334	CH□ Process alarm upper upper limit value (Un\G200,
CH□ Derivative action selection (Un\G729, Un\G745,	Un\G216, Un\G232, Un\G248)
Jn\G761, Un\G777)	CH□ Process value (PV) scaling function enable/disable
CH□ Derivative time (D) setting (Un\G37, Un\G69,	setting (Un\G725, Un\G741, Un\G757, Un\G773) 405
Jn\G101, Un\G133)	CH□ Process value (PV) scaling lower limit value
CH□ Forward/reverse action setting (Un\G54, Un\G86,	(Un\G726, Un\G742, Un\G758, Un\G774) 406
Jn\G118, Un\G150)	CH□ Process value (PV) scaling upper limit value
CH□ Heater disconnection alert setting (Un\G58,	(Un\G727, Un\G743, Un\G759, Un\G775) 406
Jn\G90, Un\G122, Un\G154)	CH□ Process value (PV) scaling value (Un\G728,
CH□ Heating control output cycle setting (Un\G47,	Un\G744, Un\G760, Un\G776) 406
Jn\G79, Un\G111, Un\G143)	CH□ Proportional band (P) setting (Un\G35, Un\G67,
CH□ Heating proportional band (Ph) setting (Un\G35,	Un\G99, Un\G131)
Jn\G67, Un\G99, Un\G131)	CH□ Rate alarm alert detection cycle (Un\G202,
CH□ Heating transistor output flag (Un\G21 to Un\G24)	Un\G218, Un\G234, Un\G250)
	CH□ Rate alarm alert output enable/disable setting
CH□ Heating upper limit output limiter (Un\G42, Un\G74,	(Un\G201, Un\G217, Un\G233, Un\G249) 389
Jn\G106, Un\G138)	CH□ Rate alarm lower limit value (Un\G204, Un\G220,
CH□ Input range (Un\G32, Un\G64, Un\G96, Un\G128)	Un\G236, Un\G252)
	CH□ Rate alarm upper limit value (Un\G203, Un\G219,
CHD Integral time (I) setting (Un\G36, Un\G68,	Un\G235, Un\G251)
Jn\G100, Un\G132)	CH□ Self-tuning flag (Un\G575, Un\G607, Un\G639,
CH□ Loop disconnection detection dead band (Un\G60,	Un\G671)
Jn\G92, Un\G124, Un\G156)	CH□ Self-tuning setting (Un\G574, Un\G606, Un\G638, Un\G670)
CHD Loop disconnection detection judgment time (Un\G59, Un\G91, Un\G123, Un\G155)	CH□ Sensor correction value setting (Un\G45, Un\G77,
CH□ Lower limit output limiter (Un\G43, Un\G75,	Un\G109, Un\G141)
Jn\G107, Un\G139)	CH□ Set value (SV) monitor (Un\G25 to Un\G28)
CH□ Lower limit setting limiter (Un\G56, Un\G88,	
Jn\G120, Un\G152)	CH□ Set value (SV) setting (Un\G34, Un\G66, Un\G98,
CH□ MAN output setting (Un\G51, Un\G83, Un\G115,	Un\G130)
Jn\G147)368	CH□ Setting change rate limiter (temperature drop)
CH□ Manipulated value (MV) (Un\G13 to Un\G16)	(Un\G564, Un\G596, Un\G628, Un\G660) 369
	CH□ Setting change rate limiter (temperature rise)
CH□ Manipulated value (MV) for output with another	(Un\G52, Un\G84, Un\G116, Un\G148)369
analog module (Un\G177 to Un\G180)383	CH□ Setting change rate limiter (Un\G52, Un\G84,
CH□ Manipulated value for cooling (MVc) (Un\G704 to	Un\G116, Un\G148)
Jn\G707)339	CH□ Setting change rate limiter time unit setting
CH□ Manipulated value for heating (MVh) (Un\G13 to	(Un\G735, Un\G751, Un\G767, Un\G783) 342,411
Jn\G16)339	CH□ Simultaneous temperature rise AT mode selection
CH□ Manipulated value of cooling (MVc) for output with	(Un\G733, Un\G749, Un\G765, Un\G781) 409
another analog module (Un\G708 to Un\G711) 383	CH□ Simultaneous temperature rise dead time
CH□ Manipulated value of heating (MVh) for output with	(Un\G732, Un\G748, Un\G764, Un\G780) 408
another analog module (Un/G177 to Un\G180) 383	CH□ Simultaneous temperature rise gradient data
CHD Manual reset amount setting (Un\G724, Un\G740,	(Un\G731, Un\G747, Un\G763, Un\G779) 408
Jn\G756, Un\G772)	CHO Simultaneous temperature rise group setting
CH□ Memory of PID constants read instruction (Un\G62, Jn\G94, Un\G126, Un\G158) 343,377	(Un\G730, Un\G746, Un\G762, Un\G778) 407 CH□ Simultaneous temperature rise status (Un\G734,
CH□ Output variation limiter setting (Un\G44, Un\G76,	Un\G750, Un\G766, Un\G782)
Jn\G108, Un\G140)	CH□ Stop mode setting (Un\G33, Un\G65, Un\G97,
CH□ Overlap/dead band function (Un\G723, Un\G739,	Un\G129)
Jn\G755, Un\G771)	CH□ Temperature conversion setting (Un\G695 to
Sincros, omorrij	Un\G697)
	1

CH□ Temperature process value (PV) (Un\G9 to Un\G12)	CT□ Reference heater current value (Un\G280 to Un\G287)
CH□ Temperature process value (PV) for input with	Current sensor for heater disconnection detection 82
another analog module(Un\G689 to Un\G692) 402	outfolk school for ficator disconfication detection.
CH□ Temperature rise judgment flag (Un\G17 to	<b>D</b>
Un\G20)	D
CH□ Transistor output flag (Un\G21 to Un\G24) 341	Data read from non-volatile memory 236
CH□ Unused channel setting (Un\G61, Un\G93,	Data write to non-volatile memory
Un\G125, Un\G157)	Dead band
CH□ Upper limit output limiter (Un\G42, Un\G74,	Dead band setting range
Un\G106, Un\G138)	Default setting registration instruction (Yn9) 332,376
CH□ Upper limit setting limiter (Un\G55, Un\G87,	Default value write completion flag (Xn9) 327
Un\G119, Un\G151)	Derivative action (D-action)
Clearing error	Derivative action selection
Cold junction temperature compensation accuracy:	Deviation alert
(ambient temperature: 0 to 55°C)	Dielectric withstand voltage
Cold junction temperature compensation resistor	Differences
30,87	Differences between auto tuning and self-tuning 175
Cold junction temperature compensation selection	DIN rail hook
(Un\G182)384	Discontinuation of self-tuning
Cold junction temperature process value (Un\G29)	Display unit
	Displayed in English
Compensation lead wire	, , ,
Condition for alert judgment	E
Condition where CH□ Alert occurrence flag (XnC to XnF)	<u> </u>
turns off	Effect from wiring resistance of 1 ohm
Conditions for self-tuning (starting ST)	ERR. LED
Conditions for self-tuning (vibration ST)	Error clear
Conditions for the simultaneous temperature rise	Error code
function	Error code (Un\G0)
Conditions where auto tuning cannot be executed	Error code list
Conditions where auto tuning ends in fail 150	Error code priorities
Conditions where self-tuning ends in fall 130  Conditions where self-tuning does not complete due to	Error history
errors	Error history 1 to 16 (Un\G1280 to Un\G1407) 415
Conditions where self-tuning is not executed 181	Error occurrence flag (Xn2)312,325
Connection terminal	Error reset instruction (Yn2)
Control method	Expanded mode
Control mode	External dimensions
Control mode selection	External output
Control output	
Control output cycle	F
Control output cycle unit selection 140	
Control output cycle unit selection setting 109,414	Fixed value action
Control output setting at CPU stop error	Forward action
Control switching monitor (Un\G183) 385	Full scale
Conversion enable/disable	Function extension bit monitor (Un\G787) 414
Conversion enable/disable setting (Un\G693) 402	Function list
Cooling method setting	Function version
Cooling method setting (Un\G719)	Functional comparison 417
CPU module	
CT monitor method switching (Un\G176) 382	G
CT ratio setting	
CTL-12-S36-10 (0.0 to 100.0A)	GX Developer
CTL-12-S36-8 (0.0 to 100.0A)	GX Works2
CTL 6 P (0.00 to 20.00A)	
CTL 6 P L (0.00 to 20.00A)	Н
CTL-6-P-H (0.00 to 20.00A)	
CT CT input channel assignment setting (Un\G264 to	H/W LED information
Un\G271)	H/W switch information
CTD CT ratio setting (Un\G288 to Un\G295) 392,393	Hardware error flag (Xn3)312,325
CT□ CT selection (GMG272 to GMG279)	HBA LED
Un\G263)	Head module
J	Heater disconnection correction function 217

Heater disconnection correction function selection (Un\G170)	Module joint levers29Module READY flag (Xn0)312,323Module selection107Module's detailed information321Monitoring the scaling value221
example for three-phase heater	Mount position
Heating-cooling control (expanded mode) 126,127 Heating-cooling control (normal mode) 126 High response mode	New module107Number of accesses to non-volatile memory32Number of alert delay169Number of alert delay (Un\G165)379Number of connectable modules82Number of loops14Number of occupied I/O points33Number of parameters34Number of temperature input points32
<u> </u>	0
Indication accuracy   32	Offset (remaining deviation)
Linear207,404Loop disconnection detection204Loops126Lower limit deviation alert160	P control       131,137,357         Package       15         Parameter setting       110         Part names       29
M	PD control
MAN mode shift completion flag (Un\G30) 342,368 Manipulated value (MV) and control output cycle 339 Manual control	Peak current suppression control group setting (Un\G784)         193,412           Performance specifications         32           PI control         132,357           PID action         28           PID auto-correction status         400           PID constant range         32           PID constants         14           PID continuation flag (Un\G169)         128,381           PID control         133           Platinum resistance thermometer type         350           Primary delay digital filter         118

Procedure before operation79Procedure for the self-tuning control177Procedure of auto tuning144Process alarm120Processing of the error history function237Product information321Program compatibility418Programming procedure250Programming tool14Proportional action356Proportional action (P-action)25Proportional band setting206Proportional gain25,356	Simultaneous temperature rise AT disable status
Q	T
Q64TCRTBWN       417         Q64TCRTN       417         Q64TCTTBWN       417         Q64TCTTN       417	T         117           Temperature control method         32           Temperature control mode         13,14,125           Temperature control modules         417           Temperature conversion         212
	Temperature conversion completion flag (Un\G786)
R1.25-3	Temperature conversion method
S	Temperature unit         345           Terminal         30
Sampling cycle	Terminal block

#### U

Unuse Upper	ed channel
V	
Vibration	on ST
w	
Water Water Weight When Measu When When When When When When When When	dog timer error.       323         cooled       207         cooling       404         t       33         AUTO mode is shifted to MAN mode       367         measured value exceeds temperature         greenent range       338         measured value falls below temperature         greenent range       338         the auto tuning does not complete       313         the auto tuning does not start       312         the self-tuning does not start       313         the temperature process value (PV) is abnormal       314         using the L60TC4 as a temperature input module       108          85          92,93         range alort       161

#### **REVISIONS**

\*The manual number is given on the bottom left of the back cover.

Print date	*Manual number	Revision
July, 2011	SH(NA)-081000ENG-A	First edition

Japanese manual version SH-080999-A

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2011 MITSUBISHI ELECTRIC CORPORATION

#### **WARRANTY**

Please confirm the following product warranty details before using this product.

#### 1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

[Gratis Warranty Term]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
  - 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
  - 2. Failure caused by unapproved modifications, etc., to the product by the user.
  - 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
  - 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
  - 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
  - Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
  - 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

#### 2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued.
  - Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

#### 3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

#### 4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation of damages caused by any cause found not to be the responsibility of Mitsubishi, loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products, special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products, replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

#### 5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

Microsoft, Windows, Windows NT, and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries.

Pentium is a trademark of Intel Corporation in the United States and other countries. Ethernet is a trademark of Xerox Corporation.

The SD logo and SDHC logo are trademarks.

All other company names and product names used in this manual are trademarks or registered trademarks of their respective companies.





### MELSEC-L Temperature Control Module User's Manual

MODEL	L60TCTT4/RT4-U-E	
MODEL CODE	13JZ64	
SH(NA)-081000ENG-A(1107)MEE		



HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.